

Programmable thermostat 2-pole with touch display

Operating instructions



WTH-16

Art. no. WDE002478, WDE003478, WDE004478

Accessories

- WDE002495 Floor Sensor

For operating the thermostat in floor and dual mode.

For your safety



DANGER

Risk of serious damage to property and personal injury, e.g. from fire or electric shock, due to incorrect electrical installation.

Safe electrical installation can only be ensured if the person in question can prove basic knowledge in the following areas:

- Connecting to installation networks
- Connecting several electrical devices
- Laying electric cables

These skills and experience are normally only possessed by skilled professionals who are trained in the field of electrical installation technology. If these minimum requirements are not met or are disregarded in any way, you will be solely liable for any damage to property or personal injury.



DANGER

Risk of death from electric shock.

The outputs may carry an electrical current even when the device is switched off. Always disconnect the fuse in the incoming circuit from the supply before working on connected loads.

Table of Content

Function and installation

- Getting to know the thermostat
- Installing the thermostat

Operation

- Displays and operating elements
- Starting up
- Operating the thermostat
- Adjusting the basic settings

Appendix

- Behaviour during mains voltage failure and recovery / power reserve
- What should I do if there is a problem?
- Technical data

Getting to know the thermostat

With the programmable thermostat 2-pole with touch display (referred to in the following as the **thermostat**), you can regulate the room and/or floor temperature. The unit is operated using a touch display.

The thermostat can be connected to electrical underfloor heating systems, radiators or valve drives which can be switched.

The thermostat has a weekly clock with an individually adjustable program. Alternatively, you can select one of 3 pre-programmed weekly programs. Various heating modes with individual temperature setpoints are available: comfort mode, eco mode and frost protection mode.

Operating modes

The thermostat can be operated in four different variants.

- **Room air:** The internal temperature sensor detects the room temperature. The thermostat controls this with the aid of the connected heat load.
- **Floor:** The floor sensor detects the floor temperature. The thermostat controls this with the aid of the underfloor heating.
- **Dual:** The internal temperature sensor monitors the room temperature and controls it with the help of the connected heating systems. At the same time, the floor sensor monitors the floor temperature and limits this to the predefined maximum temperature value ("max temp").
This variant is particularly recommended for temperature-sensitive parquet and laminate floors.
- **PWM:** The pulse width modulator (PWM) switches the heating on and off at regular intervals. In PWM mode, you can adjust the desired temperature using the PWM value (see "Settings the PWM value").
The floor sensor does not work in this operating mode. The room temperature limits are met.



External temperature reduction

In all operating modes, you can connect an external switch or time controls for temperature reduction (TR). The internal temperature control is overwritten here.



Installing the thermostat

Installation site of thermostat and floor sensor



Room air mode or dual mode


To ensure reliable thermostat operation, note the following when planning the installation site:

- (A) Minimum installation height: 1.5 m above the floor.
- (B) Do not install too close to windows, doors or ventilation openings.
- (C) Avoid direct sunlight or direct light from lamps.
Do not install above radiators or other heat sources.
- (D) Do not cover or install behind curtains.

Floor mode or dual mode

- (E) Position at least 1 m from walls or doors.
Install in the middle of the loops of the underfloor heating unit (see drawing).
- (F) Lay the floor sensor in a plastic tube with an inside diameter of 10 mm.

Wire the thermostat




Mounting the thermostat and covers

- 1 Install the thermostat in a flush-mounted box.
- 2 Place the frame onto the insert.
- 3 Press in the snap ring until it presses against the frame.


i Selecting a central plate with switches allows you to disconnect both the device and the connected load from the network at both terminals.

- 4 Press on the central plate until it audibly clicks into place.




Removing the covers

- 1 Using a suitable screwdriver, press on the marked points to loosen the central plate.



- 2 Tilt the central plate forward and remove it.
- 3 Lift out the snap ring using a suitable screwdriver and remove it.
- 4 Remove the frame.

Displays and operating elements



Individual display elements


The following symbols are shown on the display, depending on your selections and the navigation level:

Heating mode selection / default

- (A) Auto mode
Weekly program that is currently set
- (B) Comfort mode / +21 °C
- (C) Eco mode / +19 °C
- (D) Frost protection mode / +7 °C

Symbol for manual mode (with hand): setting was selected manually.

Symbol for external temperature reduction (arrow): temperature is set via TR input.




Basic settings 1/4 / default

- (A) Date and time / 01.01.2015, 12:00
- (B) Frost protection mode (+5 °C to +21 °C) and eco mode (+5 °C to +50 °C) setpoints
- (C) "Pre-programmed weekly programs" menu
- (D) Display brightness (15% to 100%) / 30%
Brightness during standard display

"Pre-programmed weekly programs" selection

- (A) Freely adjustable weekly programmable
- (B) Work
- (C) Family
- (D) Weekend house



Basic settings 2/4 / default


- (A) "Room temperature range" menu (PIN lock)
 - (B) "Floor temperature range" menu (PIN lock)
 - (C) "Calibrate sensor" menu (PIN lock)
 - (D) "Operating modes" menu (PIN lock)
- Red dot on the sensor position indicates the operating mode that is currently selected (here: dual).

"Temperature" settings

- (A) Minimum and maximum room temperature (+5 °C, +35 °C) / +5 °C, +30 °C
- (B) Minimum and maximum floor temperature (+5 °C, +50 °C) / +5 °C, +40 °C
- (C) Calibrate room air sensor (-3 °C to +3 °C) and floor sensor (-9 °C to +9 °C)

"Operating modes" selection

- (A) Room air
Only internal temperature sensor active
- (B) Floor
Only floor sensor active
- (C) Dual
Temperature and floor sensors active
- (D) PWM
Pulse width modulator: the heating switches on and off at regular intervals.



Basic settings 3/4 / default

- (A) Floor sensor type (PIN lock)
Resistance of built-in sensor in ohms at 25 °C: 2 k, 10 k, 12 k, 15 k, 33 k, 47 k
- (B) Valve protection
green: activated, white: deactivated
- (C) Relay output (PIN lock)
Normally open contact (NO=green), Normally closed contact (NC=green)
- (D) Summer/winter time (CEST)
green: activated, white: deactivated




Basic settings 4/4 / default

- (A) Energy efficiency interval
Period for energy efficiency calculation in days / 1 d, 7 d, 30 d
- (B) Exit basic settings




Basic settings for operation

- (A) PIN lock
Settings require PIN entry (PIN: 5)
Applies until you exit basic settings
- (B) Checkbox selected
- (C) Checkbox deselected



Faults

- (A) Internal overheating in thermostat (> +85 °C)
 - (B) Room temperature sensor not detected.
 - (C) Floor temperature sensor not detected.
- All "faults" symbols are yellow.



Starting up

Switching on the thermostat for the first time

If the thermostat is connected and the push-button switch is pressed in (D), the start display appears.

Setting the date and time

- | Touch | Display |
|---|---------|
| (1) Reduce (-) or increase (+) the value marked by the cursor using the navigation keys.
Press key briefly: change value in steps
Press and hold key: change value continuously | |
| (2) Confirm the value and switch to the next one with the selection key.

The settings are saved once you confirm the last value. | |

The thermostat starts with the default settings:

- Comfort heating mode
- Room air operating mode

If a floor sensor is connected, it is detected automatically and the floor operating mode is selected. The thermostat then switches to the standard display.


- i** Also check the following settings:
- **Operating mode:** Always set the dual operating mode manually. If the sensor configuration is changed later, the operating mode does not switch automatically and you also have to set this manually.
 - **Floor sensor type:** Always select the connected floor sensor in the basic settings to ensure correct temperature regulation.
 - All the default settings that are automatically selected when the device is switched on for the first time can be adjusted later on in the "Basic settings" menu.

Standard display

In the standard display, three different windows appear, changing in rotation every 10 seconds. The current settings and measured values are shown.

The current time is displayed at the top of each window. A red line under the display indicates that the heating is currently active.

- (A) **Temperature**
Currently measured temperature
- (B) **Energy efficiency information**
Number of hours of heating during the selected energy efficiency interval
- (C) **Heating mode**
Mode with individual setpoint that currently applies to the heating (here: comfort mode)
A hand next to the symbol indicates that the heating mode was selected manually (manual mode) and the heating is not being controlled by a weekly program. This applies until you reactivate auto mode.




- i** To make the display last as long as possible, it moves slightly every 4 hours (screen saving function).

Operating the thermostat

Overview of operation

You can open the menus from each window of the standard display.



Setting the temperature for comfort mode

- i** Heating the floor or the room to the desired temperature may take several hours. You should therefore wait a while before increasing the temperature.

Setting the temperature setpoint

- | Touch | Display |
|--|---------|
| (1) Switch to the temperature setpoint display:
Press one of the navigation keys.

The setpoint for the room or floor temperature is shown on the display with green underlining. | |
| (2) Lower (-) or raise (+) the setpoint in steps of 0.5 K using the navigation keys (room air and dual operating modes from 5 °C to 35 °C, floor operating mode from 5 °C to 50 °C).

The desired setpoint for the room temperature in comfort mode is shown on the display. | |
| (3) Confirm the new setpoint with the selection key.

The standard display opens. If the measured temperature is lower than the new setpoint, the heating turns on. The display shows red underlining during heating. | |

Settings the PWM value

The pulse width modulator (PWM) switches the heating on and off at regular intervals. In PWM mode, you can adjust the desired temperature using the PWM value. The value is displayed instead of the temperature setpoint, in the same way (see "Setting the temperature setpoint"). The PWM value specifies the percentage that the heating heats in a recurring interval of 10 minutes.

Example:

- 0%: heating is permanently off
- 50%: heating is on for 5 minutes, then off for 5 minutes
- 100%: heating is permanently on

- i** The thermostat automatically returns to the standard display without saving changes if no entries are made for 15 seconds.

Selecting the heating mode

	Touch	Display
<p>① Open heating mode selection: Briefly press the selection key.</p> <p>The following four heating modes are displayed (from left to right):</p> <ul style="list-style-type: none"> - Auto mode - Comfort mode - Eco mode - Frost protection mode <p>The green cursor marks the heating mode that is currently selected (here: auto mode with eco mode programming for the current point in time).</p>		
<p>② Select heating mode: Use the navigation keys to move the cursor to the desired heating mode (here: comfort mode).</p>		
<p>③ Save heating mode and return to standard display: Press the selection key.</p> <p>A hand is displayed in addition to the comfort mode because the mode was selected manually.</p>		

i The thermostat automatically returns to the standard display without saving changes if no entries are made for 15 seconds.

i If the PWM function is active, heating mode selection is suspended.

Setting a weekly program

A weekly program is the schedule for heating phases in eco and comfort modes for the entire week. Each switching time for a heating phase is defined for individual days or a group of days.

Three pre-programmed weekly programs are available (see "Possible settings/pre-programmed weekly programs") and you can change these temporarily. Your settings are only retained until you select another weekly program. In addition, you can create a freely adjustable weekly program of your own to meet your needs. During commissioning, the freely adjustable weekly program is selected but no heating phases are stored.

Navigating the weekly program

	Touch	Display
<p>① Open "Weekly program" menu: Press and hold the selection key on the standard display.</p> <p>The information for a saved heating phase of the active weekly program is shown on the display (here: not heating phase stored).</p> <p>Information per line:</p> <ul style="list-style-type: none"> (A) Days of the week (Mon-Sun = 1-7) green: activated, red: deactivated (B) Heating mode and switching time (C) Operating menu 		
<p>② Select desired function: Use the navigation keys to move the cursor to the desired function.</p>		
<p>③ Activate selected function: Press the selection key.</p> <p>Functions:</p> <ul style="list-style-type: none"> (A) Exit menu (B) Change heating phase (C) Delete heating phase (D) Add new heating phase (E) Scroll between heating phases 		

Creating a new heating phase

	Touch	Display
<p>① Add new heating phase: Select and activate the function "Add heating phase" (D).</p> <p>The heating phase settings display opens.</p>		
<p>② Make settings (see "Editing settings")</p>		

Change heating phase

	Touch	Display
<p>① Select heating phase: Use the "scroll" (E) function to select the heating phase that you want to change (see "Navigating the weekly program").</p>		
<p>② Open settings for heating phase: Select and activate the function "Change heating phase" (B).</p> <p>The heating phase settings display opens.</p>		
<p>③ Change settings (see "Editing settings")</p>		

Editing settings

	Touch	Display
<p>① Activate days of the week: Deactivate (-) or activate (+) the days on which the heating phase runs (green/in bold here) or does not run (red) and confirm your entries with the selection key.</p> <p>The cursor moves to the next day of the week when you press a navigation key and goes to the switching time if you then confirm this with the selection key.</p>		
<p>② Change switching time: Increase (+) or reduce (-) the hours in steps of one and the minutes in steps of ten. Confirm each entry with the selection key.</p> <p>After the first confirmation, the cursor moves to the minute display and after the second confirmation, it moves to the heating mode line.</p>		
<p>③ Set heating mode: Change the active heating mode (green) with the navigation keys and confirm your choice with the selection key.</p> <p>The settings are saved. The "Weekly program" menu appears again.</p>		

Delete heating phase

	Touch	Display
<p>① Select heating phase: Use the "scroll" (E) function to select the heating phase that you want to delete (see "Navigating the weekly program").</p>		
<p>② Delete heating phase: Select and activate the function "Delete heating phase" (C).</p> <p>The next saved heating phase is displayed.</p>		

Exit menu

	Touch	Display
<p>① Select and activate the function "Exit menu" (A).</p> <p>The standard display opens.</p>		

i The thermostat automatically returns to the standard display without saving changes if no entries are made for one minute.

Adjusting the basic settings

Navigating in the basic settings

Selecting a possible setting

① Open basic settings:
Press and hold both navigation keys together.
The first of four pages is displayed. The green cursor marks the first possible "date/time" setting on the first page.

② Select basic settings page:
Starting from the bottom/right icon, open the next page with the (+) navigation key.

Or

Starting from the top/left icon, open the previous page with the (-) navigation key.

Basic settings pages (possible settings from left to right):

- Ⓐ Date/time, heating mode setpoints, pre-programmed weekly programs, display brightness
- Ⓑ Room temperature range, floor temperature range, calibrate sensor, operating modes
- Ⓒ Floor sensor type, valve protection, relay output, summer/winter time (CEST)
- Ⓓ Energy efficiency interval, exit

③ Open possible setting:
Use the navigation keys to move the cursor to the desired possible setting.
Confirm your choice with the selection key.

With PIN entry Ⓔ:

Some possible settings are protected by PIN entry for safety reasons. The authorisation remains valid until you exit the basic settings.


Enter the PIN (5) using the navigation keys.
Confirm your entry with the selection key.

Or

Without PIN entry Ⓕ:

You do not have to enter a PIN for standard settings.


The setting window is displayed.



Exit menu

① Go to the last page of the basic settings 4/4 and select the "exit" symbol with the cursor.

② Press the selection key to return to the standard display.



Adjusting the basic settings

Depending on the possible setting, you can change values, select icons or select icons and change the corresponding values.


Changing values

Date/time (example)

① Reduce (-) or increase (+) a value with the navigation keys.

② Confirm the value and switch to the next one with the selection key.


When you confirm the last value, the settings are saved. The display switches to the current basic settings page.



Selecting an icon

Pre-programmed weekly programs (example)

- ① Select weekly program:
Use the navigation keys to move the cursor to the desired weekly program.
- ② Confirm your choice with the selection key.
The current page of the basic settings is displayed.




Selecting an icon and changing the value

Heating mode setpoints (example)

The cursor marks the first symbol (here: frost protection mode).

- ① Change the corresponding value with the navigation keys.
- ② Confirm the value and switch to the next symbol (here: eco mode) with the selection key.

When you confirm the last value, the settings are saved. The display switches to the current basic settings page.




i The thermostat automatically returns to the standard display without saving changes if no entries are made for one minute.

Setting options

Basic settings 1/4

- Ⓐ Date/time
- Ⓑ Setpoints for frost protection and eco mode
- Ⓒ Pre-programmed weekly programs (see "Weekly program curve")
You can choose between three default weekly programs. The default programs are useful for efficient heating with different alternative uses. They can be changed but not permanently overwritten. The next time you select them, the previous changes are discarded. In addition, you can also configure your own weekly program and select that. This is retained permanently even when you change programs.
- Ⓓ Display brightness



- Ⓔ Reduced brightness improves the display's service life.

Weekly program curve

The diagrams show the temperature curve over the course of a day:

- Ⓐ Temperature
- Ⓑ Time in hours or days (Monday to Sunday = 1-7)
- Ⓒ Temperature curve at weekend (dotted line)
- Ⓓ Temperature curve on workdays (solid line)
- Ⓔ Raise temperature (optimum start)

The higher setpoint temperature is reached by the set time. Heating begins in advance. The thermostat automatically learns the time needed to heat up.

- Ⓕ Lower temperature

The temperature is reduced at the set time until it reaches the lower setpoint temperature after the cooling down time.

Freely adjustable weekly programmable:

Use the comfort and eco modes to set a temperature curve to match your needs.

Example:

The heating runs in eco mode at night and in comfort mode during the day. On workdays, the comfort setpoint temperature is reached at 6 am and is lowered again after 10 pm. At the weekend, comfort mode is used for the heating between 8 am and midnight.

