

# Esmi Impresia Red IP65 Deep Base

Instruction Sheet  
R10212GB0



## **Schneider Electric Fire & Security Oy**

Sokerilinnantie 11 C  
FI-02600 Espoo, Finland  
Tel: +358 10 446 511  
Website: [www.se.com](http://www.se.com)  
Document number: R10212GB0  
Published: 18.12.2020

© 2020 – Schneider Electric. All Rights Reserved. This information is only to be used as guidance. Subject to changes and errors.

# 1 Esmi Impresia Red IP65 Deep Base

Esmi Impresia Red IP65 Deep Base (FFS06741013) is a waterproof protected deep base specially designed for installing in addressable fire alarm systems with Esmi ELC loop controller supporting Schneider Electric communication protocol. The deep base is suitable for wall mounting in applications in aggressive environments requiring IP65 protection of the devices. Esmi Impresia Red IP65 Deep Base comes in a kit with a solid rubber gasket, o-ring sealant and IP65 rated cable glands. Esmi Impresia Standard Base (FFS06741018) is mounted with screws. EN 60529 for indoor and outdoor use.

## 1.1 Installation

1. Remove the Esmi Impresia Standard Base from the deep base body.
2. Remove the knockouts and place the two cable glands from the kit.
3. Fix the deep base and the solid gasket to the mounting surface.
4. Run the loop wires through the cable glands.
5. Mount the Esmi Impresia Standard Base back in place as observe the short mark on its narrow side to align with the short mark of the deep base.
6. Then fix the Esmi Impresia Standard Base to the deep base body with the screws from the kit.
7. Connect the loop wires to the standard base terminals according the connection diagram. Please also refer to the installation manual of the Esmi Impresia Red VAD Wall Mounted Sounder (FFS06741012) or Esmi Impresia White VAD Wall Mounted Sounder (FFS06741015).
8. To perform the correct wiring - the electrical connection may differ according that the sounder is with or without a built-in isolator module.



Made in Bulgaria  
EN 60529+A1:2004

1 Esmi Impresia Red IP65 Deep Base

### 1 Structure /

**Attention:**  
The o-ring sealant must be correctly fitted in the channel to provide the declared IP65 rating!

- (1) - Solid rubber gasket
- (2) - Deep base body
- (3) - Cable glands IP65 (2 pcs.)
- (4) - O-ring rubber sealant
- (5) - **Standard base**
- (6) - Screws for fixing the standard base to the deep base (2 pcs.)

### 2 Surface Mounting

Remove the knockouts of the cable gland holes./

Place the back box in upright position; Mount cable glands with IP65 into the holes and tighten the nuts underneath./

### 3 Connection Diagram

**ATTENTION:** Disconnect the loop power before installing the sounder!/  
**RI** - Remote Indicator  
**+Loop** - Positive loop wire  
**-Loop** - Negative loop wire  
**Earth** - Earth point

**Attention:**  
Do not drill holes in the solid rubber gasket in advance! Place the gasket behind the deep base and fix them together to the installation surface./

Mount the deep base to the wall placing the solid rubber gasket behind./