## **DATA SHEET**

tightening belt



ww.kopos.com

he support ng and

## SPK 200X4.6

product description:	The tightening belt serves for attaching the cable to the support trunking.
	The tightening belt should be placed under the trunking and tightened for the diameter of the cable.
	The maximum distance of tightening belts is 600 mm.
configuration:	XX - stainless steel AISI 304
sales amount:	á 100 pc
classification:	ČSN 73 0895 ZP 27/2008 P90-R DIN 41012-12 E90 STN 92 0205 PS 90 Fire classification is depend on the specific conditions of the cable tray, detailed in the catalog Systems with maintained functionality in fire.