## Base for a wireless dimmer switch, 71 x 71 mm, claw fixing

## 360-00002



Base with claw fixing for mounting a wireless dimmer switch (for Hue system, EnOcean®, Bluetooth® and KNX®). You can click it together and combine it with one or more flush-mounting mechanisms from Niko.

## Technical data

Base for a wireless dimmer switch, 71 x 71 mm, claw fixing.

- Fixing method
  - simple mounting in a flush-mounting box with grip surfaces
  - with claws that rotate open using screws with a combination screwhead (Pz2 or slot 1 x 5.5 mm), for mounting in a flush-mounting box with grip surfaces
  - engagement depth of claws: 23.5 mm
  - claws turn back completely when loosened
- Centre-to-centre distance
  - horizontal coupling and vertical coupling with centre-to-centre distance 71 mm
  - horizontal connection of several bases is quick and perfect thanks to the folded-up dovetails on the left and right side
  - extra robustness due to the folded-up edges on the outside of the base and the continuation to the inside of the base
- Marking: CE



