


PRODUCT-DETAILS

1721-281

1721-281 Afdekraam 1gang(s) zwart - Busch-axcent



Algemene informatie

Type	1721-281
Artikelnummer	2CKA001754A4409
EAN	4011395126363
Omschrijving	1721-281 Afdekraam 1gang(s) zwart - Busch-axcent
Omschrijving	Afdekraam 1-voudig afdekraam

Installation

Instructies en handleidingen	No document needed
------------------------------	--------------------

Technical

Gegevensblad, technische informatie	No document needed
Aantal eenheden	1
Schakelaarprogramma	Busch-axcent 63x63
Montagetype	Inbouw
Soort bevestiging	Klem
Montagerichting	Horizontaal Verticaal
Uitvoering oppervlakte	Onbehandeld Glanzend

Materiaal	Thermoplast
Voorzien van labelruimte	Nee
RAL-nummer	RAL 9005 - Gitzwart
Kleur	zwart

Environmental

Beschermingsgraad	IP20
RoHS-status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS-informatie	2CKA200000E2756
REACH-verklaring	2CKA309999E9999

Dimensions

Product netto breedte	91 mm
Product netto hoogte	91 mm
Product netto diepte	11 mm
Product netto gewicht	31 g

Ordering

Minimale bestelhoeveelheid	1 stuk
Pakketniveau 1 Units	karton 10 stuk
Pakketniveau 1 Brutogewicht	0.416 kg
Nummer douanetarief	85389099
E-Number (Finland)	2166200
E-Number (Sweden)	1817620
Land van herkomst	Germany (DE)

Certificates and Declarations

Conformiteitsverklaring - CE	2CKA200000E2756
------------------------------	-----------------

Classifications

ETIM 8	EC000007 - Afdekraam schakelmateriaal
ETIM 9	EC000007 - Afdekraam schakelmateriaal
WEEE-categorie	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001731A1981	1720-885 Rocker Switch Pull cord black matt - 63x63	1720-885	1	piece
2CKA001710A3892	1740 DR/03-885 Cover plate with legend Level switch Turn button black matt - 63x63	1740 DR/03-885	1	piece
2CKA001710A3893	1740 DRL-885-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" black matt - 63x63	1740 DRL-885-503	1	piece
2CKA001710A3894	1740-885 Cover plate with legend Venetian blind Turn button Symbol "arrows" black matt - 63x63	1740-885	1	piece
2CKA001710A3895	1742-885 Cover Plate Blind cap 1 gang with Mounting plate black matt - 63x63	1742-885	1	piece

2CKA001724A4371	1743/10-04-885 Cover Plate SAT 4 gang black matt - 63x63	1743/10-04-885	1	piece
2CKA001724A4298	1743-885 Cover Plate SAT 3 gang black matt - 63x63	1743-885	1	piece
2CKA001710A3896	1745-885 Cover Plate telephone connector boxes (VDo) black matt - 63x63	1745-885	1	piece
2CKA001710A3897	1746/10-885 Cover Plate Telecommunication inserts 50 x 50 mm black matt - 63x63	1746/10-885	1	piece
2CKA001710A3898	1746-885 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid black matt - 63x63	1746-885	1	piece
2CKA001710A4099	1747 BSI-885 Intermediate Ring For cover plates Busch-Balance® SI black matt - 63x63	1747 BSI-885	1	piece
2CKA001710A3899	1748-885 Cover Plate Data connection 2 gang black matt - 63x63	1748-885	1	piece
2CKA001710A3900	1749-885 Cover Plate Cable outlet black matt - 63x63	1749-885	1	piece
2CKA001710A3901	1750-885 Cover Plate BNC/TNC 2 gang black matt - 63x63	1750-885	1	piece
2CKA001723A0259	1751-885 Cover Plate Loudspeaker 2 gang black matt - 63x63	1751-885	1	piece
2CKA001710A3902	1755 SL/PZ-885-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" black matt - 63x63	1755 SL/PZ-885-101	1	piece
2CKA001753A0252	1756-885 Cover Plate Busch-Infolicht® black matt - 63x63	1756-885	1	piece
2CKA001724A4299	1758-885 Cover plate with labelling field For data connection housing 2 gang black matt - 63x63	1758-885	1	piece
2CKA001731A4005	1764 NLI/KI-885 Rocker with labelling field Switch/push button Single push button Symbol "bell" black matt - 63x63	1764 NLI/KI-885	1	piece
2CKA001731A1982	1764 NLI-885 Rocker with labelling field Switch/push button Single push button black matt - 63x63	1764 NLI-885	1	piece
2CKA001710A3903	1766-885 Cover Plate TAE 1 gang black matt - 63x63	1766-885	1	piece
2CKA001753A0261	1770-885-103 Cover Plate Time switch Toggle 1 ... 15 Min black matt - 63x63	1770-885-103	1	piece
2CKA001753A0304	1771-885-103 Cover Plate Time switch Toggle 10 ... 120 Min black matt - 63x63	1771-885-103	1	piece
2CKA001751A3105	1785 JA/02-885 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" black matt - 63x63	1785 JA/02-885	1	piece
2CKA001751A3036	1785 JA-885 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" black matt - 63x63	1785 JA-885	1	piece
2CKA001751A3037	1785/11-885 Rocker with legend Switch/push button Two-part rocker DND, MUR black matt - 63x63	1785/11-885	1	piece
2CKA001751A3038	1785-885 Rocker Switch/push button Two-part rocker black matt - 63x63	1785-885	1	piece
2CKA001751A3104	1786 JA/02-885 Rocker with legend Symbol "arrows" black matt - 63x63	1786 JA/02-885	1	piece
2CKA001751A3040	1786/11-885 Rocker Switch/push button Single rocker DND black matt - 63x63	1786/11-885	1	piece
2CKA001751A3094	1786-885-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint black matt - 63x63	1786-885-500	1	piece
2CKA001751A3042	1788-885 Rocker Switch/push button Single rocker black matt - 63x63	1788-885	1	piece
2CKA001751A3043	1789 H-885 Rocker with legend Switch/push button Single rocker Heizung black matt - 63x63	1789 H-885	1	piece
2CKA001751A3044	1789 KI-885 Rocker with legend Switch/push button Single rocker Symbol "bell" black matt - 63x63	1789 KI-885	1	piece
2CKA001751A3045	1789 LI-885 Rocker with legend Switch/push button Single rocker Symbol "light" black matt - 63x63	1789 LI-885	1	piece
2CKA001751A3154	1789 N-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 N-885	1	piece
2CKA001751A3164	1789 ST-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 ST-885	1	piece

2CKA001751A3046	1789 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	1789 TR-885	1	piece
2CKA001751A3047	1789-885 Rocker Switch/push button Single rocker black matt - 63x63	1789-885	1	piece
2CKA001710A3905	1792-885 Cover plate with legend Hotel card Hotel card Card black matt - 63x63	1792-885	1	piece
2CKA001710A3906	1794 TA-885 Cover plate with legend for Thermostat Turn button black matt - 63x63	1794 TA-885	1	piece
2CKA001710A3907	1794-885 Cover Plate for Thermostat Turn button black matt - 63x63	1794-885	1	piece
2CKA001710A4020	1795 HK-885 Cover Plate for Thermostat Turn button black matt - 63x63	1795 HK-885	1	piece
2CKA001710A4052	1795 HKEA-885 Cover plate with legend for Thermostat Turn button 1 sliding switch black matt - 63x63	1795 HKEA-885	1	piece
2CKA001710A3908	1795 TA-885 Cover plate with legend for Thermostat Turn button 1 sliding switch black matt - 63x63	1795 TA-885	1	piece
2CKA001710A3909	1795-885 Cover plate with legend for Thermostat Turn button 1 sliding switch black matt - 63x63	1795-885	1	piece
2CKA001753A0314	1796-885 Cover Plate Pull cord black matt - 63x63	1796-885	1	piece
2CKA001710A3910	1800-885 Cover plate with labelling field Modular Jack 2 gang black matt - 63x63	1800-885	1	piece
2CKA001710A3911	1803-02-885 Cover plate with labelling field UAE/IAE (ISDN) 2 gang black matt - 63x63	1803-02-885	1	piece
2CKA001710A3912	1803-885 Cover plate with labelling field UAE/IAE (ISDN) 1 gang black matt - 63x63	1803-885	1	piece
2CKA002013A5410	20 EUAB-885 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	20 EUAB-885	1	piece
2CKA002011A6211	20 EUC-885-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) black matt - 63x63	20 EUC-885-500	1	piece
2CKA002013A5330	20 EUCBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Control light; LED /Green black matt - 63x63	20 EUCBL-885	1	piece
2CKA002013A5331	20 EUCBLI-885 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter Night orientation light with Night light; LED /White black matt - 63x63	20 EUCBLI-885	1	piece
2CKA002013A5332	20 EUCKSDV-885 Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	20 EUCKSDV-885	1	piece
2CKA002013A5333	20 EUCKS-885 Socket insert Protective Contact (SCHUKO) Safety Shutter Protective contact (SCHUKO) black matt - 63x63	20 EUCKS-885	1	piece
2CKA002013A5434	20 EUCNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	20 EUCNB-885	1	piece
2CKA002013A5444	20 EUICRB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	20 EUICRB-885	1	piece
2CKA002018A1495	20 EUK-885 Socket insert Protective Contact (SCHUKO) with Hinged Lid black matt - 63x63	20 EUK-885	1	piece
2CKA002018A1523	20 EUKB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid black matt - 63x63	20 EUKB-885	1	piece
2CKA002011A3884	20 EUN-885 Socket insert Protective Contact (SCHUKO) black matt - 63x63	20 EUN-885	1	piece
2CKA002017A0902	20 MUCKS-885-500 Socket insert Safety Shutter French norm NF black matt - 63x63	20 MUCKS-885-500	1	piece
2CKA001751A3173	2029 UC-885 Bell push-switch DND / MUR insert Single push button Push button DND, MUR and Symbol "bell" with LED black matt - 63x63	2029 UC-885	1	piece
2CKA002495A0092	2095 UC-885 Socket insert Equipotential compensation Socket outlet 2-position black matt - 63x63	2095 UC-885	1	piece
2CKA002013A5480	23 EUICB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	23 EUICB-885	1	piece
2CKA002013A5454	2300 EUICB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	2300 EUICB-885	1	piece
2CKA002113A5340	2300 UCRKS-885-503 Cover Plates (partly incl. Insert) Safety Shutter black matt - 63x63	2300 UCRKS-885-503	1	piece

2CKA002011A3885	2310EUGL/VA-885-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) black matt - 63x63	2310EUGL/VA-885-11	1	piece
2CKA001719A0223	2518-WD-885 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring black matt - 63x63	2518-WD-885	1	piece
2CKA001751A3183	2520 KI-885 Rocker with legend Switch/push button Single rocker Symbol "bell" black matt - 63x63	2520 KI-885	1	piece
2CKA001751A3193	2520 LI-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 LI-885	1	piece
2CKA001751A3202	2520 TR-885 Rocker Switch/push button Single rocker black matt - 63x63	2520 TR-885	1	piece
2CKA001724A4301	2533-885 Cover Plate Bore hole 1 gang black matt - 63x63	2533-885	1	piece
2CKA001710A3913	2542 DR/01-885 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" black matt - 63x63	2542 DR/01-885	1	piece
2CKA001710A3914	2542 DR/02-885 Cover plate with legend Level switch Turn button Symbol "1-2-3" black matt - 63x63	2542 DR/02-885	1	piece
2CKA001724A4405	2553-885 Cover Plate XLR 1 gang black matt - 63x63	2553-885	1	piece
2CKA001753A0397	2561-02-885 Cover Plate Modular Jack 2 gang black matt - 63x63	2561-02-885	1	piece
2CKA001753A0406	2561-885 Cover Plate Modular Jack 1 gang black matt - 63x63	2561-885	1	piece
2CKA003116A0671	3120 EUCB-885 Socket insert FI-Schukomat Protective Contact (SCHUKO) 30 mA black matt - 63x63	3120 EUCB-885	1	piece
2CKA003117A0013	3151 UC-885 RCD - Insert Buschmat RCD 30 mA black matt - 63x63	3151 UC-885	1	piece
2CKA006115A0488	6108/61-885-500 Coverplate f. CE	6108/61-885-500	1	piece
2CKA006155A0065	6109/03-885-500 Coverplate f. RTC	6109/03-885-500	1	piece
2CKA006132A0381	6122/10-885-500 BW standard	6122/10-885-500	1	piece
2CKA006115A0215	6125/01-885-500 Control element 1g w. BAU	6125/01-885-500	1	piece
2CKA006115A0227	6125/02-885-500 Control element 1/2gang	6125/02-885-500	1	piece
2CKA006116A0205	6126/01-885-500 Control element 2g w. BAU	6126/01-885-500	1	piece
2CKA006116A0217	6126/02-885-500 Control element 2/4gang	6126/02-885-500	1	piece
2CKA006117A0231	6127/01-885-500 Control element 4g w. BAU	6127/01-885-500	1	piece
2CKA006117A0243	6127/02-885-500 Control element 4/8gang	6127/02-885-500	1	piece
2CKA006134A0339	6128/28-885-500 RTC Control element 2/4g	6128/28-885-500	1	piece
2CKA006135A0166	6129/01-885-500 Control element 3/6g w. IR	6129/01-885-500	1	piece
2CKA006430A0386	6430-885-102 Control Element for Venetian blind black matt - 63x63	6430-885-102	1	piece
2CKA006430A0389	6435-885 Cover plate with legend for Time switch black matt - 63x63	6435-885	1	piece
2CKA006470A0011	6476-885 Cover Plate for Proximity switch black matt - 63x63	6476-885	1	piece
2CKA006400A0063	6477-885 Cover Plate PowerDock 1 gang black matt - 63x63	6477-885	1	piece
2CKA006599A2966	6540-885-102 Cover Plate for Dimmer Turn button with Neon lamp black matt - 63x63	6540-885-102	1	piece
2CKA006599A2967	6541-885 Cover Plate for Cooling black matt - 63x63	6541-885	1	piece
2CKA006599A2968	6543-885-101 Control Element for Switch/dimmer Single push button black matt - 63x63	6543-885-101	1	piece
2CKA006599A2969	6545-885 Control Element for Dimmer Two-part button with Neon lamp black matt - 63x63	6545-885	1	piece

2CKA006730A0141	6736 FoH-885 Control Element for Switch/dimmer Two-part button black matt - 63x63	6736 FoH-885	1	piece
2CKA006800A2840	6815-885-101-500 Cover Plates (partly incl. Insert) Movement sensor black matt - 63x63	6815-885-101-500	1	piece
2CKA008200A0126	8253-885 Cover Plate Loudspeaker black matt - 63x63	8253-885	1	piece
2CKA006220A0634	CP-FCC-885 C-plate Fan Coil	CP-FCC-885	1	piece
2CKA006220A0631	CP-RTC-885 C-plate RT sensor unit	CP-RTC-885	1	piece
2CKA006220A0632	MD-F-1.0.1-885 Movement detector	MD-F-1.0.1-885	1	piece
2CKA006220A0633	MSA-F-1.1.1-885 Mov. detector/actuator 1g	MSA-F-1.1.1-885	1	piece
2CKA006200A0098	MSA-F-1.1.1-885-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-885-WL	1	piece
2CKA006220A0618	SR-1-885 Solo free@home black matt - 63x63	SR-1-885	1	piece
2CKA006220A0623	SR-2-885 Solo free@home black matt - 63x63	SR-2-885	1	piece
2CKA006220A0620	SRB-1-885 Solo free@home black matt - 63x63	SRB-1-885	1	piece
2CKA006220A0625	SRB-2-885 Solo free@home black matt - 63x63	SRB-2-885	1	piece
2CKA006220A0622	SRD-1-885 Solo free@home black matt - 63x63	SRD-1-885	1	piece
2CKA006220A0627	SRD-2-L-885 Solo free@home black matt - 63x63	SRD-2-L-885	1	piece
2CKA006220A0628	SRD-2-R-885 Solo free@home black matt - 63x63	SRD-2-R-885	1	piece
2CKA006220A0619	SRL-1-885 Solo free@home black matt - 63x63	SRL-1-885	1	piece
2CKA006220A0624	SRL-2-L-885 Solo free@home black matt - 63x63	SRL-2-L-885	1	piece
2CKA006220A0629	SRL-2-R-885 Solo free@home black matt - 63x63	SRL-2-R-885	1	piece
2CKA006220A0621	SRS-1-885 Solo free@home black matt - 63x63	SRS-1-885	1	piece
2CKA006220A0626	SRS-2-L-885 Solo free@home black matt - 63x63	SRS-2-L-885	1	piece
2CKA006220A0630	SRS-2-R-885 Solo free@home black matt - 63x63	SRS-2-R-885	1	piece
2CKA001582A0346	1571 CN-84 Cover plate with labelling field Busch -Infoline® Signalling Single push button studio white - 63x63	1571 CN-84	1	piece
2CKA001582A0348	1572 CN-84 Cover plate with labelling field Busch -Infoline® Signalling Touch control button Clear studio white - 63x63	1572 CN-84	1	piece
2CKA001582A0350	1573 CN-84 Cover plate with labelling field Busch -Infoline® Signalling studio white - 63x63	1573 CN-84	1	piece
2CKA001582A0353	1575 CN-84 Cover Plate Busch-Infoline® Signalling studio white - 63x63	1575 CN-84	1	piece
2CKA001731A1923	1716-84 Cover Busch-Infolicht® studio white - 63x63	1716-84	1	piece
2CKA001731A1916	1720-84 Rocker Switch Pull cord studio white - 63x63	1720-84	1	piece
2CKA001710A3808	1740 DR/03-84 Cover plate with legend Level switch Turn button studio white - 63x63	1740 DR/03-84	1	piece
2CKA001710A3512	1740 DRL-84-503 Cover Plate Level switch Turn button Symbol "2-1-3" studio white - 63x63	1740 DRL-84-503	1	piece
2CKA001710A3172	1740-84 Cover plate with legend Venetian blind Turn button Symbol "arrows" studio white - 63x63	1740-84	1	piece
2CKA001710A3161	1742-84 Cover Plate Blind cap 1 gang with Mounting plate studio white - 63x63	1742-84	1	piece
2CKA001710A3991	1742-84-500 Cover Plates (partly incl. Insert) Blind cap 0 gang studio white - 63x63	1742-84-500	1	piece
2CKA001724A4368	1743/10-04-84 Cover Plate SAT 4 gang studio white - 63x63	1743/10-04-84	1	piece
2CKA001724A4332	1743-84-500 Cover Plates (partly incl. Insert) SAT 3 gang studio white - 63x63	1743-84-500	1	piece
2CKA001710A3173	1745-84 Cover Plate telephone connector boxes (VDo) studio white - 63x63	1745-84	1	piece
2CKA001710A3993	1746/10-84-500 Cover Plates (partly incl. Insert) Telecommunication inserts 0 gang studio white - 63x63	1746/10-84-500	1	piece
2CKA001710A3167	1746-84 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid studio white - 63x63	1746-84	1	piece
2CKA001710A4096	1747 BSI-84 Intermediate Ring For cover plates Busch-Balance® SI studio white - 63x63	1747 BSI-84	1	piece
2CKA001710A3863	1747 SI-84 Cover Plates (partly incl. Insert) studio white - 63x63	1747 SI-84	1	piece

2CKA001710A3861	1747-84 Intermediate Ring studio white - 63x63	1747-84	1	piece
2CKA001710A3656	1748-84 Cover Plate Data connection 2 gang studio white - 63x63	1748-84	1	piece
2CKA001710A3163	1749-84 Cover Plate Cable outlet studio white - 63x63	1749-84	1	piece
2CKA001710A3166	1750-84 Cover Plate BNC/TNC 2 gang studio white - 63x63	1750-84	1	piece
2CKA001723A0240	1751-84 Cover Plate Loudspeaker 2 gang studio white - 63x63	1751-84	1	piece
2CKA001710A3175	1755 SL/PZ-84-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" studio white - 63x63	1755 SL/PZ-84-101	1	piece
2CKA001753A0092	1756-84 Cover Plate studio white - 63x63	1756-84	1	piece
2CKA001724A2761	1758-84 Cover plate with labelling field For data connection housing studio white - 63x63	1758-84	1	piece
2CKA001731A1877	1764 NLI-84 Rocker with labelling field Switch/push button Single push button studio white - 63x63	1764 NLI-84	1	piece
2CKA001710A3992	1766-84-500 Cover Plates (partly incl. Insert) TAE 0 gang studio white - 63x63	1766-84-500	1	piece
2CKA001753A0258	1770-84-103 Cover Plate Time switch Toggle 1 ... 15 Min studio white - 63x63	1770-84-103	1	piece
2CKA001753A0301	1771-84-103 Cover Plate Time switch Toggle 10 ... 120 Min studio white - 63x63	1771-84-103	1	piece
2CKA001751A3099	1785 JA/02-84 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white - 63x63	1785 JA/02-84	1	piece
2CKA001751A3088	1785 JA-84-500 Cover Plates (partly incl. Insert) Venetian blind Two-part rocker Symbol "arrows" studio white - 63x63	1785 JA-84-500	1	piece
2CKA001751A3128	1785 K-84-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker None studio white - 63x63	1785 K-84-500	1	piece
2CKA001751A2992	1785/11-84 Rocker with legend Switch/push button Two-part rocker DND, MUR studio white - 63x63	1785/11-84	1	piece
2CKA001751A3076	1785-84-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint studio white - 63x63	1785-84-500	1	piece
2CKA001751A3098	1786 JA/02-84 Rocker Venetian blind Single rocker studio white - 63x63	1786 JA/02-84	1	piece
2CKA001751A2998	1786/11-84 Rocker Switch/push button Single rocker DND studio white - 63x63	1786/11-84	1	piece
2CKA001751A3074	1786-84-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white - 63x63	1786-84-500	1	piece
2CKA001751A2750	1788-84 Rocker Switch/push button Single rocker studio white - 63x63	1788-84	1	piece
2CKA001751A2751	1789 H-84 Rocker with legend Switch/push button Single rocker Heizung studio white - 63x63	1789 H-84	1	piece
2CKA001751A2754	1789 KI-84 Rocker with legend Switch/push button Single rocker Symbol "bell" studio white - 63x63	1789 KI-84	1	piece
2CKA001751A3084	1789 LI-84-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Symbol "light" studio white - 63x63	1789 LI-84-500	1	piece
2CKA001751A3151	1789 N-84-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white - 63x63	1789 N-84-500	1	piece
2CKA001751A3161	1789 ST-84-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Various symbols studio white - 63x63	1789 ST-84-500	1	piece
2CKA001751A2755	1789 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	1789 TR-84	1	piece
2CKA001751A3091	1789-84-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white - 63x63	1789-84-500	1	piece
2CKA001710A3698	1794 TA-84 Cover plate with legend for Thermostat Turn button studio white - 63x63	1794 TA-84	1	piece
2CKA001710A4017	1795 HK-84 Cover Plate for Thermostat Turn button studio white - 63x63	1795 HK-84	1	piece

2CKA001710A4049	1795 HKEA-84 Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - 63x63	1795 HKEA-84	1	piece
2CKA001710A3725	1795 TA-84 Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - 63x63	1795 TA-84	1	piece
2CKA001753A0311	1796-84 Cover Plate Pull cord studio white - 63x63	1796-84	1	piece
2CKA001710A3990	1800-84-500 Cover Plates (partly incl. Insert) Modular Jack 2 gang studio white - 63x63	1800-84-500	1	piece
2CKA001710A1551	1803-02-84-500 Cover Plates (partly incl. Insert) UAE/IAE (ISDN) 2 gang studio white - 63x63	1803-02-84- 500	1	piece
2CKA001710A1550	1803-84-500 Cover Plates (partly incl. Insert) UAE/IAE (ISDN) 1 gang studio white - 63x63	1803-84-500	1	piece
2CKA002013A5407	20 EUAB-84 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter studio white - 63x63	20 EUAB-84	1	piece
2CKA002011A6207	20 EUC-84-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - 63x63	20 EUC-84- 500	1	piece
2CKA002013A5286	20 EUCBL-84 Socket insert Protective Contact (SCHUKO) Safety Shutter with Control light; LED /Green studio white - 63x63	20 EUCBL-84	1	piece
2CKA002013A5294	20 EUCBLI-84 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter Night orientation light with Night light; LED /White studio white - 63x63	20 EUCBLI-84	1	piece
2CKA002013A5268	20 EUCKS/DV-84 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white - 63x63	20 EUCKS/DV- 84	1	piece
2CKA002013A5372	20 EUCKS-84-500 Socket insert Protective Contact (SCHUKO) Safety Shutter Protective contact (SCHUKO) studio white - 63x63	20 EUCKS-84- 500	1	piece
2CKA002013A5441	20 EUCRB-84-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - 63x63	20 EUCRB-84- 500	1	piece
2CKA002018A1509	20 EUK-84-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) with Hinged Lid studio white - 63x63	20 EUK-84-500	1	piece
2CKA002018A1520	20 EUKB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid studio white - 63x63	20 EUKB-84	1	piece
2CKA002011A6209	20 EUN-84-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - 63x63	20 EUN-84- 500	1	piece
2CKA001751A3170	2029 UC-84 Bell push-switch DND / MUR insert Single push button Push button DND, MUR with LED studio white - 63x63	2029 UC-84	1	piece
2CKA002495A0086	2095 UC-84 Socket insert Equipotential compensation Socket outlet 2-position studio white - 63x63	2095 UC-84	1	piece
2CKA002190A0215	2190 EUC-84 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard studio white - 63x63	2190 EUC-84	1	piece
2CKA002013A5474	23 EUCB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	23 EUCB-81	1	piece
2CKA002013A5477	23 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white - 63x63	23 EUCB-84	1	piece
2CKA002013A5479	23 EUCB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	23 EUCB-884	1	piece
2CKA002013A5451	2300 EUCB-84 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white - 63x63	2300 EUCB-84	1	piece
2CKA002011A3833	2310 EUGL/VA-84-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) studio white - 63x63	2310 EUGL/VA -84-11	1	piece
2CKA002099A0214	2399 UCKS-84 Socket insert Earthing Pin Safety Shutter Earthing pin studio white - 63x63	2399 UCKS-84	1	piece
2CKA001719A0220	2518-WD-84 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white - 63x63	2518-WD-84	1	piece

2CKA001751A3180	2520 KI-84-500 Cover Plates (partly incl. Insert) for Switch/push button Single rocker studio white - 2520 KI-84-500 63x63		1	piece
2CKA001751A3199	2520 TR-84 Rocker Switch/push button Single rocker studio white - 63x63	2520 TR-84	1	piece
2CKA001724A4256	2533-84 Cover Plate Bore hole 1 gang studio white - 63x63	2533-84	1	piece
2CKA001710A3646	2542 DR/01-84 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" studio white - 2542 DR/01-84 63x63		1	piece
2CKA001710A3651	2542 DR/02-84 Cover plate with legend Level switch Turn button Symbol "1-2-3" studio white - 2542 DR/02-84 63x63		1	piece
2CKA001724A4402	2553-84 Cover Plate XLR 1 gang studio white - 63x63	2553-84	1	piece
2CKA001753A0394	2561-02-84 Cover Plate Modular Jack 2 gang studio white - 63x63	2561-02-84	1	piece
2CKA001753A0395	2561-02-866 Cover Plate Modular Jack 2 gang stainless steel - Pure Stainless Steel	2561-02-866	1	piece
2CKA001753A0403	2561-84 Cover Plate Modular Jack 1 gang studio white - 63x63	2561-84	1	piece
2CKA003116A0662	3120 EUCB-84 Socket insert FI-Schukomat Protective Contact (SCHUKO) 30 mA studio white - 3120 EUCB-84 - 63x63		1	piece
2CKA003117A0006	3151 UC-84 RCD - Insert Buschmat RCD 30 mA studio white - 63x63	3151 UC-84	1	piece
2CKA006115A0486	6108/61-84-500 Coverplate f. CE	6108/61-84- 500	1	piece
2CKA006155A0063	6109/03-84-500 Coverplate f. RTC	6109/03-84- 500	1	piece
2CKA006132A0379	6122/10-84-500 BW standard	6122/10-84- 500	1	piece
2CKA006115A0183	6125/01-84-500 Control element 1g w. BAU	6125/01-84- 500	1	piece
2CKA006115A0219	6125/02-84-500 Control element 1/2gang	6125/02-84- 500	1	piece
2CKA006116A0174	6126/01-84-500 Control element 2g w. BAU	6126/01-84- 500	1	piece
2CKA006116A0209	6126/02-84-500 Control element 2/4gang	6126/02-84- 500	1	piece
2CKA006117A0200	6127/01-84-500 Control element 4g w. BAU	6127/01-84- 500	1	piece
2CKA006117A0235	6127/02-84-500 Control element 4/8gang	6127/02-84- 500	1	piece
2CKA006134A0334	6128/28-84-500 RTC Control element 2/4g	6128/28-84- 500	1	piece
2CKA006135A0146	6129/01-84-500 Control element 3/6g w. IR	6129/01-84- 500	1	piece
2CKA006430A0400	6430-84-102-500 Cover Plates (partly incl. Insert) for Venetian blind studio white - 63x63	6430-84-102- 500	1	piece
2CKA006430A0306	6435-84 Cover plate with legend for Time switch studio white - 63x63	6435-84	1	piece
2CKA006400A0059	6477-84 Cover Plate PowerDock 1 gang studio white - 63x63	6477-84	1	piece
2CKA006599A3009	6540-84-102-500 Cover Plates (partly incl. Insert) for Dimmer studio white - 63x63	6540-84-102- 500	1	piece
2CKA006599A2835	6541-84 Cover Plate for Cooling Central cover plate studio white - 63x63	6541-84	1	piece
2CKA006599A3010	6543-84-101-500 Cover Plates (partly incl. Insert) for Switch/dimmer Single push button studio white - 63x63	6543-84-101- 500	1	piece
2CKA006599A2908	6545-84 Control Element for Dimmer Two-part button with Neon lamp studio white - 63x63	6545-84	1	piece
2CKA006730A0136	6736 FoH-84 Control Element for Switch/dimmer Two-part button studio white - 63x63	6736 FoH-84	1	piece
2CKA006800A2834	6815-84-101-500 Cover Plates (partly incl. Insert) studio white - 63x63	6815-84-101- 500	1	piece
2CKA008200A0081	8253-84 Cover Plate Loudspeaker studio white - 63x63	8253-84	1	piece
2CKA006220A0244	CP-FCC-84 C-plate Fan Coil	CP-FCC-84	1	piece

2CKA006220A0181	CP-RTC-84 C-plate RT sensor unit	CP-RTC-84	1	piece
2CKA006220A0214	MD-F-1.0.1-84 Movement detector	MD-F-1.0.1-84	1	piece
2CKA006220A0217	MSA-F-1.1.1-84 Mov. detector/actuator 1g	MSA-F-1.1.1-84	1	piece
2CKA006220A0086	MSA-F-1.1.1-84-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-84-WL	1	piece
2CKA006220A0139	SR-1-84 Solo free@home studio white - 63x63	SR-1-84	1	piece
2CKA006220A0154	SR-2-84 Solo free@home studio white - 63x63	SR-2-84	1	piece
2CKA006220A0145	SRB-1-84 Solo free@home studio white - 63x63	SRB-1-84	1	piece
2CKA006220A0160	SRB-2-84 Solo free@home studio white - 63x63	SRB-2-84	1	piece
2CKA006220A0151	SRD-1-84 Solo free@home studio white - 63x63	SRD-1-84	1	piece
2CKA006220A0166	SRD-2-L-84 Solo free@home studio white - 63x63	SRD-2-L-84	1	piece
2CKA006220A0260	SRD-2-R-84 Solo free@home studio white - 63x63	SRD-2-R-84	1	piece
2CKA006220A0142	SRL-1-84 Solo free@home studio white - 63x63	SRL-1-84	1	piece
2CKA006220A0157	SRL-2-L-84 Solo free@home studio white - 63x63	SRL-2-L-84	1	piece
2CKA006220A0169	SRL-2-R-84 Solo free@home studio white - 63x63	SRL-2-R-84	1	piece
2CKA006220A0148	SRS-1-84 Solo free@home studio white - 63x63	SRS-1-84	1	piece
2CKA006220A0163	SRS-2-L-84 Solo free@home studio white - 63x63	SRS-2-L-84	1	piece
2CKA006220A0175	SRS-2-R-84 Solo free@home studio white - 63x63	SRS-2-R-84	1	piece
2CKA001731A1930	1716-21 Cover Busch-Infolicht® bronze - alpha	1716-21	1	piece
2CKA001731A1931	1716-22 Cover Busch-Infolicht® ivory - alpha	1716-22	1	piece
2CKA001731A1933	1716-24G Cover Busch-Infolicht® studio white - alpha	1716-24G	1	piece
2CKA001731A1938	1716-260 Cover Busch-Infolicht® palladium - alpha	1716-260	1	piece
2CKA001731A1939	1716-266 Cover Busch-Infolicht® titanium - alpha	1716-266	1	piece
2CKA001731A1976	1716-803 Cover Busch-Infolicht® grey metallic - 63x63	1716-803	1	piece
2CKA001731A1921	1716-81 Cover Busch-Infolicht® anthracite - 63x63	1716-81	1	piece
2CKA001731A1922	1716-82 Cover Busch-Infolicht® ivory white - 63x63	1716-82	1	piece
2CKA001731A1950	1716-83 Cover Busch-Infolicht® aluminium silver - 63x63	1716-83	1	piece
2CKA001731A2025	1716-840-500 Cover Plates (partly incl. Insert) LED antique brass - 63x63	1716-840-500	1	piece
2CKA001731A1955	1716-866 Cover Busch-Infolicht® stainless steel - Pure Stainless Steel	1716-866	1	piece
2CKA001731A1978	1716-884 Cover Busch-Infolicht® studio white matt - 63x63	1716-884	1	piece
2CKA001731A1914	1720-81 Rocker Switch Pull cord anthracite - 63x63	1720-81	1	piece
2CKA001731A1915	1720-82 Rocker Switch Pull cord ivory white - 63x63	1720-82	1	piece
2CKA001731A1949	1720-83 Rocker Switch Pull cord aluminium silver - 63x63	1720-83	1	piece
2CKA001731A1954	1720-866 Rocker Switch Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001731A1979	1720-884 Rocker Switch Pull cord studio white matt - 63x63	1720-884	1	piece
2CKA001754A4822	1723-815 Cover Frame 3gang(s) porcelain anthracite - carat	1723-815	1	piece
2CKA001710A4119	1740 DR/03-803 Cover plate with legend Level switch Turn button grey metallic - 63x63	1740 DR/03-803	1	piece
2CKA001710A4120	1740 DR/03-81 Cover plate with legend Level switch Turn button anthracite - 63x63	1740 DR/03-81	1	piece
2CKA001710A3807	1740 DR/03-82 Cover plate with legend Level switch Turn button ivory white - 63x63	1740 DR/03-82	1	piece
2CKA001710A3811	1740 DR/03-83 Cover plate with legend Level switch Turn button aluminium silver - 63x63	1740 DR/03-83	1	piece
2CKA001710A3812	1740 DR/03-866 Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	piece

2CKA001710A3870	1740 DR/03-884 Cover plate with legend Level switch Turn button studio white matt - 63x63	1740 DR/03-884	1	piece
2CKA001753A1092	1740 DR-20 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" platinum - alpha	1740 DR-20	1	piece
2CKA001753A1175	1740 DR-21 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" bronze - alpha	1740 DR-21	1	piece
2CKA001710A2330	1740 DR-22G Cover Plate Venetian blind Turn button Symbol "arrows" and "0" ivory - alpha	1740 DR-22G	1	piece
2CKA001753A7263	1740 DR-24G Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" studio white - alpha	1740 DR-24G	1	piece
2CKA001710A3302	1740 DR-260 Cover Plate Venetian blind Turn button Symbol "arrows" and "0" palladium - alpha	1740 DR-260	1	piece
2CKA001710A3328	1740 DR-266 Cover plate with legend Venetian blind Turn button Symbol "arrows" and "0" titanium - alpha	1740 DR-266	1	piece
2CKA001753A8279	1740 DRL-20 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" platinum	1740 DRL-20	1	piece
2CKA001753A8287	1740 DRL-21 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" bronze - alpha	1740 DRL-21	1	piece
2CKA001710A3032	1740 DRL-22G Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" ivory - alpha	1740 DRL-22G	1	piece
2CKA001753A8246	1740 DRL-24G Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" studio white - alpha	1740 DRL-24G	1	piece
2CKA001710A3457	1740 DRL-260-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" palladium - alpha	1740 DRL-260-503	1	piece
2CKA001710A3459	1740 DRL-266-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" titanium - alpha	1740 DRL-266-503	1	piece
2CKA001710A4121	1740 DRL-803-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" grey metallic - 63x63	1740 DRL-803-503	1	piece
2CKA001710A4122	1740 DRL-81-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" anthracite - 63x63	1740 DRL-81-503	1	piece
2CKA001710A3511	1740 DRL-82-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" ivory white - 63x63	1740 DRL-82-503	1	piece
2CKA001710A4123	1740 DRL-83-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" aluminium silver - 63x63	1740 DRL-83-503	1	piece
2CKA001710A3771	1740 DRL-866-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	piece
2CKA001710A3871	1740 DRL-884-503 Cover Plates (partly incl. Insert) Level switch Turn button Symbol "2-1-3" studio white matt - 63x63	1740 DRL-884-503	1	piece
2CKA001710A3840	1740-803 Cover plate with legend Venetian blind Turn button Symbol "arrows" grey metallic - 63x63	1740-803	1	piece
2CKA001710A3623	1740-81 Cover plate with legend Venetian blind Turn button Symbol "arrows" anthracite - 63x63	1740-81	1	piece
2CKA001710A3154	1740-82 Cover plate with legend Venetian blind Turn button Symbol "arrows" ivory white - 63x63	1740-82	1	piece
2CKA001710A3661	1740-83 Cover plate with legend Venetian blind Turn button Symbol "arrows" aluminium silver - 63x63	1740-83	1	piece
2CKA001710A4089	1740-840-500 Cover Plates (partly incl. Insert) Venetian blind Turn button Symbol "arrows" antique brass - 63x63	1740-840-500	1	piece
2CKA001710A3748	1740-866 Cover plate with legend Venetian blind Turn button Symbol "arrows" stainless steel - Pure Stainless Steel	1740-866	1	piece
2CKA001710A3872	1740-884 Cover plate with legend Venetian blind Turn button Symbol "arrows" studio white matt - 63x63	1740-884	1	piece
2CKA001753A1118	1742-20 Cover Plate Blind cap 1 gang with Mounting plate platinum - alpha	1742-20	1	piece

2CKA001753A1431	1742-21 Cover Plate Blind cap 1 gang with Mounting plate bronze - alpha	1742-21	1	piece
2CKA001710A2389	1742-22G Cover Plate Blind cap 0 gang with Mounting plate ivory - alpha	1742-22G	1	piece
2CKA001753A7412	1742-24G Cover Plate Blind cap 1 gang with Mounting plate studio white - alpha	1742-24G	1	piece
2CKA001710A3309	1742-260 Cover Plate Blind cap 1 gang with Mounting plate palladium - alpha	1742-260	1	piece
2CKA001710A3335	1742-266 Cover Plate Blind cap 1 gang with Mounting plate titanium - alpha	1742-266	1	piece
2CKA001710A3843	1742-803 Cover Plate Blind cap 1 gang with Mounting plate grey metallic - 63x63	1742-803	1	piece
2CKA001710A3612	1742-81 Cover Plate Blind cap 1 gang with Mounting plate anthracite - 63x63	1742-81	1	piece
2CKA001710A3143	1742-82 Cover Plate Blind cap 1 gang with Mounting plate ivory white - 63x63	1742-82	1	piece
2CKA001710A3664	1742-83 Cover Plate Blind cap 1 gang with Mounting plate aluminium silver - 63x63	1742-83	1	piece
2CKA001710A4080	1742-840-500 Cover Plates (partly incl. Insert) Blind cap 0 gang antique brass - 63x63	1742-840-500	1	piece
2CKA001710A3751	1742-866 Cover Plate Blind cap 1 gang with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	piece
2CKA001710A3873	1742-884 Cover Plate Blind cap 1 gang with Mounting plate studio white matt - 63x63	1742-884	1	piece
2CKA001724A4364	1743/10-04-803 Cover Plate SAT 4 gang grey metallic - 63x63	1743/10-04-803	1	piece
2CKA001724A4365	1743/10-04-81 Cover Plate SAT 4 gang anthracite - 63x63	1743/10-04-81	1	piece
2CKA001724A4366	1743/10-04-82 Cover Plate SAT 4 gang ivory white - 63x63	1743/10-04-82	1	piece
2CKA001724A4367	1743/10-04-83 Cover Plate SAT 4 gang aluminium silver - 63x63	1743/10-04-83	1	piece
2CKA001724A4369	1743/10-04-866 Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743/10-04-866	1	piece
2CKA001724A4370	1743/10-04-884 Cover Plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63	1743/10-04-884	1	piece
2CKA001724A4373	1743-04-803 Cover Plate TV / Radio / 2x SAT 4 gang grey metallic - 63x63	1743-04-803	1	piece
2CKA001724A4374	1743-04-81 Cover Plate SAT 4 gang anthracite - 63x63	1743-04-81	1	piece
2CKA001724A4375	1743-04-82 Cover Plate TV / Radio / 2x SAT 4 gang ivory white - 63x63	1743-04-82	1	piece
2CKA001724A4376	1743-04-83 Cover Plate SAT 4 gang aluminium silver - 63x63	1743-04-83	1	piece
2CKA001724A4378	1743-04-866 Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743-04-866	1	piece
2CKA001724A4379	1743-04-884 Cover Plate TV / Radio / 2x SAT 4 gang studio white matt - 63x63	1743-04-884	1	piece
2CKA001724A4380	1743-04-885 Cover Plate SAT 4 gang black matt - 63x63	1743-04-885	1	piece
2CKA001753A1126	1743-20 Cover Plate SAT 2 gang platinum - alpha	1743-20	1	piece
2CKA001753A1449	1743-21 Cover Plate SAT 2 gang bronze - alpha	1743-21	1	piece
2CKA001710A2454	1743-22G Cover Plate SAT 2 gang ivory - alpha	1743-22G	1	piece
2CKA001753A7628	1743-24G Cover Plate SAT 2 gang studio white - alpha	1743-24G	1	piece
2CKA001724A2791	1743-260 Cover Plate SAT 2 gang palladium - alpha	1743-260	1	piece
2CKA001724A2796	1743-266 Cover Plate SAT 2 gang titanium - alpha	1743-266	1	piece
2CKA001724A4291	1743-803 Cover Plate SAT 3 gang grey metallic - 63x63	1743-803	1	piece
2CKA001724A4252	1743-81 Cover Plate SAT 3 gang anthracite - 63x63	1743-81	1	piece
2CKA001724A2758	1743-82 Cover Plate SAT 3 gang ivory white - 63x63	1743-82	1	piece
2CKA001724A4262	1743-83 Cover Plate SAT 3 gang aluminium silver - 63x63	1743-83	1	piece
2CKA001724A4362	1743-840-500 Cover Plate SAT 3 gang antique brass - 63x63	1743-840-500	1	piece

2CKA001724A4271	1743-866 Cover Plate SAT 3 gang stainless steel - Pure Stainless Steel	1743-866	1	piece
2CKA001724A4293	1743-884 Cover Plate SAT 3 gang studio white matt - 63x63	1743-884	1	piece
2CKA001710A3855	1745-803 Cover Plate telephone connector boxes (VDo) grey metallic - 63x63	1745-803	1	piece
2CKA001710A3624	1745-81 Cover Plate telephone connector boxes (VDo) anthracite - 63x63	1745-81	1	piece
2CKA001710A3155	1745-82 Cover Plate telephone connector boxes (VDo) ivory white - 63x63	1745-82	1	piece
2CKA001710A3675	1745-83 Cover Plate telephone connector boxes (VDo) aluminium silver - 63x63	1745-83	1	piece
2CKA001710A3766	1745-866 Cover Plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel	1745-866	1	piece
2CKA001710A3874	1745-884 Cover Plate telephone connector boxes (VDo) studio white matt - 63x63	1745-884	1	piece
2CKA001753A8550	1746/10-20 Cover Plate Telecommunication inserts 50 x 50 mm platinum - alpha	1746/10-20	1	piece
2CKA001753A8568	1746/10-21 Cover Plate Telecommunication inserts 50 x 50 mm bronze - alpha	1746/10-21	1	piece
2CKA001710A2652	1746/10-22G Cover Plate Telecommunication inserts 50 x 50 mm ivory - alpha	1746/10-22G	1	piece
2CKA001710A2744	1746/10-24G Cover Plate Telecommunication inserts 50 x 50 mm studio white - alpha	1746/10-24G	1	piece
2CKA001710A3312	1746/10-260 Cover Plate Telecommunication inserts 50 x 50 mm palladium - alpha	1746/10-260	1	piece
2CKA001710A3338	1746/10-266 Cover Plate Telecommunication inserts 50 x 50 mm titanium - alpha	1746/10-266	1	piece
2CKA001710A3857	1746/10-803 Cover Plate Telecommunication inserts 50 x 50 mm grey metallic - 63x63	1746/10-803	1	piece
2CKA001710A3628	1746/10-81 Cover Plate Telecommunication inserts 50 x 50 mm anthracite - 63x63	1746/10-81	1	piece
2CKA001710A3521	1746/10-82 Cover Plate Telecommunication inserts 50 x 50 mm ivory white - 63x63	1746/10-82	1	piece
2CKA001710A3677	1746/10-83 Cover Plate Telecommunication inserts 50 x 50 mm aluminium silver - 63x63	1746/10-83	1	piece
2CKA001710A3768	1746/10-866 Cover Plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746/10-866	1	piece
2CKA001710A3875	1746/10-884 Cover Plate Telecommunication inserts 50 x 50 mm studio white matt - 63x63	1746/10-884	1	piece
2CKA001753A1753	1746-20 FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid platinum - alpha	1746-20 FN	1	piece
2CKA001753A5978	1746-20-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid platinum - alpha	1746-20-101	1	piece
2CKA001753A1761	1746-21 FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid bronze - alpha	1746-21 FN	1	piece
2CKA001753A5986	1746-21-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid bronze - alpha	1746-21-101	1	piece
2CKA001710A2488	1746-22G FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid ivory - alpha	1746-22G FN	1	piece
2CKA001710A2470	1746-22G-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid ivory - alpha	1746-22G-101	1	piece
2CKA001753A7719	1746-24G FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid studio white - alpha	1746-24G FN	1	piece
2CKA001753A7685	1746-24G-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid studio white - alpha	1746-24G-101	1	piece
2CKA001710A3311	1746-260 FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid palladium - alpha	1746-260 FN	1	piece
2CKA001710A3313	1746-260-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid palladium - alpha	1746-260-101	1	piece
2CKA001710A3337	1746-266 FN Cover Plate Telecommunication inserts 1 gang with Hinged Lid titanium - alpha	1746-266 FN	1	piece

2CKA001710A3339	1746-266-101 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid titanium - alpha	1746-266-101	1	piece
2CKA001710A3858	1746-803 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid grey metallic - 63x63	1746-803	1	piece
2CKA001710A3618	1746-81 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid anthracite - 63x63	1746-81	1	piece
2CKA001710A3149	1746-82 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid ivory white - 63x63	1746-82	1	piece
2CKA001710A3678	1746-83 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid aluminium silver - 63x63	1746-83	1	piece
2CKA001710A4086	1746-840-500 Accessories 0 gang antique brass - 63x63	1746-840-500	1	piece
2CKA001710A3769	1746-866 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid stainless steel - Pure Stainless Steel	1746-866	1	piece
2CKA001710A3876	1746-884 Cover Plate Telecommunication inserts 50 x 50 mm 1 gang with Hinged Lid studio white matt - 63x63	1746-884	1	piece
2CKA001710A4092	1747 BSI-803 Intermediate Ring For cover plates Busch-Balance® SI grey metallic - 63x63	1747 BSI-803	1	piece
2CKA001710A4093	1747 BSI-81 Intermediate Ring For cover plates Busch-Balance® SI anthracite - 63x63	1747 BSI-81	1	piece
2CKA001710A4094	1747 BSI-82 Intermediate Ring For cover plates Busch-Balance® SI ivory white - 63x63	1747 BSI-82	1	piece
2CKA001710A4095	1747 BSI-83 Intermediate Ring For cover plates Busch-Balance® SI aluminium silver - 63x63	1747 BSI-83	1	piece
2CKA001710A4097	1747 BSI-866 Intermediate Ring For cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	piece
2CKA001710A4098	1747 BSI-884 Intermediate Ring For cover plates Busch-Balance® SI studio white matt - 63x63	1747 BSI-884	1	piece
2CKA001710A3862	1747 SI-82 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747 SI-82	1	piece
2CKA001710A4079	1747 SI-840-500 Cover Plates (partly incl. Insert) antique brass - 63x63	1747 SI-840-500	1	piece
2CKA001710A3860	1747-82 Intermediate Ring Cover plates Busch-Duro 2000® SI and Reflex SI ivory white - 63x63	1747-82	1	piece
2CKA001753A1167	1748-20 Cover Plate Data connection 2 gang platinum - alpha	1748-20	1	piece
2CKA001753A1480	1748-21 Cover Plate Data connection 2 gang bronze - alpha	1748-21	1	piece
2CKA001710A2546	1748-22G Cover Plate Data connection 2 gang ivory - alpha	1748-22G	1	piece
2CKA001753A7891	1748-24G Cover Plate Data connection 2 gang studio white - alpha	1748-24G	1	piece
2CKA001710A3323	1748-260 Cover Plate Data connection 2 gang palladium - alpha	1748-260	1	piece
2CKA001710A3349	1748-266 Cover Plate Data connection 2 gang titanium - alpha	1748-266	1	piece
2CKA001710A3851	1748-803 Cover Plate Data connection 2 gang grey metallic - 63x63	1748-803	1	piece
2CKA001710A3654	1748-81 Cover Plate Data connection 2 gang anthracite - 63x63	1748-81	1	piece
2CKA001710A3655	1748-82 Cover Plate Data connection 2 gang ivory white - 63x63	1748-82	1	piece
2CKA001710A3673	1748-83 Cover Plate Data connection 2 gang aluminium silver - 63x63	1748-83	1	piece
2CKA001710A3760	1748-866 Cover Plate Data connection 2 gang stainless steel - Pure Stainless Steel	1748-866	1	piece
2CKA001710A3877	1748-884 Cover Plate Data connection 2 gang studio white matt - 63x63	1748-884	1	piece
2CKA001710A0904	1749-20 Cover Plate Cable outlet platinum - alpha	1749-20	1	piece
2CKA001710A0946	1749-21 Cover Plate Cable outlet bronze - alpha	1749-21	1	piece
2CKA001710A2561	1749-22G Cover Plate Cable outlet ivory - alpha	1749-22G	1	piece
2CKA001710A1209	1749-24G Cover Plate Cable outlet studio white - alpha	1749-24G	1	piece

2CKA001710A3316	1749-260 Cover Plate Cable outlet palladium - alpha	1749-260	1	piece
2CKA001710A3342	1749-266 Cover Plate Cable outlet titanium - alpha	1749-266	1	piece
2CKA001710A3844	1749-803 Cover Plate Cable outlet grey metallic - 63x63	1749-803	1	piece
2CKA001710A3614	1749-81 Cover Plate Cable outlet anthracite - 63x63	1749-81	1	piece
2CKA001710A3145	1749-82 Cover Plate Cable outlet ivory white - 63x63	1749-82	1	piece
2CKA001710A3665	1749-83 Cover Plate Cable outlet aluminium silver - 63x63	1749-83	1	piece
2CKA001710A4081	1749-840-500 Cover Plates (partly incl. Insert) Cable outlet 0 gang antique brass - 63x63	1749-840-500	1	piece
2CKA001710A3752	1749-866 Cover Plate Cable outlet stainless steel - Pure Stainless Steel	1749-866	1	piece
2CKA001710A3878	1749-884 Cover Plate Cable outlet studio white matt - 63x63	1749-884	1	piece
2CKA001710A3859	1750-803 Cover Plate BNC/TNC 2 gang grey metallic - 63x63	1750-803	1	piece
2CKA001710A3617	1750-81 Cover Plate BNC/TNC 2 gang anthracite - 63x63	1750-81	1	piece
2CKA001710A3148	1750-82 Cover Plate BNC/TNC 2 gang ivory white - 63x63	1750-82	1	piece
2CKA001710A3679	1750-83 Cover Plate BNC/TNC 2 gang aluminium silver - 63x63	1750-83	1	piece
2CKA001710A3770	1750-866 Cover Plate BNC/TNC 2 gang stainless steel - Pure Stainless Steel	1750-866	1	piece
2CKA001710A3879	1750-884 Cover Plate BNC/TNC 2 gang studio white matt - 63x63	1750-884	1	piece
2CKA001723A0113	1751-20 Cover Plate Loudspeaker 2 gang platinum - alpha	1751-20	1	piece
2CKA001723A0121	1751-21 Cover Plate Loudspeaker 2 gang bronze - alpha	1751-21	1	piece
2CKA001723A0238	1751-22G Cover Plate Loudspeaker 2 gang ivory - alpha	1751-22G	1	piece
2CKA001723A0204	1751-24G Cover Plate Loudspeaker 2 gang studio white - alpha	1751-24G	1	piece
2CKA001723A0245	1751-260 Cover Plate Loudspeaker 2 gang palladium - alpha	1751-260	1	piece
2CKA001723A0246	1751-266 Cover Plate Loudspeaker 2 gang titanium - alpha	1751-266	1	piece
2CKA001723A0257	1751-803 Cover Plate Loudspeaker 2 gang grey metallic - 63x63	1751-803	1	piece
2CKA001723A0253	1751-81 Cover Plate Loudspeaker 2 gang anthracite - 63x63	1751-81	1	piece
2CKA001723A0239	1751-82 Cover Plate Loudspeaker 2 gang ivory white - 63x63	1751-82	1	piece
2CKA001723A0254	1751-83 Cover Plate Loudspeaker 2 gang aluminium silver - 63x63	1751-83	1	piece
2CKA001723A0255	1751-866 Cover Plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel	1751-866	1	piece
2CKA001723A0260	1751-884 Cover Plate Loudspeaker 2 gang studio white matt - 63x63	1751-884	1	piece
2CKA001710A3841	1755 SL/PZ-803-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" grey metallic - 63x63	1755 SL/PZ-803-101	1	piece
2CKA001710A3626	1755 SL/PZ-81-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" anthracite - 63x63	1755 SL/PZ-81-101	1	piece
2CKA001710A3157	1755 SL/PZ-82-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" ivory white - 63x63	1755 SL/PZ-82-101	1	piece
2CKA001710A3662	1755 SL/PZ-83-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" aluminium silver - 63x63	1755 SL/PZ-83-101	1	piece
2CKA001710A3749	1755 SL/PZ-866-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	piece

2CKA001710A3925	1755 SL/PZ-884-101 Cover plate with legend Venetian blind Key Symbol "arrows" or "0 - 1" studio white matt - 63x63	1755 SL/PZ-884-101	1	piece
2CKA001753A1506	1756-20 Cover Plate Busch-Infolicht® platinum - alpha	1756-20	1	piece
2CKA001753A1522	1756-21 Cover Plate Busch-Infolicht® bronze - alpha	1756-21	1	piece
2CKA001710A2413	1756-22G Cover Plate Busch-Infolicht® ivory - alpha	1756-22G	1	piece
2CKA001753A7503	1756-24G Cover Plate Busch-Infolicht® studio white - alpha	1756-24G	1	piece
2CKA001710A3306	1756-260 Cover Plate Busch-Infolicht® palladium - alpha	1756-260	1	piece
2CKA001710A3332	1756-266 Cover Plate Busch-Infolicht® titanium - alpha	1756-266	1	piece
2CKA001753A0088	1756-803 Cover Plate Busch-Infolicht® grey metallic - 63x63	1756-803	1	piece
2CKA001753A0089	1756-81 Cover Plate Busch-Infolicht® anthracite - 63x63	1756-81	1	piece
2CKA001753A0091	1756-83 Cover Plate Busch-Infolicht® aluminium silver - 63x63	1756-83	1	piece
2CKA001753A0093	1756-866 Cover Plate Busch-Infolicht® stainless steel - Pure Stainless Steel	1756-866	1	piece
2CKA001753A0251	1756-884 Cover Plate Busch-Infolicht® studio white matt - 63x63	1756-884	1	piece
2CKA001724A1010	1758-20 Cover plate with labelling field For data connection housing 2 gang platinum - alpha	1758-20	1	piece
2CKA001724A1028	1758-21 Cover plate with labelling field For data connection housing 2 gang bronze - alpha	1758-21	1	piece
2CKA001724A2513	1758-22G Cover plate with labelling field For data connection housing 2 gang ivory - alpha	1758-22G	1	piece
2CKA001724A2067	1758-24G Cover plate with labelling field For data connection housing 2 gang studio white - alpha	1758-24G	1	piece
2CKA001724A2793	1758-260 Cover Plate For data connection housing 2 gang palladium	1758-260	1	piece
2CKA001724A2798	1758-266 Cover plate with labelling field For data connection housing 2 gang titanium - alpha	1758-266	1	piece
2CKA001724A4292	1758-803 Cover plate with labelling field For data connection housing 2 gang grey metallic - 63x63	1758-803	1	piece
2CKA001724A4253	1758-81 Cover plate with labelling field For data connection housing 2 gang anthracite - 63x63	1758-81	1	piece
2CKA001724A2759	1758-82 Cover plate with labelling field For data connection housing 2 gang ivory white - 63x63	1758-82	1	piece
2CKA001724A4263	1758-83 Cover plate with labelling field For data connection housing 2 gang aluminium silver - 63x63	1758-83	1	piece
2CKA001724A4272	1758-866 Cover plate with labelling field For data connection housing 2 gang stainless steel - Pure Stainless Steel	1758-866	1	piece
2CKA001724A4307	1758-884 Cover plate with labelling field For data connection housing 2 gang studio white matt - 63x63	1758-884	1	piece
2CKA001731A3997	1764 NLI/KI-803 Rocker with labelling field Switch/push button Single push button Symbol "bell" grey metallic - 63x63	1764 NLI/KI-803	1	piece
2CKA001731A3998	1764 NLI/KI-81 Rocker with labelling field Switch/push button Single push button Symbol "bell" anthracite - 63x63	1764 NLI/KI-81	1	piece
2CKA001731A3999	1764 NLI/KI-82 Rocker with labelling field Switch/push button Single push button Symbol "bell" ivory white - 63x63	1764 NLI/KI-82	1	piece
2CKA001731A4000	1764 NLI/KI-83 Rocker with labelling field Switch/push button Single push button Symbol "bell" aluminium silver - 63x63	1764 NLI/KI-83	1	piece
2CKA001731A4003	1764 NLI/KI-866 Rocker with labelling field Switch/push button Single push button Symbol "bell" stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	piece
2CKA001731A4004	1764 NLI/KI-884 Rocker with labelling field Switch/push button Single push button Symbol "bell" studio white matt - 63x63	1764 NLI/KI-884	1	piece

2CKA001731A4011	1764 NLI-12-82-101 Rocker with labelling field Switch/push button Single push button red - 63x63	1764 NLI-12- 82-101	1	piece
2CKA001731A4007	1764 NLI-13-82 Rocker with labelling field Switch/push button Single push button green - 63x63	1764 NLI-13- 82	1	piece
2CKA001731A1858	1764 NLI-22G Rocker with labelling field Switch/push button Single rocker ivory - alpha	1764 NLI-22G	1	piece
2CKA001731A1569	1764 NLI-24G Rocker with labelling field Switch/push button Single rocker studio white - alpha	1764 NLI-24G	1	piece
2CKA001731A1975	1764 NLI-803 Rocker with labelling field Switch/push button Single rocker grey metallic - 63x63	1764 NLI-803	1	piece
2CKA001731A1552	1764 NLI-81 Rocker with labelling field Switch/push button Single push button anthracite - 63x63	1764 NLI-81	1	piece
2CKA001731A1876	1764 NLI-82 Rocker with labelling field Switch/push button Single push button ivory white - 63x63	1764 NLI-82	1	piece
2CKA001731A1948	1764 NLI-83 Rocker with labelling field Switch/push button Single push button aluminium silver - 63x63	1764 NLI-83	1	piece
2CKA001731A2024	1764 NLI-840-500 Rocker Switch/push button Single rocker Without imprint antique brass - 63x63	1764 NLI-840- 500	1	piece
2CKA001731A1953	1764 NLI-866 Rocker with labelling field Switch/push button Single push button stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001731A1985	1764 NLI-884 Rocker with labelling field Switch/push button Single push button studio white matt - 63x63	1764 NLI-884	1	piece
2CKA001753A2629	1766-20 Cover Plate TAE 1 gang platinum - alpha	1766-20	1	piece
2CKA001753A2637	1766-21 Cover Plate TAE 1 gang bronze - alpha	1766-21	1	piece
2CKA001710A2496	1766-22G Cover Plate TAE 1 gang ivory - alpha	1766-22G	1	piece
2CKA001753A7743	1766-24G Cover Plate TAE 1 gang studio white - alpha	1766-24G	1	piece
2CKA001710A3310	1766-260 Cover Plate TAE 1 gang palladium - alpha	1766-260	1	piece
2CKA001710A3336	1766-266 Cover Plate TAE 1 gang titanium - alpha	1766-266	1	piece
2CKA001710A3854	1766-803 Cover Plate TAE 1 gang grey metallic - 63x63	1766-803	1	piece
2CKA001710A3613	1766-81 Cover Plate TAE 1 gang anthracite - 63x63	1766-81	1	piece
2CKA001710A3144	1766-82 Cover Plate TAE 1 gang ivory white - 63x63	1766-82	1	piece
2CKA001710A3659	1766-83 Cover Plate TAE 1 gang aluminium silver - 63x63	1766-83	1	piece
2CKA001710A4084	1766-840-500 Cover Plate TAE 0 gang brass - 63x63	1766-840-500	1	piece
2CKA001710A3765	1766-866 Cover Plate TAE 1 gang stainless steel - Pure Stainless Steel	1766-866	1	piece
2CKA001710A3926	1766-884 Cover Plate TAE 1 gang studio white matt - 63x63	1766-884	1	piece
2CKA001753A6075	1770-20-101 Cover plate with legend Time switch Turn button 1 ... 15 Min platinum - alpha	1770-20-101	1	piece
2CKA001753A6083	1770-21-101 Cover plate with legend Time switch Turn button 1 ... 15 Min bronze - alpha	1770-21-101	1	piece
2CKA001710A2397	1770-22G-101 Cover Plate Time switch Turn button Various symbols ivory - alpha	1770-22G-101	1	piece
2CKA001753A7446	1770-24G-101 Cover plate with legend Time switch Turn button 1 ... 15 Min studio white - alpha	1770-24G-101	1	piece
2CKA001753A0254	1770-803-103 Cover Plate Time switch Toggle grey metallic - 63x63	1770-803-103	1	piece
2CKA001753A0255	1770-81-103 Cover Plate Time switch Toggle 1 ... 15 Min anthracite - 63x63	1770-81-103	1	piece
2CKA001753A0256	1770-82-103 Cover Plate Time switch Toggle ivory white - 63x63	1770-82-103	1	piece
2CKA001753A0257	1770-83-103 Cover Plate Time switch Toggle 1 ... 15 Min aluminium silver - 63x63	1770-83-103	1	piece

2CKA001753A0259	1770-866-103 Cover Plate Time switch Toggle 1 ... 15 Min stainless steel - Pure Stainless Steel	1770-866-103	1	piece
2CKA001753A0260	1770-884-103 Cover Plate Time switch Toggle 1 ... 15 Min studio white matt - 63x63	1770-884-103	1	piece
2CKA001753A6224	1771-20-101 Cover plate with legend Time switch Turn button 10 ... 120 Min platinum - alpha	1771-20-101	1	piece
2CKA001753A6232	1771-21-101 Cover plate with legend Time switch Turn button 10 ... 120 Min bronze - alpha	1771-21-101	1	piece
2CKA001710A2405	1771-22G-101 Cover plate with legend Time switch Turn button 10 ... 120 Min ivory - alpha	1771-22G-101	1	piece
2CKA001753A7479	1771-24G-101 Cover plate with legend Time switch Turn button 10 ... 120 Min studio white - alpha	1771-24G-101	1	piece
2CKA001753A0264	1771-803-103 Cover Plate Time switch Toggle 10 ... 120 Min grey metallic - 63x63	1771-803-103	1	piece
2CKA001753A0265	1771-81-103 Cover Plate Time switch Toggle 10 ... 120 Min anthracite - 63x63	1771-81-103	1	piece
2CKA001753A0266	1771-82-103 Cover Plate Time switch Toggle 10 ... 120 Min ivory white - 63x63	1771-82-103	1	piece
2CKA001753A0267	1771-83-103 Cover Plate Time switch Toggle 10 ... 120 Min aluminium silver - 63x63	1771-83-103	1	piece
2CKA001753A0302	1771-866-103 Cover Plate Time switch Toggle 10 ... 120 Min stainless steel - Pure Stainless Steel	1771-866-103	1	piece
2CKA001753A0303	1771-884-103 Cover Plate Time switch Toggle 10 ... 120 Min studio white matt - 63x63	1771-884-103	1	piece
2CKA001751A3101	1785 JA/02-82 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" ivory white	1785 JA/02-82	1	piece
2CKA001751A3097	1785 JA/02-83 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" aluminium silver - 63x63	1785 JA/02-83	1	piece
2CKA001751A3103	1785 JA/02-884 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white matt - 63x63	1785 JA/02- 884	1	piece
2CKA001751A1823	1785 JA-20 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" platinum - alpha	1785 JA-20	1	piece
2CKA001751A1831	1785 JA-21 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" bronze - alpha	1785 JA-21	1	piece
2CKA001751A2581	1785 JA-22G Rocker with legend Venetian blind Two-part rocker Symbol "arrows" ivory - alpha	1785 JA-22G	1	piece
2CKA001751A2128	1785 JA-24G Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white - alpha	1785 JA-24G	1	piece
2CKA001751A2831	1785 JA-260 Rocker Venetian blind Two-part rocker palladium - alpha	1785 JA-260	1	piece
2CKA001751A2842	1785 JA-266 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" titanium - alpha	1785 JA-266	1	piece
2CKA001751A3020	1785 JA-803 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" grey metallic - 63x63	1785 JA-803	1	piece
2CKA001751A2934	1785 JA-81 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" anthracite - 63x63	1785 JA-81	1	piece
2CKA001751A2748	1785 JA-82 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" ivory white - 63x63	1785 JA-82	1	piece
2CKA001751A2944	1785 JA-83 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" aluminium silver - 63x63	1785 JA-83	1	piece
2CKA001751A3120	1785 JA-840-500 Cover Plates Venetian blind Two-part rocker Symbol "arrows" antique brass - 63x63	1785 JA-840- 500	1	piece
2CKA001751A2964	1785 JA-866 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" stainless steel - Pure Stainless Steel	1785 JA-866	1	piece
2CKA001751A3022	1785 JA-884 Rocker with legend Venetian blind Two-part rocker Symbol "arrows" studio white matt - 63x63	1785 JA-884	1	piece
2CKA001751A3138	1785 K-20 Rocker Switch/push button Two-part rocker platinum - alpha	1785 K-20	1	piece
2CKA001751A3139	1785 K-21 Rocker Switch/push button Two-part rocker bronze - alpha	1785 K-21	1	piece

2CKA001751A3140	1785 K-22G Rocker Switch/push button Two-part rocker ivory - alpha	1785 K-22G	1	piece
2CKA001751A3142	1785 K-24G Rocker Switch/push button Two-part rocker studio white - alpha	1785 K-24G	1	piece
2CKA001751A3143	1785 K-260 Rocker Switch/push button Two-part rocker palladium - alpha	1785 K-260	1	piece
2CKA001751A3144	1785 K-266 Rocker Switch/push button Two-part rocker titanium - alpha	1785 K-266	1	piece
2CKA001751A3126	1785 K-83-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker None aluminium silver - 63x63	1785 K-83-500	1	piece
2CKA001751A3204	1785/11-803 Rocker with legend Switch/push button Single rocker DND, MUR grey metallic - 63x63	1785/11-803	1	piece
2CKA001751A3205	1785/11-81 Rocker with legend Switch/push button Two-part rocker DND, MUR anthracite - 63x63	1785/11-81	1	piece
2CKA001751A2991	1785/11-82 Rocker with legend Switch/push button Two-part rocker DND, MUR ivory white - 63x63	1785/11-82	1	piece
2CKA001751A2995	1785/11-83 Rocker with legend Switch/push button Two-part rocker DND, MUR aluminium silver - 63x63	1785/11-83	1	piece
2CKA001751A3119	1785/11-840-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker antique brass - 63x63	1785/11-840-500	1	piece
2CKA001751A2996	1785/11-866 Rocker with legend Switch/push button Two-part rocker DND, MUR stainless steel - Pure Stainless Steel	1785/11-866	1	piece
2CKA001751A3023	1785/11-884 Rocker with legend Switch/push button Two-part rocker DND, MUR studio white matt - 63x63	1785/11-884	1	piece
2CKA001751A1682	1785-20 Rocker Switch/push button Two-part rocker platinum - alpha	1785-20	1	piece
2CKA001751A1773	1785-21 Rocker Switch/push button Two-part rocker bronze - alpha	1785-21	1	piece
2CKA001751A2706	1785-21-101 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint bronze	1785-21-101	1	piece
2CKA001751A2565	1785-22G Rocker Switch/push button Two-part rocker ivory - alpha	1785-22G	1	piece
2CKA001751A2110	1785-24G Rocker Switch/push button Two-part rocker studio white - alpha	1785-24G	1	piece
2CKA001751A2827	1785-260 Rocker Switch/push button Two-part rocker palladium - alpha	1785-260	1	piece
2CKA001751A3082	1785-260-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint palladium - alpha	1785-260-500	1	piece
2CKA001751A2838	1785-266 Rocker Switch/push button Two-part rocker titanium - alpha	1785-266	1	piece
2CKA001751A3018	1785-803 Rocker Switch/push button Two-part rocker grey metallic - 63x63	1785-803	1	piece
2CKA001751A2930	1785-81 Rocker Switch/push button Two-part rocker anthracite - 63x63	1785-81	1	piece
2CKA001751A2744	1785-82 Rocker Switch/push button Two-part rocker ivory white - 63x63	1785-82	1	piece
2CKA001751A2942	1785-83 Rocker Switch/push button Two-part rocker aluminium silver - 63x63	1785-83	1	piece
2CKA001751A3092	1785-83-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint aluminium silver - 63x63	1785-83-500	1	piece
2CKA001751A3117	1785-840-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint antique brass - 63x63	1785-840-500	1	piece
2CKA001751A3087	1785-866-500 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3024	1785-884 Rocker Switch/push button Two-part rocker studio white matt - 63x63	1785-884	1	piece
2CKA001751A3100	1786 JA/02-82 Rocker Venetian blind Single rocker ivory white	1786 JA/02-82	1	piece

2CKA001751A3096	1786 JA/02-83 Rocker with legend Switch/push button Symbol "arrows" aluminium silver - 63x63	1786 JA/02-83	1	piece
2CKA001751A3102	1786 JA/02-884 Rocker Venetian blind Single rocker studio white matt - 63x63	1786 JA/02-884	1	piece
2CKA001751A3207	1786/11-81 Rocker Switch/push button Single rocker DND anthracite - 63x63	1786/11-81	1	piece
2CKA001751A2997	1786/11-82 Rocker Switch/push button Single rocker DND ivory white - 63x63	1786/11-82	1	piece
2CKA001751A3001	1786/11-83 Rocker Switch/push button Single rocker DND aluminium silver - 63x63	1786/11-83	1	piece
2CKA001751A3002	1786/11-866 Rocker Switch/push button Single rocker DND stainless steel - Pure Stainless Steel	1786/11-866	1	piece
2CKA001751A3026	1786/11-884 Rocker Switch/push button Single rocker DND studio white matt - 63x63	1786/11-884	1	piece
2CKA001751A3145	1786-12-82 Rocker Switch/push button Single rocker red - 63x63	1786-12-82	1	piece
2CKA001751A3090	1786-20-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint platinum - alpha	1786-20-500	1	piece
2CKA001751A3086	1786-21-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint bronze - alpha	1786-21-500	1	piece
2CKA001751A3081	1786-22G-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint ivory - alpha	1786-22G-500	1	piece
2CKA001751A3078	1786-24G-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white	1786-24G-500	1	piece
2CKA001751A3080	1786-260-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint palladium - alpha	1786-260-500	1	piece
2CKA001751A3085	1786-266-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint titanium - alpha	1786-266-500	1	piece
2CKA001751A3093	1786-803-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint grey metallic - 63x63	1786-803-500	1	piece
2CKA001751A3079	1786-81-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint anthracite - 63x63	1786-81-500	1	piece
2CKA001751A3083	1786-82-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint ivory white - 63x63	1786-82-500	1	piece
2CKA001751A3075	1786-83-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint aluminium silver - 63x63	1786-83-500	1	piece
2CKA001751A3116	1786-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1786-840-500	1	piece
2CKA001751A3077	1786-866-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A3089	1786-884-500 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint studio white matt - 63x63	1786-884-500	1	piece
2CKA001751A2045	1787-20 Rocker Switch/push button Single rocker platinum - alpha	1787-20	1	piece
2CKA001751A2052	1787-21 Rocker Switch/push button Single rocker bronze - alpha	1787-21	1	piece
2CKA001751A2508	1787-22G Rocker Switch/push button Single rocker ivory - alpha	1787-22G	1	piece
2CKA001751A2177	1787-24G Rocker Switch/push button Single rocker studio white - alpha	1787-24G	1	piece
2CKA001751A2824	1787-260 Rocker Switch/push button Single rocker palladium - alpha	1787-260	1	piece
2CKA001751A2835	1787-266 Rocker Switch/push button Single rocker titanium - alpha	1787-266	1	piece
2CKA001751A1674	1788-20 Rocker Switch/push button Single rocker platinum - alpha	1788-20	1	piece
2CKA001751A1765	1788-21 Rocker Switch/push button Single rocker bronze - alpha	1788-21	1	piece

2CKA001751A2557	1788-22G Rocker Switch/push button Single rocker ivory - alpha	1788-22G	1	piece
2CKA001751A2326	1788-24G Rocker Switch/push button Single rocker studio white - alpha	1788-24G	1	piece
2CKA001751A2823	1788-260 Rocker Switch/push button Single rocker palladium - alpha	1788-260	1	piece
2CKA001751A2834	1788-266 Rocker Switch/push button Single rocker titanium - alpha	1788-266	1	piece
2CKA001751A3017	1788-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1788-803	1	piece
2CKA001751A2927	1788-81 Rocker Switch/push button Single rocker anthracite - 63x63	1788-81	1	piece
2CKA001751A2742	1788-82 Rocker Switch/push button Single rocker ivory white - 63x63	1788-82	1	piece
2CKA001751A2954	1788-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1788-83	1	piece
2CKA001751A2961	1788-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1788-866	1	piece
2CKA001751A3028	1788-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1788-884	1	piece
2CKA001751A1690	1789 H-20 Rocker with legend Switch/push button Single rocker Heizung platinum - alpha	1789 H-20	1	piece
2CKA001751A1781	1789 H-21 Rocker with legend Switch/push button Single rocker Heizung bronze - alpha	1789 H-21	1	piece
2CKA001751A2573	1789 H-22G Rocker with legend Switch/push button Single rocker Heizung ivory - alpha	1789 H-22G	1	piece
2CKA001751A2375	1789 H-24G Rocker with legend Switch/push button Single rocker Heizung studio white - alpha	1789 H-24G	1	piece
2CKA001751A2826	1789 H-260 Rocker with legend Switch/push button Single rocker Heizung palladium - alpha	1789 H-260	1	piece
2CKA001751A2837	1789 H-266 Rocker with legend Switch/push button Single rocker Heizung titanium - alpha	1789 H-266	1	piece
2CKA001751A3019	1789 H-803 Rocker with legend Switch/push button Single rocker Heizung grey metallic - 63x63	1789 H-803	1	piece
2CKA001751A2929	1789 H-81 Rocker with legend Switch/push button Single rocker Heizung anthracite - 63x63	1789 H-81	1	piece
2CKA001751A2743	1789 H-82 Rocker with legend Switch/push button Single rocker Heizung ivory white - 63x63	1789 H-82	1	piece
2CKA001751A2955	1789 H-83 Rocker with legend Switch/push button Single rocker Heizung aluminium silver - 63x63	1789 H-83	1	piece
2CKA001751A2963	1789 H-866 Rocker with legend Switch/push button Single rocker Heizung stainless steel - Pure Stainless Steel	1789 H-866	1	piece
2CKA001751A3029	1789 H-884 Rocker with legend Switch/push button Single rocker Heizung studio white matt - 63x63	1789 H-884	1	piece
2CKA001751A1641	1789 KI-20 Rocker Switch/push button Single rocker platinum - alpha	1789 KI-20	1	piece
2CKA001751A1732	1789 KI-21 Rocker Switch/push button Single rocker bronze - alpha	1789 KI-21	1	piece
2CKA001751A2524	1789 KI-22G Rocker with legend Switch/push button Single rocker Symbol "bell" ivory - alpha	1789 KI-22G	1	piece
2CKA001751A2235	1789 KI-24G Rocker with legend Switch/push button Single rocker Symbol "bell" studio white - alpha	1789 KI-24G	1	piece
2CKA001751A2829	1789 KI-260 Rocker with legend Switch/push button Single rocker Symbol "bell" palladium - alpha	1789 KI-260	1	piece
2CKA001751A2840	1789 KI-266 Rocker with legend Switch/push button Single rocker Symbol "bell" titanium - alpha	1789 KI-266	1	piece
2CKA001751A3015	1789 KI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 KI-803	1	piece
2CKA001751A2932	1789 KI-81 Rocker with legend Switch/push button Single rocker Symbol "bell" anthracite - 63x63	1789 KI-81	1	piece
2CKA001751A2746	1789 KI-82 Rocker with legend Switch/push button Single rocker Symbol "bell" ivory white - 63x63	1789 KI-82	1	piece
2CKA001751A2952	1789 KI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 KI-83	1	piece

2CKA001751A2959	1789 KI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	piece
2CKA001751A3030	1789 KI-884 Rocker with legend Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	1789 KI-884	1	piece
2CKA001751A1633	1789 LI-20 Rocker with legend Switch/push button Single rocker Symbol "light" platinum - alpha	1789 LI-20	1	piece
2CKA001751A1724	1789 LI-21 Rocker with legend Switch/push button Single rocker Symbol "light" bronze - alpha	1789 LI-21	1	piece
2CKA001751A2516	1789 LI-22G Rocker with legend Switch/push button Single rocker Symbol "light" ivory - alpha	1789 LI-22G	1	piece
2CKA001751A2201	1789 LI-24G Rocker with legend Switch/push button Single rocker Symbol "light" studio white - alpha	1789 LI-24G	1	piece
2CKA001751A2828	1789 LI-260 Rocker with legend Switch/push button Single rocker Symbol "light" palladium - alpha	1789 LI-260	1	piece
2CKA001751A2839	1789 LI-266 Rocker with legend Switch/push button Single rocker Symbol "light" titanium - alpha	1789 LI-266	1	piece
2CKA001751A3014	1789 LI-803 Rocker with legend Switch/push button Single rocker Symbol "light" grey metallic - 63x63	1789 LI-803	1	piece
2CKA001751A2931	1789 LI-81 Rocker with legend Switch/push button Single rocker Symbol "light" anthracite - 63x63	1789 LI-81	1	piece
2CKA001751A2745	1789 LI-82 Rocker with legend Switch/push button Single rocker Symbol "light" ivory white - 63x63	1789 LI-82	1	piece
2CKA001751A2951	1789 LI-83 Rocker with legend Switch/push button Single rocker Symbol "light" aluminium silver - 63x63	1789 LI-83	1	piece
2CKA001751A2958	1789 LI-866 Rocker with legend Switch/push button Single rocker Symbol "light" stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A3031	1789 LI-884 Rocker with legend Switch/push button Single rocker Symbol "light" studio white matt - 63x63	1789 LI-884	1	piece
2CKA001751A3146	1789 N-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 N-803	1	piece
2CKA001751A3147	1789 N-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 N-81	1	piece
2CKA001751A3148	1789 N-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 N-82	1	piece
2CKA001751A3149	1789 N-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 N-83	1	piece
2CKA001751A3152	1789 N-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A3153	1789 N-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 N-884	1	piece
2CKA001751A3156	1789 ST-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 ST-803	1	piece
2CKA001751A3157	1789 ST-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 ST-81	1	piece
2CKA001751A3158	1789 ST-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 ST-82	1	piece
2CKA001751A3159	1789 ST-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 ST-83	1	piece
2CKA001751A3162	1789 ST-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	piece
2CKA001751A3163	1789 ST-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 ST-884	1	piece
2CKA001751A1658	1789 TR-20 Rocker with legend Switch/push button Single rocker Symbol "key/door" platinum	1789 TR-20	1	piece
2CKA001751A1740	1789 TR-21 Rocker Switch/push button Single rocker bronze - alpha	1789 TR-21	1	piece
2CKA001751A2532	1789 TR-22G Rocker Switch/push button Single rocker ivory - alpha	1789 TR-22G	1	piece
2CKA001751A2268	1789 TR-24G Rocker Switch/push button Single rocker studio white - alpha	1789 TR-24G	1	piece

2CKA001751A2830	1789 TR-260 Rocker Switch/push button Single rocker palladium - alpha	1789 TR-260	1	piece
2CKA001751A2841	1789 TR-266 Rocker Switch/push button Single rocker titanium - alpha	1789 TR-266	1	piece
2CKA001751A3016	1789 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789 TR-803	1	piece
2CKA001751A2933	1789 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789 TR-81	1	piece
2CKA001751A2747	1789 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789 TR-82	1	piece
2CKA001751A2953	1789 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789 TR-83	1	piece
2CKA001751A2960	1789 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	piece
2CKA001751A3032	1789 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789 TR-884	1	piece
2CKA001751A1625	1789-20 Rocker Switch/push button Single rocker platinum - alpha	1789-20	1	piece
2CKA001751A1716	1789-21 Rocker Switch/push button Single rocker bronze - alpha	1789-21	1	piece
2CKA001751A2490	1789-22G Rocker Switch/push button Single rocker ivory - alpha	1789-22G	1	piece
2CKA001751A2102	1789-24G Rocker Switch/push button Single rocker studio white - alpha	1789-24G	1	piece
2CKA001751A2825	1789-260 Rocker Switch/push button Single rocker palladium - alpha	1789-260	1	piece
2CKA001751A2836	1789-266 Rocker Switch/push button Single rocker titanium - alpha	1789-266	1	piece
2CKA001751A3013	1789-803 Rocker Switch/push button Single rocker grey metallic - 63x63	1789-803	1	piece
2CKA001751A2928	1789-81 Rocker Switch/push button Single rocker anthracite - 63x63	1789-81	1	piece
2CKA001751A2813	1789-82 Rocker Switch/push button Single rocker ivory white - 63x63	1789-82	1	piece
2CKA001751A2945	1789-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	1789-83	1	piece
2CKA001751A3118	1789-840-500 Cover Plates Switch/push button Single rocker Without imprint antique brass - 63x63	1789-840-500	1	piece
2CKA001751A2957	1789-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001751A3033	1789-884 Rocker Switch/push button Single rocker studio white matt - 63x63	1789-884	1	piece
2CKA001710A3293	1792-20-101 Cover plate with legend Hotel card Hotel card Card platinum - alpha	1792-20-101	1	piece
2CKA001710A3294	1792-21-101 Cover plate with legend Hotel card Hotel card Card bronze - alpha	1792-21-101	1	piece
2CKA001710A3295	1792-22G-101 Cover plate with legend Hotel card Hotel card Card ivory - alpha	1792-22G-101	1	piece
2CKA001710A3297	1792-24G-101 Cover plate with legend Hotel card Hotel card Card studio white - alpha	1792-24G-101	1	piece
2CKA001710A3305	1792-260-101 Cover plate with legend Hotel card Hotel card Card palladium - alpha	1792-260-101	1	piece
2CKA001710A3331	1792-266-101 Cover plate with legend Hotel card Hotel card Card titanium - alpha	1792-266-101	1	piece
2CKA001710A4124	1792-803 Cover plate with legend Hotel card Hotel card Card grey metallic - 63x63	1792-803	1	piece
2CKA001710A3639	1792-81 Cover plate with legend Hotel card Hotel card Card anthracite - 63x63	1792-81	1	piece
2CKA001710A3640	1792-82 Cover plate with legend Hotel card Hotel card Card ivory white - 63x63	1792-82	1	piece
2CKA001710A3670	1792-83 Cover plate with legend Hotel card Hotel card Card aluminium silver - 63x63	1792-83	1	piece
2CKA001710A4078	1792-840-500 Cover Plates (partly incl. Insert) Switch/push button Hotel card antique brass - 63x63	1792-840-500	1	piece
2CKA001710A3757	1792-866 Cover plate with legend Hotel card Hotel card Card stainless steel - Pure Stainless Steel	1792-866	1	piece

2CKA001710A3928	1792-884 Cover plate with legend Hotel card Hotel card Card studio white matt - 63x63	1792-884	1	piece
2CKA001710A3684	1794 TA-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1794 TA-20	1	piece
2CKA001710A3685	1794 TA-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1794 TA-21	1	piece
2CKA001710A3686	1794 TA-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1794 TA-22G	1	piece
2CKA001710A3688	1794 TA-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1794 TA-24G	1	piece
2CKA001710A3693	1794 TA-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1794 TA-260	1	piece
2CKA001710A3694	1794 TA-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1794 TA-266	1	piece
2CKA001710A3849	1794 TA-803 Cover plate with legend for Thermostat Turn button grey metallic - 63x63	1794 TA-803	1	piece
2CKA001710A3695	1794 TA-81 Cover plate with legend for Thermostat Turn button anthracite - 63x63	1794 TA-81	1	piece
2CKA001710A3696	1794 TA-82 Cover plate with legend for Thermostat Turn button ivory white - 63x63	1794 TA-82	1	piece
2CKA001710A3697	1794 TA-83 Cover plate with legend for Thermostat Turn button aluminium silver - 63x63	1794 TA-83	1	piece
2CKA001710A3761	1794 TA-866 Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	piece
2CKA001710A3883	1794 TA-884 Cover plate with legend for Thermostat Turn button studio white matt - 63x63	1794 TA-884	1	piece
2CKA001710A3532	1794-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1794-20	1	piece
2CKA001710A3533	1794-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1794-21	1	piece
2CKA001710A3534	1794-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1794-22G	1	piece
2CKA001710A3536	1794-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1794-24G	1	piece
2CKA001710A3541	1794-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1794-260	1	piece
2CKA001710A3542	1794-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1794-266	1	piece
2CKA001710A3847	1794-803 Cover plate with legend for Thermostat Turn button grey metallic - 63x63	1794-803	1	piece
2CKA001710A3629	1794-81 Cover plate with legend for Thermostat Turn button anthracite - 63x63	1794-81	1	piece
2CKA001710A3543	1794-82 Cover plate with legend for Thermostat Turn button ivory white - 63x63	1794-82	1	piece
2CKA001710A3668	1794-83 Cover plate with legend for Thermostat Turn button aluminium silver - 63x63	1794-83	1	piece
2CKA001710A4087	1794-840-500 Cover Plates (partly incl. Insert) antique brass - 63x63	1794-840-500	1	piece
2CKA001710A3755	1794-866 Cover plate with legend for Thermostat stainless steel - Pure Stainless Steel	1794-866	1	piece
2CKA001710A3884	1794-884 Cover Plate for Thermostat Turn button studio white matt - 63x63	1794-884	1	piece
2CKA001710A3998	1795 HK-20 Cover plate with legend for Thermostat Turn button platinum - alpha	1795 HK-20	1	piece
2CKA001710A3999	1795 HK-21 Cover plate with legend for Thermostat Turn button bronze - alpha	1795 HK-21	1	piece
2CKA001710A4000	1795 HK-22G Cover plate with legend for Thermostat Turn button ivory - alpha	1795 HK-22G	1	piece
2CKA001710A4002	1795 HK-24G Cover plate with legend for Thermostat Turn button studio white - alpha	1795 HK-24G	1	piece
2CKA001710A4003	1795 HK-260 Cover plate with legend for Thermostat Turn button palladium - alpha	1795 HK-260	1	piece
2CKA001710A4004	1795 HK-266 Cover plate with legend for Thermostat Turn button titanium - alpha	1795 HK-266	1	piece
2CKA001710A4012	1795 HK-803 Cover plate with legend for Thermostat Turn button grey metallic - 63x63	1795 HK-803	1	piece
2CKA001710A4013	1795 HK-81 Cover plate with legend for Thermostat Turn button anthracite - 63x63	1795 HK-81	1	piece

2CKA001710A4015	1795 HK-82 Cover plate with legend for Thermostat Turn button ivory white - 63x63	1795 HK-82	1	piece
2CKA001710A4016	1795 HK-83 Cover Plate for Thermostat Turn button aluminium silver - 63x63	1795 HK-83	1	piece
2CKA001710A4018	1795 HK-866 Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	piece
2CKA001710A4019	1795 HK-884 Cover plate with legend for Thermostat Turn button studio white matt - 63x63	1795 HK-884	1	piece
2CKA001710A4030	1795 HKEA-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 HKEA-20	1	piece
2CKA001710A4031	1795 HKEA-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 HKEA-21	1	piece
2CKA001710A4032	1795 HKEA-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 HKEA- 22G	1	piece
2CKA001710A4034	1795 HKEA-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795 HKEA- 24G	1	piece
2CKA001710A4035	1795 HKEA-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 HKEA- 260	1	piece
2CKA001710A4036	1795 HKEA-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 HKEA- 266	1	piece
2CKA001710A4044	1795 HKEA-803 Cover plate with legend for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795 HKEA- 803	1	piece
2CKA001710A4045	1795 HKEA-81 Cover plate with legend for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795 HKEA-81	1	piece
2CKA001710A4047	1795 HKEA-82 Cover plate with legend for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795 HKEA-82	1	piece
2CKA001710A4048	1795 HKEA-83 Cover plate with legend for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795 HKEA-83	1	piece
2CKA001710A4050	1795 HKEA-866 Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 HKEA- 866	1	piece
2CKA001710A4051	1795 HKEA-884 Cover plate with legend for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795 HKEA- 884	1	piece
2CKA001710A3711	1795 TA-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 TA-20	1	piece
2CKA001710A3712	1795 TA-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 TA-21	1	piece
2CKA001710A3713	1795 TA-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 TA-22G	1	piece
2CKA001710A3715	1795 TA-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795 TA-24G	1	piece
2CKA001710A3720	1795 TA-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 TA-260	1	piece
2CKA001710A3721	1795 TA-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 TA-266	1	piece
2CKA001710A3850	1795 TA-803 Cover plate with legend for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795 TA-803	1	piece
2CKA001710A3722	1795 TA-81 Cover plate with legend for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795 TA-81	1	piece
2CKA001710A3723	1795 TA-82 Cover plate with legend for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795 TA-82	1	piece

2CKA001710A3724	1795 TA-83 Cover plate with legend for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795 TA-83	1	piece
2CKA001710A3762	1795 TA-866 Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 TA-866	1	piece
2CKA001710A3885	1795 TA-884 Cover plate with legend for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795 TA-884	1	piece
2CKA001710A3557	1795-20 Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795-20	1	piece
2CKA001710A3558	1795-21 Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795-21	1	piece
2CKA001710A3559	1795-22G Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795-22G	1	piece
2CKA001710A3561	1795-24G Cover plate with legend for Thermostat Turn button 1 sliding switch studio white - alpha	1795-24G	1	piece
2CKA001710A3566	1795-260 Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795-260	1	piece
2CKA001710A3567	1795-266 Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795-266	1	piece
2CKA001710A3848	1795-803 Cover plate with legend for Thermostat Turn button 1 sliding switch grey metallic - 63x63	1795-803	1	piece
2CKA001710A3630	1795-81 Cover plate with legend for Thermostat Turn button 1 sliding switch anthracite - 63x63	1795-81	1	piece
2CKA001710A3568	1795-82 Cover plate with legend for Thermostat Turn button 1 sliding switch ivory white - 63x63	1795-82	1	piece
2CKA001710A3669	1795-83 Cover plate with legend for Thermostat Turn button 1 sliding switch aluminium silver - 63x63	1795-83	1	piece
2CKA001710A4088	1795-840-500 Cover Plates (partly incl. Insert) antique brass - 63x63	1795-840-500	1	piece
2CKA001710A3756	1795-866 Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795-866	1	piece
2CKA001710A3886	1795-884 Cover plate with legend for Thermostat Turn button 1 sliding switch studio white matt - 63x63	1795-884	1	piece
2CKA001753A0307	1796-803 Cover Plate Pull cord grey metallic - 63x63	1796-803	1	piece
2CKA001753A0308	1796-81 Cover Plate Pull cord anthracite - 63x63	1796-81	1	piece
2CKA001753A0309	1796-82 Cover Plate Pull cord ivory white - 63x63	1796-82	1	piece
2CKA001753A0310	1796-83 Cover Plate Pull cord aluminium silver - 63x63	1796-83	1	piece
2CKA001753A0312	1796-866 Cover Plate Pull cord stainless steel - Pure Stainless Steel	1796-866	1	piece
2CKA001753A0313	1796-884 Cover Plate Pull cord studio white matt - 63x63	1796-884	1	piece
2CKA001753A9178	1800-20 Cover plate with labelling field Modular Jack 2 gang platinum - alpha	1800-20	1	piece
2CKA001753A9186	1800-21 Cover plate with labelling field Modular Jack 2 gang bronze - alpha	1800-21	1	piece
2CKA001710A2645	1800-22G Cover plate with labelling field Modular Jack 2 gang ivory - alpha	1800-22G	1	piece
2CKA001710A2710	1800-24G Cover plate with labelling field Modular Jack 2 gang studio white - alpha	1800-24G	1	piece
2CKA001710A3318	1800-260 Cover Plate Modular Jack 2 gang palladium - alpha	1800-260	1	piece
2CKA001710A3344	1800-266 Cover plate with labelling field Modular Jack 2 gang titanium - alpha	1800-266	1	piece
2CKA001710A3856	1800-803 Cover plate with labelling field Modular Jack 2 gang grey metallic - 63x63	1800-803	1	piece
2CKA001710A3627	1800-81 Cover plate with labelling field Modular Jack 2 gang anthracite - 63x63	1800-81	1	piece
2CKA001710A3158	1800-82 Cover plate with labelling field Modular Jack 2 gang ivory white - 63x63	1800-82	1	piece
2CKA001710A3676	1800-83 Cover plate with labelling field Modular Jack 2 gang aluminium silver - 63x63	1800-83	1	piece
2CKA001710A4085	1800-840-500 Cover Plate Modular Jack 2 gang antique brass - 63x63	1800-840-500	1	piece

2CKA001710A3767	1800-866 Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel	1800-866	1	piece
2CKA001710A3887	1800-884 Cover plate with labelling field Modular Jack 2 gang studio white matt - 63x63	1800-884	1	piece
2CKA001753A8485	1803-02-20 Cover Plate UAE/IAE (ISDN) 2 gang platinum - alpha	1803-02-20	1	piece
2CKA001753A8493	1803-02-21 Cover Plate UAE/IAE (ISDN) 2 gang bronze - alpha	1803-02-21	1	piece
2CKA001710A2611	1803-02-22G Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-02-22G	1	piece
2CKA001710A2033	1803-02-24G Cover Plate UAE/IAE (ISDN) 2 gang studio white - alpha	1803-02-24G	1	piece
2CKA001710A3321	1803-02-260 Cover Plate UAE/IAE (ISDN) 2 gang palladium - alpha	1803-02-260	1	piece
2CKA001710A3347	1803-02-266 Cover Plate UAE/IAE (ISDN) 2 gang titanium - alpha	1803-02-266	1	piece
2CKA001710A3853	1803-02-803 Cover plate with labelling field UAE/IAE (ISDN) 2 gang grey metallic - 63x63	1803-02-803	1	piece
2CKA001710A3615	1803-02-81 Cover plate with labelling field UAE/IAE (ISDN) 2 gang anthracite - 63x63	1803-02-81	1	piece
2CKA001710A3146	1803-02-82 Cover plate with labelling field UAE/IAE (ISDN) 2 gang ivory white - 63x63	1803-02-82	1	piece
2CKA001710A3610	1803-02-83 Cover plate with labelling field UAE/IAE (ISDN) 2 gang aluminium silver - 63x63	1803-02-83	1	piece
2CKA001710A4083	1803-02-840-500 Cover Plate UAE/IAE (ISDN) 2 gang antique brass - 63x63	1803-02-840-500	1	piece
2CKA001710A3764	1803-02-866 Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel	1803-02-866	1	piece
2CKA001710A3888	1803-02-884 Cover plate with labelling field UAE/IAE (ISDN) 2 gang studio white matt - 63x63	1803-02-884	1	piece
2CKA001753A8410	1803-20 Cover Plate UAE/IAE (ISDN) 1 gang platinum - alpha	1803-20	1	piece
2CKA001753A8428	1803-21 Cover Plate UAE/IAE (ISDN) 1 gang bronze - alpha	1803-21	1	piece
2CKA001710A2603	1803-22G Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-22G	1	piece
2CKA001710A2025	1803-24G Cover Plate UAE/IAE (ISDN) 1 gang studio white - alpha	1803-24G	1	piece
2CKA001710A3322	1803-260 Cover Plate UAE/IAE (ISDN) 1 gang palladium - alpha	1803-260	1	piece
2CKA001710A3348	1803-266 Cover Plate UAE/IAE (ISDN) 1 gang titanium - alpha	1803-266	1	piece
2CKA001710A3852	1803-803 Cover plate with labelling field UAE/IAE (ISDN) 1 gang grey metallic - 63x63	1803-803	1	piece
2CKA001710A3616	1803-81 Cover plate with labelling field UAE/IAE (ISDN) 1 gang anthracite - 63x63	1803-81	1	piece
2CKA001710A3147	1803-82 Cover plate with labelling field UAE/IAE (ISDN) 1 gang ivory white - 63x63	1803-82	1	piece
2CKA001710A3674	1803-83 Cover plate with labelling field UAE/IAE (ISDN) 1 gang aluminium silver - 63x63	1803-83	1	piece
2CKA001710A4082	1803-840-500 Cover Plate UAE/IAE (ISDN) 1 gang antique brass - 63x63	1803-840-500	1	piece
2CKA001710A3763	1803-866 Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel	1803-866	1	piece
2CKA001710A3889	1803-884 Cover plate with labelling field UAE/IAE (ISDN) 1 gang studio white matt - 63x63	1803-884	1	piece
2CKA002013A5404	20 EUAB-81 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUAB-81	1	piece
2CKA002013A5405	20 EUAB-82 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUAB-82	1	piece
2CKA002013A5406	20 EUAB-83 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUAB-83	1	piece
2CKA002013A5408	20 EUAB-866 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUAB-866	1	piece

2CKA002013A5409	20 EUAB-884 Busch-Object socket outlet Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	20 EUAB-884	1	piece
2CKA002011A6260	20 EUC-13-82-101 Socket insert Protective Contact (SCHUKO) green - 63x63	20 EUC-13-82-101	1	piece
2CKA002011A3723	20 EUC-14-82 Socket Protective Contact (SCHUKO) orange - 63x63	20 EUC-14-82	1	piece
2CKA002011A6222	20 EUC-20-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) platinum - alpha	20 EUC-20-500	1	piece
2CKA002011A6221	20 EUC-21-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) bronze - alpha	20 EUC-21-500	1	piece
2CKA002011A6225	20 EUC-22G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) ivory - alpha	20 EUC-22G-500	1	piece
2CKA002011A6223	20 EUC-24G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - alpha	20 EUC-24G-500	1	piece
2CKA002011A6229	20 EUC-260-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) palladium - alpha	20 EUC-260-500	1	piece
2CKA002011A6226	20 EUC-266-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) titanium - alpha	20 EUC-266-500	1	piece
2CKA002011A6216	20 EUC-803-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) grey metallic - 63x63	20 EUC-803-500	1	piece
2CKA002011A6215	20 EUC-81-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) anthracite - 63x63	20 EUC-81-500	1	piece
2CKA002011A6214	20 EUC-82-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) ivory white - 63x63	20 EUC-82-500	1	piece
2CKA002011A6213	20 EUC-83-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) aluminium silver - 63x63	20 EUC-83-500	1	piece
2CKA002011A6212	20 EUC-866-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) stainless steel - Pure Stainless Steel	20 EUC-866-500	1	piece
2CKA002011A6208	20 EUC-884-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white matt - 63x63	20 EUC-884-500	1	piece
2CKA002013A5472	20 EUCB-13-82-102 Socket insert Protective Contact (SCHUKO) Safety Shutter green - 63x63	20 EUCB-13-82-102	1	piece
2CKA002013A5413	20 EUCB-14-82-10 Socket insert Protective Contact (SCHUKO) Safety Shutter orange - 63x63	20 EUCB-14-82-10	1	piece
2CKA002013A5414	20 EUCBDR-803 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter grey metallic - 63x63	20 EUCBDR-803	1	piece
2CKA002013A5415	20 EUCBDR-81 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUCBDR-81	1	piece
2CKA002013A5416	20 EUCBDR-82 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUCBDR-82	1	piece
2CKA002013A5417	20 EUCBDR-83 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUCBDR-83	1	piece
2CKA002013A5419	20 EUCBDR-866 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	piece
2CKA002013A5421	20 EUCBDR-885 Busch-Service-Socket Socket insert Protective Contact (SCHUKO) Safety Shutter black matt - 63x63	20 EUCBDR-885	1	piece
2CKA002013A5467	20 EUCBL-13-84-101 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green green - 63x63	20 EUCBL-13-84-101	1	piece
2CKA002013A5288	20 EUCBL-14-84 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green orange - 63x63	20 EUCBL-14-84	1	piece
2CKA002013A5456	20 EUCBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green grey metallic - 63x63	20 EUCBL-803	1	piece
2CKA002013A5457	20 EUCBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green anthracite - 63x63	20 EUCBL-81	1	piece

2CKA002013A5284	20 EUCBL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green ivory white - 63x63	20 EUCBL-82	1	piece
2CKA002013A5285	20 EUCBL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green aluminium silver - 63x63	20 EUCBL-83	1	piece
2CKA002013A5289	20 EUCBL-866 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel	20 EUCBL-866	1	piece
2CKA002013A5336	20 EUCBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green studio white matt - 63x63	20 EUCBL-884	1	piece
2CKA002013A5458	20 EUCBLI-803 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter withNight light; LED /White grey metallic - 63x63	20 EUCBLI-803	1	piece
2CKA002013A5459	20 EUCBLI-81 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter Night orientation light withNight light; LED /White anthracite - 63x63	20 EUCBLI-81	1	piece
2CKA002013A5292	20 EUCBLI-82 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter Night orientation light withNight light; LED /White ivory white - 63x63	20 EUCBLI-82	1	piece
2CKA002013A5293	20 EUCBLI-83 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter withNight light; LED /White aluminium silver - 63x63	20 EUCBLI-83	1	piece
2CKA002013A5399	20 EUCBLI-840-500 Busch-steplight Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) Night orientation light withNight light; LED /White antique brass - 63x63	20 EUCBLI-840-500	1	piece
2CKA002013A5460	20 EUCBLI-866 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter withNight light; LED /White stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	piece
2CKA002013A5326	20 EUCBLI-884 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter withNight light; LED /White studio white matt - 63x63	20 EUCBLI-884	1	piece
2CKA002013A5463	20 EUCKSDV-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter red - 63x63	20 EUCKSDV-12-82-101	1	piece
2CKA002013A5462	20 EUCKSDV-803 Socket insert Protective Contact (SCHUKO) Safety Shutter grey metallic - 63x63	20 EUCKSDV-803	1	piece
2CKA002013A5266	20 EUCKSDV-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUCKSDV-81	1	piece
2CKA002013A5267	20 EUCKSDV-82 Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUCKSDV-82	1	piece
2CKA002013A5273	20 EUCKSDV-83 Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUCKSDV-83	1	piece
2CKA002013A5277	20 EUCKSDV-866 Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKSDV-866	1	piece
2CKA002013A5327	20 EUCKSDV-884 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	20 EUCKSDV-884	1	piece
2CKA002013A5464	20 EUCKSDV-12-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter red - 63x63	20 EUCKSDV-12-82-101	1	piece
2CKA002013A5470	20 EUCKSDV-13-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter green - 63x63	20 EUCKSDV-13-82-101	1	piece
2CKA002013A5324	20 EUCKSDV-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter orange - 63x63	20 EUCKSDV-14-82	1	piece
2CKA002013A4458	20 EUCKSDV-20 Socket insert Protective Contact (SCHUKO) Safety Shutter platinum - alpha	20 EUCKSDV-20	1	piece
2CKA002013A4466	20 EUCKSDV-21 Socket insert Protective Contact (SCHUKO) Safety Shutter bronze - alpha	20 EUCKSDV-21	1	piece
2CKA002013A5240	20 EUCKSDV-22G Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - alpha	20 EUCKSDV-22G	1	piece
2CKA002013A5377	20 EUCKSDV-24G-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) studio white - alpha	20 EUCKSDV-24G-500	1	piece

2CKA002013A5252	20 EUCKS-260 Socket insert Protective Contact (SCHUKO) Safety Shutter palladium - alpha	20 EUCKS-260	1	piece
2CKA002013A5253	20 EUCKS-266 Socket insert Protective Contact (SCHUKO) Safety Shutter titanium - alpha	20 EUCKS-266	1	piece
2CKA002013A5297	20 EUCKS-803 Socket insert Protective Contact (SCHUKO) Safety Shutter grey metallic - 63x63	20 EUCKS-803	1	piece
2CKA002013A5265	20 EUCKS-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUCKS-81	1	piece
2CKA002013A5376	20 EUCKS-82-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUCKS-82-500	1	piece
2CKA002013A5375	20 EUCKS-83-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUCKS-83-500	1	piece
2CKA002013A5374	20 EUCKS-866-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKS-866-500	1	piece
2CKA002013A5373	20 EUCKS-884-500 Socket insert Protective Contact (SCHUKO) Safety Shutter Protective contact (SCHUKO) studio white matt - 63x63	20 EUCKS-884-500	1	piece
2CKA002013A5423	20 EUCNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter red - 63x63	20 EUCNB-12-82	1	piece
2CKA002013A5424	20 EUCNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter green - 63x63	20 EUCNB-13-82	1	piece
2CKA002013A5425	20 EUCNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter orange - 63x63	20 EUCNB-14-82	1	piece
2CKA002013A5426	20 EUCNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter grey metallic - 63x63	20 EUCNB-803	1	piece
2CKA002013A5427	20 EUCNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUCNB-81	1	piece
2CKA002013A5428	20 EUCNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUCNB-82	1	piece
2CKA002013A5429	20 EUCNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUCNB-83	1	piece
2CKA002013A5432	20 EUCNB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUCNB-866	1	piece
2CKA002013A5433	20 EUCNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	20 EUCNB-884	1	piece
2CKA002013A5436	20 EUCRB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter Protective contact (SCHUKO) grey metallic - 63x63	20 EUCRB-803	1	piece
2CKA002013A5437	20 EUCRB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	20 EUCRB-81	1	piece
2CKA002013A5438	20 EUCRB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	20 EUCRB-82	1	piece
2CKA002013A5439	20 EUCRB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	20 EUCRB-83	1	piece
2CKA002013A5442	20 EUCRB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	20 EUCRB-866	1	piece
2CKA002013A5443	20 EUCRB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	20 EUCRB-884	1	piece
2CKA002018A0695	20 EUK-20 Socket insert Protective Contact (SCHUKO) with Hinged Lid platinum - alpha	20 EUK-20	1	piece
2CKA002018A0703	20 EUK-21 Socket insert Protective Contact (SCHUKO) with Hinged Lid bronze - alpha	20 EUK-21	1	piece
2CKA002018A1446	20 EUK-22G Socket insert Protective Contact (SCHUKO) with Hinged Lid ivory white - alpha	20 EUK-22G	1	piece
2CKA002018A1040	20 EUK-24G Socket insert Protective Contact (SCHUKO) with Hinged Lid studio white - alpha	20 EUK-24G	1	piece
2CKA002018A1464	20 EUK-260 Socket insert Protective Contact (SCHUKO) with Hinged Lid palladium - alpha	20 EUK-260	1	piece
2CKA002018A1466	20 EUK-266 Socket insert Protective Contact (SCHUKO) with Hinged Lid titanium - alpha	20 EUK-266	1	piece
2CKA002018A1493	20 EUK-803 Socket insert Protective Contact (SCHUKO) with Hinged Lid grey metallic - 63x63	20 EUK-803	1	piece

2CKA002018A1486	20 EUK-81 Socket insert Protective Contact (SCHUKO) with Hinged Lid anthracite - 63x63	20 EUK-81	1	piece
2CKA002018A1465	20 EUK-82 Socket insert Protective Contact (SCHUKO) with Hinged Lid ivory white - 63x63	20 EUK-82	1	piece
2CKA002018A1487	20 EUK-83 Socket insert Protective Contact (SCHUKO) with Hinged Lid aluminium silver - 63x63	20 EUK-83	1	piece
2CKA002018A1515	20 EUK-840-500 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) with Hinged Lid antique brass - 63x63	20 EUK-840-500	1	piece
2CKA002018A1490	20 EUK-866 Socket insert Protective Contact (SCHUKO) with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	piece
2CKA002018A1494	20 EUK-884 Socket insert Protective Contact (SCHUKO) with Hinged Lid studio white matt - 63x63	20 EUK-884	1	piece
2CKA002018A1516	20 EUKB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKB-803	1	piece
2CKA002018A1517	20 EUKB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKB-81	1	piece
2CKA002018A1518	20 EUKB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKB-82	1	piece
2CKA002018A1519	20 EUKB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKB-83	1	piece
2CKA002018A1521	20 EUKB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	piece
2CKA002018A1522	20 EUKB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKB-884	1	piece
2CKA002018A1525	20 EUKBR-803 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKBR-803	1	piece
2CKA002018A1526	20 EUKBR-81 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKBR-81	1	piece
2CKA002018A1527	20 EUKBR-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKBR-82	1	piece
2CKA002018A1528	20 EUKBR-83 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKBR-83	1	piece
2CKA002018A1530	20 EUKBR-884 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKBR-884	1	piece
2CKA002018A1531	20 EUKBR-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid black matt - 63x63	20 EUKBR-885	1	piece
2CKA002018A1533	20 EUKNB-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid red - 63x63	20 EUKNB-12-82	1	piece
2CKA002018A1534	20 EUKNB-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid green - 63x63	20 EUKNB-13-82	1	piece
2CKA002018A1535	20 EUKNB-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid orange - 63x63	20 EUKNB-14-82	1	piece
2CKA002018A1536	20 EUKNB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKNB-803	1	piece
2CKA002018A1537	20 EUKNB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKNB-81	1	piece
2CKA002018A1538	20 EUKNB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid ivory white - 63x63	20 EUKNB-82	1	piece
2CKA002018A1539	20 EUKNB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid aluminium silver - 63x63	20 EUKNB-83	1	piece

2CKA002018A1541	20 EUKNB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKNB-884	1	piece
2CKA002018A1542	20 EUKNB-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid black matt - 63x63	20 EUKNB-885	1	piece
2CKA002018A1544	20 EUKNBL-12-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid red - 63x63	20 EUKNBL-12-82	1	piece
2CKA002018A1545	20 EUKNBL-13-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid green - 63x63	20 EUKNBL-13-82	1	piece
2CKA002018A1546	20 EUKNBL-14-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid orange - 63x63	20 EUKNBL-14-82	1	piece
2CKA002018A1547	20 EUKNBL-803 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid grey metallic - 63x63	20 EUKNBL-803	1	piece
2CKA002018A1548	20 EUKNBL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid anthracite - 63x63	20 EUKNBL-81	1	piece
2CKA002018A1552	20 EUKNBL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid studio white matt - 63x63	20 EUKNBL-884	1	piece
2CKA002018A1553	20 EUKNBL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid black matt - 63x63	20 EUKNBL-885	1	piece
2CKA002018A1557	20 EUKNBSL-81 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Different locking anthracite - 63x63	20 EUKNBSL-81	1	piece
2CKA002018A1558	20 EUKNBSL-81-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Simultaneous locking anthracite - 63x63	20 EUKNBSL-81-101	1	piece
2CKA002018A1559	20 EUKNBSL-82 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Different locking ivory white - 63x63	20 EUKNBSL-82	1	piece
2CKA002018A1560	20 EUKNBSL-82-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Simultaneous locking ivory white - 63x63	20 EUKNBSL-82-101	1	piece
2CKA002018A1561	20 EUKNBSL-83 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Different locking aluminium silver - 63x63	20 EUKNBSL-83	1	piece
2CKA002018A1562	20 EUKNBSL-83-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Simultaneous locking aluminium silver - 63x63	20 EUKNBSL-83-101	1	piece
2CKA002018A1565	20 EUKNBSL-884 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Different locking studio white matt - 63x63	20 EUKNBSL-884	1	piece
2CKA002018A1566	20 EUKNBSL-884-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Simultaneous locking studio white matt - 63x63	20 EUKNBSL-884-101	1	piece
2CKA002018A1567	20 EUKNBSL-885 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Different locking black matt - 63x63	20 EUKNBSL-885	1	piece
2CKA002018A1568	20 EUKNBSL-885-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid and lock; Simultaneous locking black matt - 63x63	20 EUKNBSL-885-101	1	piece
2CKA002011A3876	20 EUN-803 Socket insert Protective Contact (SCHUKO) grey metallic - 63x63	20 EUN-803	1	piece
2CKA002011A3802	20 EUN-81 Socket insert Protective Contact (SCHUKO) anthracite - 63x63	20 EUN-81	1	piece
2CKA002011A3726	20 EUN-82 Socket insert Protective Contact (SCHUKO) ivory white - 63x63	20 EUN-82	1	piece
2CKA002011A3810	20 EUN-83 Socket insert Protective Contact (SCHUKO) aluminium silver - 63x63	20 EUN-83	1	piece
2CKA002011A3851	20 EUN-866 Socket insert Protective Contact (SCHUKO) stainless steel - Pure Stainless Steel	20 EUN-866	1	piece

2CKA002011A3881	20 EUN-884 Socket insert Protective Contact (SCHUKO) studio white matt - 63x63	20 EUN-884	1	piece
2CKA002017A0808	20 MUC-20-500 Socket insert Earthing Pin platinum - alpha	20 MUC-20-500	1	piece
2CKA002017A0811	20 MUC-21-500 Socket insert Earthing Pin bronze - alpha	20 MUC-21-500	1	piece
2CKA002017A0813	20 MUC-22G-500 Socket insert Earthing Pin ivory white - alpha	20 MUC-22G-500	1	piece
2CKA002017A0815	20 MUC-24G-500 Cover Plates (partly incl. Insert) French norm NF studio white - alpha	20 MUC-24G-500	1	piece
2CKA002017A0817	20 MUC-260-500 Socket insert Earthing Pin palladium - alpha	20 MUC-260-500	1	piece
2CKA002017A0818	20 MUC-266-500 Socket insert Earthing Pin titanium - alpha	20 MUC-266-500	1	piece
2CKA002017A0785	20 MUC-82-500 Socket insert Earthing Pin ivory white - 63x63	20 MUC-82-500	1	piece
2CKA002017A0832	20 MUCKS-20-500 Socket insert Earthing Pin Safety Shutter platinum - alpha	20 MUCKS-20-500	1	piece
2CKA002017A0835	20 MUCKS-21-500 Cover Plates (partly incl. Insert) French norm NF bronze - alpha	20 MUCKS-21-500	1	piece
2CKA002017A0802	20 MUCKS-22G-500 Socket insert Earthing Pin Safety Shutter ivory white - alpha	20 MUCKS-22G-500	1	piece
2CKA002017A0803	20 MUCKS-24G-500 Cover Plates (partly incl. Insert) French norm NF studio white - alpha	20 MUCKS-24G-500	1	piece
2CKA002017A0804	20 MUCKS-260-500 Socket insert Earthing Pin Safety Shutter palladium - alpha	20 MUCKS-260-500	1	piece
2CKA002017A0805	20 MUCKS-266-500 Socket insert Earthing Pin Safety Shutter titanium - alpha	20 MUCKS-266-500	1	piece
2CKA002017A0852	20 MUCKS-803-500 Cover Plates (partly incl. Insert) Safety Shutter French norm NF grey metallic - 63x63	20 MUCKS-803-500	1	piece
2CKA002017A0898	20 MUCKS-81-500 Socket insert Earthing Pin Safety Shutter Earthing pin anthracite - 63x63	20 MUCKS-81-500	1	piece
2CKA002017A0806	20 MUCKS-82-500 Socket insert Earthing Pin Safety Shutter ivory white - 63x63	20 MUCKS-82-500	1	piece
2CKA002017A0899	20 MUCKS-83-500 Socket insert Safety Shutter French norm NF aluminium silver - 63x63	20 MUCKS-83-500	1	piece
2CKA002017A0900	20 MUCKS-866-500 Socket insert Safety Shutter French norm NF stainless steel - Pure Stainless Steel	20 MUCKS-866-500	1	piece
2CKA002017A0901	20 MUCKS-884-500 Socket insert Safety Shutter French norm NF studio white matt - 63x63	20 MUCKS-884-500	1	piece
2CKA001751A3167	2029 UC-81 Bell push-switch DND / MUR insert Single push button Push button DND, MUR with LED anthracite - 63x63	2029 UC-81	1	piece
2CKA001751A3171	2029 UC-866 Bell push-switch DND / MUR insert Single push button Push button DND, MUR and Symbol "bell" with LED stainless steel - Pure Stainless Steel	2029 UC-866	1	piece
2CKA002495A0084	2095 UC-81 Socket insert Equipotential compensation Socket outlet 2-position anthracite - 63x63	2095 UC-81	1	piece
2CKA002495A0085	2095 UC-82 Socket insert Equipotential compensation Socket outlet 2-position ivory white - 63x63	2095 UC-82	1	piece
2CKA002495A0089	2095 UC-83 Socket insert Equipotential compensation Socket outlet 2-position aluminium silver - 63x63	2095 UC-83	1	piece
2CKA002495A0090	2095 UC-866 Socket insert Equipotential compensation Socket outlet 2-position stainless steel - Pure Stainless Steel	2095 UC-866	1	piece
2CKA002495A0091	2095 UC-884 Socket insert Equipotential compensation Socket outlet 2-position studio white matt - 63x63	2095 UC-884	1	piece
2CKA002190A0224	2190 EUC-803 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard grey metallic	2190 EUC-803	1	piece
2CKA002190A0216	2190 EUC-81 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard anthracite - 63x63	2190 EUC-81	1	piece

2CKA002190A0213	2190 EUC-82 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard ivory	2190 EUC-82	1	piece
2CKA002190A0214	2190 EUC-83 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard aluminium silver - 63x63	2190 EUC-83	1	piece
2CKA002190A0222	2190 EUC-840-500 Cover Plates (partly incl. Insert) British Standard antique brass - 63x63	2190 EUC-840 -500	1	piece
2CKA002190A0217	2190 EUC-866 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard stainless steel - Pure Stainless Steel	2190 EUC-866	1	piece
2CKA002190A0218	2190 EUC-884 Cover Plates (partly incl. Insert) Power Socket Outlets - British acc. to BS1363 British Standard studio white matt - 63x63	2190 EUC-884	1	piece
2CKA002013A5475	23 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	23 EUCB-82	1	piece
2CKA002013A5476	23 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	23 EUCB-83	1	piece
2CKA002013A5478	23 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	23 EUCB-866	1	piece
2CKA002013A5447	2300 EUCB-803 Socket insert Protective Contact (SCHUKO) Safety Shutter grey metallic - 63x63	2300 EUCB- 803	1	piece
2CKA002013A5448	2300 EUCB-81 Socket insert Protective Contact (SCHUKO) Safety Shutter anthracite - 63x63	2300 EUCB-81	1	piece
2CKA002013A5449	2300 EUCB-82 Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	2300 EUCB-82	1	piece
2CKA002013A5450	2300 EUCB-83 Socket insert Protective Contact (SCHUKO) Safety Shutter aluminium silver - 63x63	2300 EUCB-83	1	piece
2CKA002013A5452	2300 EUCB-866 Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	2300 EUCB- 866	1	piece
2CKA002013A5453	2300 EUCB-884 Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	2300 EUCB- 884	1	piece
2CKA002113A0505	2300 UCRKS-22G-503 Cover Plates (partly incl. Insert) ivory	2300 UCRKS- 22G-503	1	piece
2CKA002111A0623	2300 UCRKS-24G-503 Cover Plates (partly incl. Insert) studio white	2300 UCRKS- 24G-503	1	piece
2CKA002113A0508	2300 UCRKS-260-503 Cover Plates (partly incl. Insert) palladium	2300 UCRKS- 260-503	1	piece
2CKA002113A0509	2300 UCRKS-266-503 Cover Plates (partly incl. Insert) titanium - alpha	2300 UCRKS- 266-503	1	piece
2CKA002113A5339	2300 UCRKS-81-503 Cover Plates (partly incl. Insert) Safety Shutter anthracite - 63x63	2300 UCRKS- 81-503	1	piece
2CKA002113A0510	2300 UCRKS-82-503 Cover Plates (partly incl. Insert) Safety Shutter ivory white - 63x63	2300 UCRKS- 82-503	1	piece
2CKA002113A5337	2300 UCRKS-884-503 Cover Plates (partly incl. Insert) Safety Shutter studio white matt - 63x63	2300 UCRKS- 884-503	1	piece
2CKA002011A6257	2310 EUGL/VA-12-82-101 Busch-Protector® Socket insert Protective Contact (SCHUKO) red - 63x63	2310 EUGL/VA -12-82-101	1	piece
2CKA002011A3819	2310 EUGL/VA-20-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) platinum - alpha	2310 EUGL/VA -20-11	1	piece
2CKA002011A3820	2310 EUGL/VA-21-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) bronze - alpha	2310 EUGL/VA -21-11	1	piece
2CKA002011A3830	2310 EUGL/VA-81-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) anthracite - 63x63	2310 EUGL/VA -81-11	1	piece
2CKA002011A3831	2310 EUGL/VA-82-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) ivory white - 63x63	2310 EUGL/VA -82-11	1	piece
2CKA002011A3832	2310 EUGL/VA-83-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) aluminium silver - 63x63	2310 EUGL/VA -83-11	1	piece
2CKA002011A3821	2310 EUGL/VA-22G-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) ivory white - alpha	2310 EUGL/VA- 22G-11	1	piece

2CKA002011A3823	2310EUGLVA-24G-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) studio white - alpha	2310EUGLVA-24G-11	1	piece
2CKA002011A3828	2310EUGLVA-260-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) palladium - alpha	2310EUGLVA-260-11	1	piece
2CKA002011A3829	2310EUGLVA-266-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) titanium - alpha	2310EUGLVA-266-11	1	piece
2CKA002011A3877	2310EUGLVA-803-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) grey metallic - 63x63	2310EUGLVA-803-11	1	piece
2CKA002011A3853	2310EUGLVA-866-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) stainless steel - Pure Stainless Steel	2310EUGLVA-866-11	1	piece
2CKA002011A3882	2310EUGLVA-884-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) studio white matt - 63x63	2310EUGLVA-884-11	1	piece
2CKA002099A0225	2399 UCKS-20 Cover Plates (partly incl. Insert) platinum	2399 UCKS-20	1	piece
2CKA002099A0226	2399 UCKS-21 Cover Plates (partly incl. Insert) bronze - alpha	2399 UCKS-21	1	piece
2CKA002099A0219	2399 UCKS-22G Cover Plates (partly incl. Insert) ivory	2399 UCKS-22G	1	piece
2CKA002099A0220	2399 UCKS-24G Cover Plates (partly incl. Insert) studio white - alpha	2399 UCKS-24G	1	piece
2CKA002099A0223	2399 UCKS-260 Cover Plates (partly incl. Insert) palladium	2399 UCKS-260	1	piece
2CKA002099A0224	2399 UCKS-266 Cover Plates (partly incl. Insert) titanium - alpha	2399 UCKS-266	1	piece
2CKA002099A0253	2399 UCKS-803 Cover Plates (partly incl. Insert) Safety Shutter grey metallic - 63x63	2399 UCKS-803	1	piece
2CKA002099A0216	2399 UCKS-81 Cover Plates (partly incl. Insert) Safety Shutter anthracite - 63x63	2399 UCKS-81	1	piece
2CKA002099A0211	2399 UCKS-82 Cover Plates (partly incl. Insert) Safety Shutter ivory white - 63x63	2399 UCKS-82	1	piece
2CKA002099A0191	2399 UCKS-82-505 Cover Plates (partly incl. Insert) Safety Shutter ivory white - 63x63	2399 UCKS-82-505	1	piece
2CKA002099A0241	2399 UCKS-83 Cover Plates (partly incl. Insert) Safety Shutter aluminium silver - 63x63	2399 UCKS-83	1	piece
2CKA002099A0243	2399 UCKS-866 Socket Safety Shutter stainless steel - Pure Stainless Steel	2399 UCKS-866	1	piece
2CKA002099A0255	2399 UCKS-884 Cover Plates (partly incl. Insert) Safety Shutter studio white matt - 63x63	2399 UCKS-884	1	piece
2CKA001719A0216	2518-WD-803 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring grey metallic - 63x63	2518-WD-803	1	piece
2CKA001719A0217	2518-WD-81 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring anthracite - 63x63	2518-WD-81	1	piece
2CKA001719A0218	2518-WD-82 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring ivory white - 63x63	2518-WD-82	1	piece
2CKA001719A0221	2518-WD-866 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring stainless steel - Pure Stainless Steel	2518-WD-866	1	piece
2CKA001719A0222	2518-WD-884 Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring studio white matt - 63x63	2518-WD-884	1	piece
2CKA001751A3175	2520 KI-803 Rocker with legend Switch/push button Single rocker Symbol "bell" grey metallic - 63x63	2520 KI-803	1	piece
2CKA001751A3176	2520 KI-81 Rocker with legend Switch/push button Single rocker Symbol "bell" anthracite - 63x63	2520 KI-81	1	piece
2CKA001751A3177	2520 KI-82 Rocker with legend Switch/push button Single rocker Symbol "bell" ivory white - 63x63	2520 KI-82	1	piece
2CKA001751A3178	2520 KI-83 Rocker with legend Switch/push button Single rocker Symbol "bell" aluminium silver - 63x63	2520 KI-83	1	piece

2CKA001751A3181	2520 KI-866 Rocker with legend Switch/push button Single rocker Symbol "bell" stainless steel - Pure Stainless Steel	2520 KI-866	1	piece
2CKA001751A3182	2520 KI-884 Rocker with legend Switch/push button Single rocker Symbol "bell" studio white matt - 63x63	2520 KI-884	1	piece
2CKA001751A3185	2520 LI-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 LI-803	1	piece
2CKA001751A3186	2520 LI-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 LI-81	1	piece
2CKA001751A3187	2520 LI-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 LI-82	1	piece
2CKA001751A3188	2520 LI-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 LI-83	1	piece
2CKA001751A3191	2520 LI-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3192	2520 LI-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 LI-884	1	piece
2CKA001751A3195	2520 TR-803 Rocker Switch/push button Single rocker grey metallic - 63x63	2520 TR-803	1	piece
2CKA001751A3196	2520 TR-81 Rocker Switch/push button Single rocker anthracite - 63x63	2520 TR-81	1	piece
2CKA001751A3197	2520 TR-82 Rocker Switch/push button Single rocker ivory white - 63x63	2520 TR-82	1	piece
2CKA001751A3198	2520 TR-83 Rocker Switch/push button Single rocker aluminium silver - 63x63	2520 TR-83	1	piece
2CKA001751A3200	2520 TR-866 Rocker Switch/push button Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	piece
2CKA001751A3201	2520 TR-884 Rocker Switch/push button Single rocker studio white matt - 63x63	2520 TR-884	1	piece
2CKA001724A4407	2533-803 Cover Plate Bore hole grey metallic - 63x63	2533-803	1	piece
2CKA001724A4254	2533-81 Cover Plate Bore hole 1 gang anthracite - 63x63	2533-81	1	piece
2CKA001724A4255	2533-82 Cover Plate Bore hole 1 gang ivory white - 63x63	2533-82	1	piece
2CKA001724A4261	2533-83 Cover Plate Bore hole 1 gang aluminium silver - 63x63	2533-83	1	piece
2CKA001724A4270	2533-866 Cover Plate Bore hole 1 gang stainless steel - Pure Stainless Steel	2533-866	1	piece
2CKA001724A4296	2533-884 Cover Plate Bore hole 1 gang studio white matt - 63x63	2533-884	1	piece
2CKA001710A3113	2542 DR/01-20 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" platinum - alpha	2542 DR/01-20	1	piece
2CKA001710A3114	2542 DR/01-21 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" bronze - alpha	2542 DR/01-21	1	piece
2CKA001710A3115	2542 DR/01-22G Cover Plate Level switch Turn button Symbol "0-1-2-3" ivory - alpha	2542 DR/01-22G	1	piece
2CKA001710A3117	2542 DR/01-24G Cover plate with legend Level switch Turn button Symbol "0-1-2-3" studio white - alpha	2542 DR/01-24G	1	piece
2CKA001710A3464	2542 DR/01-260 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" palladium - alpha	2542 DR/01-260	1	piece
2CKA001710A3466	2542 DR/01-266 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" titanium - alpha	2542 DR/01-266	1	piece
2CKA001710A4125	2542 DR/01-803 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" grey metallic - 63x63	2542 DR/01-803	1	piece
2CKA001710A3644	2542 DR/01-81 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" anthracite - 63x63	2542 DR/01-81	1	piece
2CKA001710A3645	2542 DR/01-82 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" ivory white - 63x63	2542 DR/01-82	1	piece
2CKA001710A3671	2542 DR/01-83 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" aluminium silver - 63x63	2542 DR/01-83	1	piece

2CKA001710A3758	2542 DR/01-866 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" stainless steel - Pure Stainless Steel	2542 DR/01-866	1	piece
2CKA001710A3890	2542 DR/01-884 Cover plate with legend Level switch Turn button Symbol "0-1-2-3" studio white matt - 63x63	2542 DR/01-884	1	piece
2CKA001710A3424	2542 DR/02-20 Cover plate with legend Level switch Turn button Symbol "1-2-3" platinum - alpha	2542 DR/02-20	1	piece
2CKA001710A3425	2542 DR/02-21 Cover plate with legend Level switch Turn button Symbol "1-2-3" bronze - alpha	2542 DR/02-21	1	piece
2CKA001710A3426	2542 DR/02-22G Cover plate with legend Level switch Turn button Symbol "1-2-3" ivory - alpha	2542 DR/02-22G	1	piece
2CKA001710A3428	2542 DR/02-24G Cover plate with legend Level switch Turn button Symbol "1-2-3" studio white - alpha	2542 DR/02-24G	1	piece
2CKA001710A3465	2542 DR/02-260 Cover plate with legend Level switch Turn button Symbol "1-2-3" palladium - alpha	2542 DR/02-260	1	piece
2CKA001710A3467	2542 DR/02-266 Cover plate with legend Level switch Turn button Symbol "1-2-3" titanium - alpha	2542 DR/02-266	1	piece
2CKA001710A4126	2542 DR/02-803 Cover plate with legend Level switch Turn button Symbol "1-2-3" grey metallic - 63x63	2542 DR/02-803	1	piece
2CKA001710A3649	2542 DR/02-81 Cover plate with legend Level switch Turn button Symbol "1-2-3" anthracite - 63x63	2542 DR/02-81	1	piece
2CKA001710A3650	2542 DR/02-82 Cover plate with legend Level switch Turn button Symbol "1-2-3" ivory white - 63x63	2542 DR/02-82	1	piece
2CKA001710A3672	2542 DR/02-83 Cover plate with legend Level switch Turn button Symbol "1-2-3" aluminium silver - 63x63	2542 DR/02-83	1	piece
2CKA001710A3759	2542 DR/02-866 Cover plate with legend Level switch Turn button Symbol "1-2-3" stainless steel - Pure Stainless Steel	2542 DR/02-866	1	piece
2CKA001710A3891	2542 DR/02-884 Cover plate with legend Level switch Turn button Symbol "1-2-3" studio white matt - 63x63	2542 DR/02-884	1	piece
2CKA001724A4398	2553-803 Cover Plate XLR grey metallic - 63x63	2553-803	1	piece
2CKA001724A4399	2553-81 Cover Plate XLR 1 gang anthracite - 63x63	2553-81	1	piece
2CKA001724A4400	2553-82 Cover Plate XLR 1 gang ivory white - 63x63	2553-82	1	piece
2CKA001724A4401	2553-83 Cover Plate XLR 1 gang aluminium silver - 63x63	2553-83	1	piece
2CKA001724A4403	2553-866 Cover Plate XLR 1 gang stainless steel - Pure Stainless Steel	2553-866	1	piece
2CKA001724A4404	2553-884 Cover Plate XLR 1 gang studio white matt - 63x63	2553-884	1	piece
2CKA001753A4047	2561-02-20 Cover Plate Modular Jack 2 gang platinum - alpha	2561-02-20	1	piece
2CKA001753A4054	2561-02-21 Cover Plate Modular Jack 2 gang bronze - alpha	2561-02-21	1	piece
2CKA001710A2512	2561-02-22G Cover Plate Modular Jack 2 gang ivory - alpha	2561-02-22G	1	piece
2CKA001753A7800	2561-02-24G Cover Plate Modular Jack 2 gang studio white - alpha	2561-02-24G	1	piece
2CKA001710A3315	2561-02-260 Cover Plate Modular Jack 2 gang palladium - alpha	2561-02-260	1	piece
2CKA001710A3341	2561-02-266 Cover Plate Modular Jack 2 gang titanium - alpha	2561-02-266	1	piece
2CKA001753A0316	2561-02-803 Cover Plate Modular Jack 2 gang grey metallic - 63x63	2561-02-803	1	piece
2CKA001753A0317	2561-02-81 Cover Plate Modular Jack 2 gang anthracite - 63x63	2561-02-81	1	piece
2CKA001753A0392	2561-02-82 Cover Plate Modular Jack ivory white - 63x63	2561-02-82	1	piece
2CKA001753A0393	2561-02-83 Cover Plate Modular Jack 2 gang aluminium silver - 63x63	2561-02-83	1	piece
2CKA001753A0396	2561-02-884 Cover Plate Modular Jack 2 gang studio white matt - 63x63	2561-02-884	1	piece

2CKA001753A3916	2561-20 Cover Plate Modular Jack 1 gang platinum - alpha	2561-20	1	piece
2CKA001753A3924	2561-21 Cover Plate Modular Jack 1 gang bronze - alpha	2561-21	1	piece
2CKA001710A2504	2561-22G Cover Plate Modular Jack 1 gang ivory - alpha	2561-22G	1	piece
2CKA001753A7776	2561-24G Cover Plate Modular Jack 1 gang studio white - alpha	2561-24G	1	piece
2CKA001710A3314	2561-260 Cover Plate Modular Jack 1 gang palladium - alpha	2561-260	1	piece
2CKA001710A3340	2561-266 Cover Plate Modular Jack 1 gang titanium - alpha	2561-266	1	piece
2CKA001753A0399	2561-803 Cover Plate Modular Jack 1 gang grey metallic - 63x63	2561-803	1	piece
2CKA001753A0400	2561-81 Cover Plate Modular Jack 1 gang anthracite - 63x63	2561-81	1	piece
2CKA001753A0401	2561-82 Cover Plate Modular Jack 1 gang ivory white - 63x63	2561-82	1	piece
2CKA001753A0402	2561-83 Cover Plate Modular Jack 1 gang aluminium silver - 63x63	2561-83	1	piece
2CKA001753A0404	2561-866 Cover Plate Modular Jack 1 gang stainless steel - Pure Stainless Steel	2561-866	1	piece
2CKA001753A0405	2561-884 Cover Plate Modular Jack 1 gang studio white matt - 63x63	2561-884	1	piece
2CKA003116A0666	3120 EUCB-803 Socket insert FI-Schukomat Protective Contact (SCHUKO) 30 mA grey metallic - 63x63	3120 EUCB- 803	1	piece
2CKA003116A0667	3120 EUCB-81 Socket insert FI-Schukomat Protective Contact (SCHUKO) 30 mA anthracite - 63x63	3120 EUCB-81	1	piece
2CKA003116A0661	3120 EUCB-82 FI-Schukomat Socket insert Protective Contact (SCHUKO) Safety Shutter ivory white - 63x63	3120 EUCB-82	1	piece
2CKA003116A0668	3120 EUCB-83 Socket insert FI-Schukomat Protective Contact (SCHUKO) 30 mA aluminium silver - 63x63	3120 EUCB-83	1	piece
2CKA003116A0669	3120 EUCB-866 FI-Schukomat Socket insert Protective Contact (SCHUKO) Safety Shutter stainless steel - Pure Stainless Steel	3120 EUCB- 866	1	piece
2CKA003116A0670	3120 EUCB-884 FI-Schukomat Socket insert Protective Contact (SCHUKO) Safety Shutter studio white matt - 63x63	3120 EUCB- 884	1	piece
2CKA003117A0008	3151 UC-803 RCD - Insert Buschmat RCD 30 mA grey metallic - 63x63	3151 UC-803	1	piece
2CKA003117A0009	3151 UC-81 RCD - Insert Buschmat RCD 30 mA anthracite - 63x63	3151 UC-81	1	piece
2CKA003117A0005	3151 UC-82 RCD - Insert Buschmat RCD 30 mA ivory white - 63x63	3151 UC-82	1	piece
2CKA003117A0010	3151 UC-83 RCD - Insert Buschmat RCD 30 mA aluminium silver - 63x63	3151 UC-83	1	piece
2CKA003117A0011	3151 UC-866 RCD - Insert Buschmat RCD 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	piece
2CKA003117A0012	3151 UC-884 RCD - Insert Buschmat RCD 30 mA studio white matt - 63x63	3151 UC-884	1	piece
2CKA006115A0489	6108/61-803-500 Coverplate f. CE	6108/61-803- 500	1	piece
2CKA006115A0483	6108/61-81-500 Coverplate f. CE	6108/61-81- 500	1	piece
2CKA006115A0484	6108/61-82-500 Coverplate f. CE	6108/61-82- 500	1	piece
2CKA006115A0485	6108/61-83-500 Coverplate f. CE	6108/61-83- 500	1	piece
2CKA006155A0121	6108/61-840-500 Coverplate f. CE	6108/61-840- 500	1	piece
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866- 500	1	piece
2CKA006115A0487	6108/61-884-500 Coverplate f. CE	6108/61-884- 500	1	piece
2CKA006155A0066	6109/03-803-500 Coverplate f. RTC	6109/03-803- 500	1	piece

2CKA006155A0060	6109/03-81-500 Coverplate f. RTC	6109/03-81-500	1	piece
2CKA006155A0061	6109/03-82-500 Coverplate f. RTC	6109/03-82-500	1	piece
2CKA006155A0062	6109/03-83-500 Coverplate f. RTC	6109/03-83-500	1	piece
2CKA006155A0114	6109/03-840-500 Coverplate f. RTC	6109/03-840-500	1	piece
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	piece
2CKA006155A0064	6109/03-884-500 Coverplate f. RTC	6109/03-884-500	1	piece
2CKA006132A0382	6122/10-803-500 BW standard	6122/10-803-500	1	piece
2CKA006132A0376	6122/10-81-500 BW standard	6122/10-81-500	1	piece
2CKA006132A0377	6122/10-82-500 BW standard	6122/10-82-500	1	piece
2CKA006132A0378	6122/10-83-500 BW standard	6122/10-83-500	1	piece
2CKA006132A0407	6122/10-840-500 BW standard	6122/10-840-500	1	piece
2CKA006132A0385	6122/10-866-500 BW standard	6122/10-866-500	1	piece
2CKA006132A0380	6122/10-884-500 BW standard	6122/10-884-500	1	piece
2CKA006115A0212	6125/01-803-500 Control element 1g w. BAU	6125/01-803-500	1	piece
2CKA006115A0205	6125/01-81-500 Control element 1g w. BAU	6125/01-81-500	1	piece
2CKA006115A0206	6125/01-82-500 Control element 1g w. BAU	6125/01-82-500	1	piece
2CKA006115A0207	6125/01-83-500 Control element 1g w. BAU	6125/01-83-500	1	piece
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	piece
2CKA006115A0214	6125/01-884-500 Control element 1g w. BAU	6125/01-884-500	1	piece
2CKA006115A0224	6125/02-803-500 Control element 1/2gang	6125/02-803-500	1	piece
2CKA006115A0216	6125/02-81-500 Control element 1/2gang	6125/02-81-500	1	piece
2CKA006115A0217	6125/02-82-500 Control element 1/2gang	6125/02-82-500	1	piece
2CKA006115A0218	6125/02-83-500 Control element 1/2gang	6125/02-83-500	1	piece
2CKA006115A0452	6125/02-840-500 cont.-element KNX 1g	6125/02-840-500	1	piece
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	piece
2CKA006115A0226	6125/02-884-500 Control element 1/2gang	6125/02-884-500	1	piece
2CKA006116A0202	6126/01-803-500 Control element 2g w. BAU	6126/01-803-500	1	piece
2CKA006116A0195	6126/01-81-500 Control element 2g w. BAU	6126/01-81-500	1	piece
2CKA006116A0196	6126/01-82-500 Control element 2g w. BAU	6126/01-82-500	1	piece
2CKA006116A0197	6126/01-83-500 Control element 2g w. BAU	6126/01-83-500	1	piece
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	piece
2CKA006116A0204	6126/01-884-500 Control element 2g w. BAU	6126/01-884-500	1	piece
2CKA006116A0214	6126/02-803-500 Control element 2/4gang	6126/02-803-500	1	piece
2CKA006116A0206	6126/02-81-500 Control element 2/4gang	6126/02-81-500	1	piece
2CKA006116A0207	6126/02-82-500 Control element 2/4gang	6126/02-82-500	1	piece

2CKA006116A0208	6126/02-83-500 Control element 2/4gang	6126/02-83-500	1	piece
2CKA006116A0227	6126/02-840-500 cont.-element KNX 2g	6126/02-840-500	1	piece
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	piece
2CKA006116A0216	6126/02-884-500 Control element 2/4gang	6126/02-884-500	1	piece
2CKA006117A0228	6127/01-803-500 Control element 4g w. BAU	6127/01-803-500	1	piece
2CKA006117A0221	6127/01-81-500 Control element 4g w. BAU	6127/01-81-500	1	piece
2CKA006117A0222	6127/01-82-500 Control element 4g w. BAU	6127/01-82-500	1	piece
2CKA006117A0223	6127/01-83-500 Control element 4g w. BAU	6127/01-83-500	1	piece
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	piece
2CKA006117A0230	6127/01-884-500 Control element 4g w. BAU	6127/01-884-500	1	piece
2CKA006117A0240	6127/02-803-500 Control element 4/8gang	6127/02-803-500	1	piece
2CKA006117A0232	6127/02-81-500 Control element 4/8gang	6127/02-81-500	1	piece
2CKA006117A0233	6127/02-82-500 Control element 4/8gang	6127/02-82-500	1	piece
2CKA006117A0234	6127/02-83-500 Control element 4/8gang	6127/02-83-500	1	piece
2CKA006117A0252	6127/02-840-500 cont.-element KNX 4g	6127/02-840-500	1	piece
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	piece
2CKA006117A0242	6127/02-884-500 Control element 4/8gang	6127/02-884-500	1	piece
2CKA006134A0336	6128/28-803-500 RTC Control element 2/4g	6128/28-803-500	1	piece
2CKA006134A0331	6128/28-81-500 RTC Control element 2/4g	6128/28-81-500	1	piece
2CKA006134A0332	6128/28-82-500 RTC Control element 2/4g	6128/28-82-500	1	piece
2CKA006134A0333	6128/28-83-500 RTC Control element 2/4g	6128/28-83-500	1	piece
2CKA006134A0342	6128/28-840-500 RTC Control element 2/4g	6128/28-840-500	1	piece
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	piece
2CKA006134A0338	6128/28-884-500 RTC Control element 2/4g	6128/28-884-500	1	piece
2CKA006135A0163	6129/01-803-500 Control element 3/6g w. IR	6129/01-803-500	1	piece
2CKA006135A0156	6129/01-81-500 Control element 3/6g w. IR	6129/01-81-500	1	piece
2CKA006135A0157	6129/01-82-500 Control element 3/6g w. IR	6129/01-82-500	1	piece
2CKA006135A0158	6129/01-83-500 Control element 3/6g w. IR	6129/01-83-500	1	piece
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	piece
2CKA006135A0165	6129/01-884-500 Control element 3/6g w. IR	6129/01-884-500	1	piece
2CKA006430A0319	6430-20-102 Control Element for Venetian blind Single push button platinum - alpha	6430-20-102	1	piece
2CKA006430A0320	6430-21-102 Control Element for Venetian blind Single push button bronze - alpha	6430-21-102	1	piece
2CKA006430A0321	6430-22G-102 Control Element for Venetian blind Single push button ivory - alpha	6430-22G-102	1	piece
2CKA006430A0323	6430-24G-102 Control Element for Venetian blind Single push button studio white - alpha	6430-24G-102	1	piece
2CKA006430A0317	6430-260-102 Control Element for Venetian blind Single push button palladium - alpha	6430-260-102	1	piece

2CKA006430A0318	6430-266-102 Control Element for Venetian blind Single push button titanium - alpha	6430-266-102	1	piece
2CKA006430A0350	6430-803-102 Control Element for Venetian blind grey metallic - 63x63	6430-803-102	1	piece
2CKA006430A0326	6430-81-102 Control Element for Venetian blind anthracite - 63x63	6430-81-102	1	piece
2CKA006430A0327	6430-82-102 Control Element for Venetian blind ivory white - 63x63	6430-82-102	1	piece
2CKA006430A0328	6430-83-102 Control Element for Venetian blind aluminium silver - 63x63	6430-83-102	1	piece
2CKA006430A0407	6430-840-102-500 cont.-element blinds	6430-840-102-500	1	piece
2CKA006430A0343	6430-866-102 Control Element for Venetian blind stainless steel - Pure Stainless Steel	6430-866-102	1	piece
2CKA006430A0385	6430-884-102 Control Element for Venetian blind studio white matt - 63x63	6430-884-102	1	piece
2CKA006430A0291	6435-20 Cover plate with legend for Time switch platinum - alpha	6435-20	1	piece
2CKA006430A0292	6435-21 Cover plate with legend for Time switch bronze - alpha	6435-21	1	piece
2CKA006430A0293	6435-22G Cover plate with legend for Time switch ivory - alpha	6435-22G	1	piece
2CKA006430A0295	6435-24G Cover plate with legend for Time switch studio white - alpha	6435-24G	1	piece
2CKA006430A0289	6435-260 Cover plate with legend for Time switch palladium - alpha	6435-260	1	piece
2CKA006430A0290	6435-266 Cover plate with legend for Time switch titanium - alpha	6435-266	1	piece
2CKA006430A0351	6435-803 Cover plate with legend for Time switch grey metallic - 63x63	6435-803	1	piece
2CKA006430A0303	6435-81 Cover plate with legend for Time switch anthracite - 63x63	6435-81	1	piece
2CKA006430A0304	6435-82 Cover plate with legend for Time switch ivory white - 63x63	6435-82	1	piece
2CKA006430A0305	6435-83 Cover plate with legend for Time switch aluminium silver - 63x63	6435-83	1	piece
2CKA006430A0405	6435-840-500 Cover Plates (partly incl. Insert) for Time switch antique brass - 63x63	6435-840-500	1	piece
2CKA006430A0344	6435-866 Cover plate with legend for Time switch stainless steel - Pure Stainless Steel	6435-866	1	piece
2CKA006430A0388	6435-884 Cover plate with legend for Time switch studio white matt - 63x63	6435-884	1	piece
2CKA006470A0006	6476-803 Cover Plate for Proximity switch grey metallic - 63x63	6476-803	1	piece
2CKA006470A0007	6476-81 Cover Plate for Proximity switch anthracite - 63x63	6476-81	1	piece
2CKA006470A0003	6476-82 Cover Plate for Proximity switch ivory white - 63x63	6476-82	1	piece
2CKA006470A0008	6476-83 Cover Plate for Proximity switch aluminium silver - 63x63	6476-83	1	piece
2CKA006470A0009	6476-866 Cover Plate for Proximity switch stainless steel - Pure Stainless Steel	6476-866	1	piece
2CKA006470A0010	6476-884 Cover Plate for Proximity switch studio white matt - 63x63	6476-884	1	piece
2CKA006400A0060	6477-803 Cover Plate PowerDock 1 gang grey metallic	6477-803	1	piece
2CKA006400A0056	6477-81 Cover Plate PowerDock 1 gang anthracite - 63x63	6477-81	1	piece
2CKA006400A0057	6477-82 Cover Plate PowerDock 1 gang white	6477-82	1	piece
2CKA006400A0058	6477-83 Cover Plate PowerDock 1 gang aluminium silver - 63x63	6477-83	1	piece
2CKA006400A0061	6477-840-500 Accessories USB antique brass - 63x63	6477-840-500	1	piece
2CKA006400A0064	6477-866 Cover Plate PowerDock 1 gang stainless steel - Pure Stainless Steel	6477-866	1	piece
2CKA006400A0062	6477-884 Cover Plate PowerDock 1 gang studio white matt - 63x63	6477-884	1	piece
2CKA006599A1458	6540-20 Cover Plate for Dimmer Turn button platinum - alpha	6540-20	1	piece

2CKA006599A1490	6540-21 Cover Plate for Dimmer Turn button bronze - alpha	6540-21	1	piece
2CKA006599A2324	6540-24G Cover Plate for Dimmer Turn button studio white - alpha	6540-24G	1	piece
2CKA006599A2852	6540-260 Cover Plate for Dimmer Turn button palladium - alpha	6540-260	1	piece
2CKA006599A2855	6540-266 Cover Plate for Dimmer Turn button titanium - alpha	6540-266	1	piece
2CKA006599A2980	6540-803-102 Cover Plate for Dimmer Turn button with Neon lamp grey metallic - 63x63	6540-803-102	1	piece
2CKA006599A2950	6540-81-102 Cover Plate for Dimmer Turn button with Neon lamp anthracite - 63x63	6540-81-102	1	piece
2CKA006599A2951	6540-82-102 Cover Plate for Dimmer Turn button with Neon lamp ivory white - 63x63	6540-82-102	1	piece
2CKA006599A2952	6540-83-102 Cover Plate for Dimmer Turn button with Neon lamp aluminium silver - 63x63	6540-83-102	1	piece
2CKA006599A3022	6540-840-102-500 Cover Plates (partly incl. Insert) for Dimmer Turn button antique brass - 63x63	6540-840-102- 500	1	piece
2CKA006599A2959	6540-866-102 Cover Plate for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel	6540-866-102	1	piece
2CKA006599A2961	6540-884-102 Cover Plate for Dimmer Turn button with Neon lamp studio white matt - 63x63	6540-884-102	1	piece
2CKA006599A1466	6541-20 Cover Plate for Cooling Central cover plate platinum - alpha	6541-20	1	piece
2CKA006599A1524	6541-21 Cover Plate for Cooling Central cover plate bronze - alpha	6541-21	1	piece
2CKA006599A2795	6541-22G Cover Plate for Cooling Central cover plate ivory - alpha	6541-22G	1	piece
2CKA006599A2332	6541-24G Cover Plate for Cooling Central cover plate studio white - alpha	6541-24G	1	piece
2CKA006599A2853	6541-260 Cover Plate for Cooling Central cover plate palladium - alpha	6541-260	1	piece
2CKA006599A2856	6541-266 Cover Plate for Cooling Central cover plate titanium - alpha	6541-266	1	piece
2CKA006599A2882	6541-81 Cover Plate for Cooling Central cover plate anthracite - 63x63	6541-81	1	piece
2CKA006599A2832	6541-82 Cover Plate for Cooling Central cover plate ivory white - 63x63	6541-82	1	piece
2CKA006599A2885	6541-83 Cover Plate for Cooling Central cover plate aluminium silver - 63x63	6541-83	1	piece
2CKA006599A2924	6541-866 Cover Plate for Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	piece
2CKA006599A2962	6541-884 Cover Plate for Cooling Central cover plate studio white matt - 63x63	6541-884	1	piece
2CKA006599A2820	6543-20-102 Control Element for Switch/dimmer Single push button with Neon lamp platinum - alpha	6543-20-102	1	piece
2CKA006599A2821	6543-21-102 Control Element for Switch/dimmer Single push button with Neon lamp bronze - alpha	6543-21-102	1	piece
2CKA006599A2822	6543-22G-102 Control Element for Switch/dimmer Single push button with Neon lamp ivory - alpha	6543-22G-102	1	piece
2CKA006599A2824	6543-24G-102 Control Element for Switch/dimmer Single push button with Neon lamp studio white - alpha	6543-24G-102	1	piece
2CKA006599A2869	6543-260-102 Control Element for Switch/dimmer Single push button with Neon lamp palladium - alpha	6543-260-102	1	piece
2CKA006599A2870	6543-266-102 Control Element for Switch/dimmer Single push button with Neon lamp titanium - alpha	6543-266-102	1	piece
2CKA006599A2881	6543-81-101 Control Element for Switch/dimmer Single push button anthracite - 63x63	6543-81-101	1	piece
2CKA006599A2831	6543-82-101 Control Element for Switch/dimmer Single push button ivory white - 63x63	6543-82-101	1	piece
2CKA006599A2887	6543-83-101 Control Element for Switch/dimmer Single push button aluminium silver - 63x63	6543-83-101	1	piece
2CKA006599A3023	6543-840-101-500 Cover Plates (partly incl. Insert) for Switch/dimmer Single push button antique brass - 63x63	6543-840-101- 500	1	piece

2CKA006599A2926	6543-866-101 Control Element for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006599A2963	6543-884-101 Control Element for Switch/dimmer Single push button studio white matt - 63x63	6543-884-101	1	piece
2CKA006599A2890	6545-20 Control Element for Dimmer Two-part button with Neon lamp platinum - alpha	6545-20	1	piece
2CKA006599A2891	6545-21 Control Element for Dimmer Two-part button with Neon lamp bronze - alpha	6545-21	1	piece
2CKA006599A2892	6545-22G Control Element for Dimmer Two-part button with Neon lamp ivory - alpha	6545-22G	1	piece
2CKA006599A2894	6545-24G Control Element for Dimmer Two-part button with Neon lamp studio white - alpha	6545-24G	1	piece
2CKA006599A2899	6545-260 Control Element for Dimmer Two-part button with Neon lamp palladium - alpha	6545-260	1	piece
2CKA006599A2900	6545-266 Control Element for Dimmer Two-part button with Neon lamp titanium - alpha	6545-266	1	piece
2CKA006599A2943	6545-803 Control Element for Dimmer Two-part button with Neon lamp grey metallic - 63x63	6545-803	1	piece
2CKA006599A2906	6545-81 Control Element for Dimmer Two-part button with Neon lamp anthracite - 63x63	6545-81	1	piece
2CKA006599A2907	6545-82 Control Element for Dimmer Two-part button with Neon lamp ivory white - 63x63	6545-82	1	piece
2CKA006599A2914	6545-83 Control Element for Dimmer Two-part button with Neon lamp aluminium silver - 63x63	6545-83	1	piece
2CKA006599A3024	6545-840-500 Cover Plates (partly incl. Insert) for Dimmer Two-part button antique brass - 63x63	6545-840-500	1	piece
2CKA006599A2927	6545-866 Control Element for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	piece
2CKA006599A2964	6545-884 Control Element for Dimmer Two-part button with Neon lamp studio white matt - 63x63	6545-884	1	piece
2CKA006730A0032	6731-82-500 Cover Plates (partly incl. Insert) 1 channel ivory white - 63x63Radio Control	6731-82-500	1	piece
2CKA006730A0035	6731-83-500 Cover Plates (partly incl. Insert) 1 channel aluminium silver - 63x63Radio Control	6731-83-500	1	piece
2CKA006730A0094	6731-840-500 cont.-element WaveL 1g	6731-840-500	1	piece
2CKA006730A0041	6731-866-500 WaveLine Cover Plates (partly incl. Insert) 1 channel stainless steel - Pure Stainless SteelRadio Control	6731-866-500	1	piece
2CKA006730A0033	6732-82-500 Cover Plates (partly incl. Insert) 2 channel ivory white - 63x63Radio Control	6732-82-500	1	piece
2CKA006730A0036	6732-83-500 Cover Plates (partly incl. Insert) 2 channel aluminium silver - 63x63Radio Control	6732-83-500	1	piece
2CKA006730A0095	6732-840-500 cont.-element WaveL 2g	6732-840-500	1	piece
2CKA006730A0042	6732-866-500 Wall sensor 2 channel stainless steel - Pure Stainless SteelRadio Control	6732-866-500	1	piece
2CKA006730A0034	6733-82-500 Cover Plates (partly incl. Insert) 4 channel ivory white - 63x63Radio Control	6733-82-500	1	piece
2CKA006730A0037	6733-83-500 Cover Plates (partly incl. Insert) 4 channel aluminium silver - 63x63Radio Control	6733-83-500	1	piece
2CKA006730A0043	6733-866-500 Cover Plates (partly incl. Insert) 4 channel stainless steel - Pure Stainless SteelRadio Control	6733-866-500	1	piece
2CKA006730A0137	6736 FoH-803 Control Element for Switch/dimmer Two-part button grey metallic	6736 FoH-803	1	piece
2CKA006730A0133	6736 FoH-81 Control Element for Switch/dimmer Two-part button anthracite - 63x63	6736 FoH-81	1	piece
2CKA006730A0134	6736 FoH-82 Control Element for Switch/dimmer Two-part button beige	6736 FoH-82	1	piece
2CKA006730A0135	6736 FoH-83 Control Element for Switch/dimmer Two-part button aluminium silver - 63x63	6736 FoH-83	1	piece
2CKA006730A0138	6736 FoH-840-500 Cover Plates (partly incl. Insert) for Switch/dimmer Single rocker brass - 63x63	6736 FoH-840- 500	1	piece
2CKA006730A0139	6736 FoH-866 Control Element for Switch/dimmer Two-part button stainless steel - Pure Stainless Steel	6736 FoH-866	1	piece
2CKA006730A0140	6736 FoH-884 Control Element for Switch/dimmer Two-part button studio white matt - 63x63	6736 FoH-884	1	piece

2CKA006800A2828	6815-81-101-500 Cover Plates (partly incl. Insert) Movement sensor anthracite - 63x63	6815-81-101-500	1	piece
2CKA006800A2830	6815-82-101-500 Cover Plates (partly incl. Insert) ivory white	6815-82-101-500	1	piece
2CKA006800A2832	6815-83-101-500 Cover Plates (partly incl. Insert) aluminium silver - 63x63	6815-83-101-500	1	piece
2CKA006800A2843	6815-866-101-500 Cover Plates (partly incl. Insert) stainless steel - Pure Stainless Steel	6815-866-101-500	1	piece
2CKA008200A0093	8253-20 Cover Plate Loudspeaker platinum - alpha	8253-20	1	piece
2CKA008200A0094	8253-21 Cover Plate Loudspeaker bronze - alpha	8253-21	1	piece
2CKA008200A0095	8253-22G Cover Plate Loudspeaker white - alpha	8253-22G	1	piece
2CKA008200A0097	8253-24G Cover Plate Loudspeaker white - alpha	8253-24G	1	piece
2CKA008200A0102	8253-260 Cover Plate Loudspeaker palladium - alpha	8253-260	1	piece
2CKA008200A0103	8253-266 Cover Plate Loudspeaker titanium - alpha	8253-266	1	piece
2CKA008200A0115	8253-803 Cover Plate Loudspeaker grey metallic - 63x63	8253-803	1	piece
2CKA008200A0078	8253-81 Cover Plate Loudspeaker anthracite - 63x63	8253-81	1	piece
2CKA008200A0079	8253-82 Cover Plate Loudspeaker ivory white - 63x63	8253-82	1	piece
2CKA008200A0080	8253-83 Cover Plate Loudspeaker aluminium silver - 63x63	8253-83	1	piece
2CKA008200A0191	8253-840-500 Cover Plates (partly incl. Insert) antique brass - 63x63	8253-840-500	1	piece
2CKA008200A0087	8253-866 Cover Plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	piece
2CKA008200A0123	8253-884 Cover Plate Loudspeaker studio white matt - 63x63	8253-884	1	piece
2CKA006220A0566	CP-FCC-803 C-plate Fan Coil	CP-FCC-803	1	piece
2CKA006220A0242	CP-FCC-81 C-plate Fan Coil	CP-FCC-81	1	piece
2CKA006220A0532	CP-FCC-82 C-plate Fan Coil	CP-FCC-82	1	piece
2CKA006220A0243	CP-FCC-83 C-plate Fan Coil	CP-FCC-83	1	piece
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	piece
2CKA006220A0617	CP-FCC-884 C-plate Fan Coil	CP-FCC-884	1	piece
2CKA006220A0563	CP-RTC-803 C-plate RT sensor unit	CP-RTC-803	1	piece
2CKA006220A0179	CP-RTC-81 C-plate RT sensor unit	CP-RTC-81	1	piece
2CKA006220A0529	CP-RTC-82 C-plate RT sensor unit	CP-RTC-82	1	piece
2CKA006220A0180	CP-RTC-83 C-plate RT sensor unit	CP-RTC-83	1	piece
2CKA006220A0384	CP-RTC-840 c-plate temp.	CP-RTC-840	1	piece
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	piece
2CKA006220A0614	CP-RTC-884 C-plate RT sensor unit	CP-RTC-884	1	piece
2CKA006220A0564	MD-F-1.0.1-803 Movement detector	MD-F-1.0.1-803	1	piece
2CKA006220A0212	MD-F-1.0.1-81 Movement detector	MD-F-1.0.1-81	1	piece
2CKA006220A0530	MD-F-1.0.1-82 Movement detector	MD-F-1.0.1-82	1	piece
2CKA006220A0213	MD-F-1.0.1-83 Movement detector	MD-F-1.0.1-83	1	piece
2CKA006220A0385	MD-F-1.0.1-840 WD 180 sens	MD-F-1.0.1-840	1	piece
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	piece
2CKA006220A0615	MD-F-1.0.1-884 Movement detector	MD-F-1.0.1-884	1	piece
2CKA006220A0565	MSA-F-1.1.1-803 Mov. detector/actuator 1g	MSA-F-1.1.1-803	1	piece
2CKA006220A0215	MSA-F-1.1.1-81 Mov. detector/actuator 1g	MSA-F-1.1.1-81	1	piece
2CKA006200A0083	MSA-F-1.1.1-81-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-81-WL	1	piece
2CKA006200A0084	MSA-F-1.1.1-82-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-82-WL	1	piece
2CKA006220A0216	MSA-F-1.1.1-83 Mov. detector/actuator 1g	MSA-F-1.1.1-83	1	piece
2CKA006200A0085	MSA-F-1.1.1-83-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-83-WL	1	piece

2CKA006220A0386	MSA-F-1.1.1-840 WD 180 sens actuator	MSA-F-1.1.1-840	1	piece
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	piece
2CKA006220A0616	MSA-F-1.1.1-884 Mov. detector/actuator 1g	MSA-F-1.1.1-884	1	piece
2CKA006200A0097	MSA-F-1.1.1-884-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-884-WL	1	piece
2CKA006220A0550	SR-1-803 Solo free@home grey metallic - 63x63	SR-1-803	1	piece
2CKA006220A0137	SR-1-81 Solo free@home anthracite - 63x63	SR-1-81	1	piece
2CKA006220A0516	SR-1-82 Solo free@home ivory white - solo	SR-1-82	1	piece
2CKA006220A0138	SR-1-83 Solo free@home aluminium silver - 63x63	SR-1-83	1	piece
2CKA006220A0371	SR-1-840 Solo free@home antique brass - 63x63	SR-1-840	1	piece
2CKA006220A0533	SR-1-866 Solo free@home stainless steel - solo	SR-1-866	1	piece
2CKA006220A0601	SR-1-884 Solo free@home studio white matt - 63x63	SR-1-884	1	piece
2CKA006220A0555	SR-2-803 Solo free@home grey metallic - 63x63	SR-2-803	1	piece
2CKA006220A0152	SR-2-81 Solo free@home anthracite - 63x63	SR-2-81	1	piece
2CKA006220A0521	SR-2-82 Solo free@home ivory white - solo	SR-2-82	1	piece
2CKA006220A0153	SR-2-83 Solo free@home aluminium silver - 63x63	SR-2-83	1	piece
2CKA006220A0376	SR-2-840 Solo free@home antique brass - 63x63	SR-2-840	1	piece
2CKA006220A0538	SR-2-866 Solo free@home stainless steel - solo	SR-2-866	1	piece
2CKA006220A0606	SR-2-884 Solo free@home studio white matt - 63x63	SR-2-884	1	piece
2CKA006220A0552	SRB-1-803 Solo free@home grey metallic - 63x63	SRB-1-803	1	piece
2CKA006220A0143	SRB-1-81 Solo free@home anthracite - 63x63	SRB-1-81	1	piece
2CKA006220A0518	SRB-1-82 Solo free@home ivory white - solo	SRB-1-82	1	piece
2CKA006220A0144	SRB-1-83 Solo free@home aluminium silver - 63x63	SRB-1-83	1	piece
2CKA006220A0373	SRB-1-840 Solo free@home antique brass - 63x63	SRB-1-840	1	piece
2CKA006220A0535	SRB-1-866 Solo free@home stainless steel - solo	SRB-1-866	1	piece
2CKA006220A0603	SRB-1-884 Solo free@home studio white matt - 63x63	SRB-1-884	1	piece
2CKA006220A0557	SRB-2-803 Solo free@home grey metallic - 63x63	SRB-2-803	1	piece
2CKA006220A0158	SRB-2-81 Solo free@home anthracite - 63x63	SRB-2-81	1	piece
2CKA006220A0523	SRB-2-82 Solo free@home ivory white - solo	SRB-2-82	1	piece
2CKA006220A0159	SRB-2-83 Solo free@home aluminium silver - 63x63	SRB-2-83	1	piece
2CKA006220A0378	SRB-2-840 Solo free@home antique brass - 63x63	SRB-2-840	1	piece
2CKA006220A0540	SRB-2-866 Solo free@home stainless steel - solo	SRB-2-866	1	piece
2CKA006220A0608	SRB-2-884 Solo free@home studio white matt - 63x63	SRB-2-884	1	piece
2CKA006220A0554	SRD-1-803 Solo free@home grey metallic - 63x63	SRD-1-803	1	piece
2CKA006220A0149	SRD-1-81 Solo free@home anthracite - 63x63	SRD-1-81	1	piece
2CKA006220A0520	SRD-1-82 Solo free@home ivory white - solo	SRD-1-82	1	piece
2CKA006220A0150	SRD-1-83 Solo free@home aluminium silver - 63x63	SRD-1-83	1	piece
2CKA006220A0375	SRD-1-840 Solo free@home antique brass - 63x63	SRD-1-840	1	piece
2CKA006220A0537	SRD-1-866 Solo free@home stainless steel - solo	SRD-1-866	1	piece
2CKA006220A0605	SRD-1-884 Solo free@home studio white matt - 63x63	SRD-1-884	1	piece
2CKA006220A0559	SRD-2-L-803 Solo free@home grey metallic - 63x63	SRD-2-L-803	1	piece
2CKA006220A0164	SRD-2-L-81 Solo free@home anthracite - 63x63	SRD-2-L-81	1	piece
2CKA006220A0525	SRD-2-L-82 Solo free@home ivory white - solo	SRD-2-L-82	1	piece
2CKA006220A0165	SRD-2-L-83 Solo free@home aluminium silver - 63x63	SRD-2-L-83	1	piece
2CKA006220A0380	SRD-2-L-840 Solo free@home antique brass - 63x63	SRD-2-L-840	1	piece

2CKA006220A0542	SRD-2-L-866 Solo free@home stainless steel - solo	SRD-2-L-866	1	piece
2CKA006220A0610	SRD-2-L-884 Solo free@home studio white matt - 63x63	SRD-2-L-884	1	piece
2CKA006220A0560	SRD-2-R-803 Solo free@home grey metallic - 63x63	SRD-2-R-803	1	piece
2CKA006220A0258	SRD-2-R-81 Solo free@home anthracite - 63x63	SRD-2-R-81	1	piece
2CKA006220A0526	SRD-2-R-82 Solo free@home ivory white - solo	SRD-2-R-82	1	piece
2CKA006220A0259	SRD-2-R-83 Solo free@home aluminium silver - 63x63	SRD-2-R-83	1	piece
2CKA006220A0383	SRD-2-R-840 Solo free@home antique brass - 63x63	SRD-2-R-840	1	piece
2CKA006220A0543	SRD-2-R-866 Solo free@home stainless steel - solo	SRD-2-R-866	1	piece
2CKA006220A0611	SRD-2-R-884 Solo free@home studio white matt - 63x63	SRD-2-R-884	1	piece
2CKA006220A0551	SRL-1-803 Solo free@home grey metallic - 63x63	SRL-1-803	1	piece
2CKA006220A0140	SRL-1-81 Solo free@home anthracite - 63x63	SRL-1-81	1	piece
2CKA006220A0517	SRL-1-82 Solo free@home ivory white - solo	SRL-1-82	1	piece
2CKA006220A0141	SRL-1-83 Solo free@home aluminium silver - 63x63	SRL-1-83	1	piece
2CKA006220A0372	SRL-1-840 Solo free@home antique brass - 63x63	SRL-1-840	1	piece
2CKA006220A0534	SRL-1-866 Solo free@home stainless steel - solo	SRL-1-866	1	piece
2CKA006220A0602	SRL-1-884 Solo free@home studio white matt - 63x63	SRL-1-884	1	piece
2CKA006220A0556	SRL-2-L-803 Solo free@home grey metallic - 63x63	SRL-2-L-803	1	piece
2CKA006220A0155	SRL-2-L-81 Solo free@home anthracite - 63x63	SRL-2-L-81	1	piece
2CKA006220A0522	SRL-2-L-82 Solo free@home ivory white - solo	SRL-2-L-82	1	piece
2CKA006220A0156	SRL-2-L-83 Solo free@home aluminium silver - 63x63	SRL-2-L-83	1	piece
2CKA006220A0377	SRL-2-L-840 Solo free@home antique brass - 63x63	SRL-2-L-840	1	piece
2CKA006220A0539	SRL-2-L-866 Solo free@home stainless steel - solo	SRL-2-L-866	1	piece
2CKA006220A0607	SRL-2-L-884 Solo free@home studio white matt - 63x63	SRL-2-L-884	1	piece
2CKA006220A0561	SRL-2-R-803 Solo free@home grey metallic - 63x63	SRL-2-R-803	1	piece
2CKA006220A0167	SRL-2-R-81 Solo free@home anthracite - 63x63	SRL-2-R-81	1	piece
2CKA006220A0527	SRL-2-R-82 Solo free@home ivory white - solo	SRL-2-R-82	1	piece
2CKA006220A0168	SRL-2-R-83 Solo free@home aluminium silver - 63x63	SRL-2-R-83	1	piece
2CKA006220A0381	SRL-2-R-840 Solo free@home antique brass - 63x63	SRL-2-R-840	1	piece
2CKA006220A0544	SRL-2-R-866 Solo free@home stainless steel - solo	SRL-2-R-866	1	piece
2CKA006220A0612	SRL-2-R-884 Solo free@home studio white matt - 63x63	SRL-2-R-884	1	piece
2CKA006220A0553	SRS-1-803 Solo free@home grey metallic - 63x63	SRS-1-803	1	piece
2CKA006220A0146	SRS-1-81 Solo free@home anthracite - 63x63	SRS-1-81	1	piece
2CKA006220A0519	SRS-1-82 Solo free@home ivory white - solo	SRS-1-82	1	piece
2CKA006220A0147	SRS-1-83 Solo free@home aluminium silver - 63x63	SRS-1-83	1	piece
2CKA006220A0374	SRS-1-840 Solo free@home antique brass - 63x63	SRS-1-840	1	piece
2CKA006220A0536	SRS-1-866 Solo free@home stainless steel - solo	SRS-1-866	1	piece
2CKA006220A0604	SRS-1-884 Solo free@home studio white matt - 63x63	SRS-1-884	1	piece
2CKA006220A0558	SRS-2-L-803 Solo free@home grey metallic - 63x63	SRS-2-L-803	1	piece
2CKA006220A0161	SRS-2-L-81 Solo free@home anthracite - 63x63	SRS-2-L-81	1	piece
2CKA006220A0524	SRS-2-L-82 Solo free@home ivory white - solo	SRS-2-L-82	1	piece
2CKA006220A0162	SRS-2-L-83 Solo free@home aluminium silver - 63x63	SRS-2-L-83	1	piece

2CKA006220A0379	SRS-2-L-840 Solo free@home antique brass - 63x63	SRS-2-L-840	1	piece
2CKA006220A0541	SRS-2-L-866 Solo free@home stainless steel - solo	SRS-2-L-866	1	piece
2CKA006220A0609	SRS-2-L-884 Solo free@home studio white matt - 63x63	SRS-2-L-884	1	piece
2CKA006220A0562	SRS-2-R-803 Solo free@home grey metallic - 63x63	SRS-2-R-803	1	piece
2CKA006220A0173	SRS-2-R-81 Solo free@home anthracite - 63x63	SRS-2-R-81	1	piece
2CKA006220A0528	SRS-2-R-82 Solo free@home ivory white - solo	SRS-2-R-82	1	piece
2CKA006220A0174	SRS-2-R-83 Solo free@home aluminium silver - 63x63	SRS-2-R-83	1	piece
2CKA006220A0382	SRS-2-R-840 Solo free@home antique brass - 63x63	SRS-2-R-840	1	piece
2CKA006220A0545	SRS-2-R-866 Solo free@home stainless steel - solo	SRS-2-R-866	1	piece
2CKA006220A0613	SRS-2-R-884 Solo free@home studio white matt - 63x63	SRS-2-R-884	1	piece

Categorieën

Laagspanningsproducten en -systemen → Schakelaarprogramma → Afdekramen

