


PRODUCT-DETAILS

1764 NLI-84

1764 NLI-84 Rocker with labelling field
Switch/push button Single push button
studio white - 63x63



Informations générales

Extension du type de produit	1764 NLI-84
Code de produit	2CKA001731A1877
EAN	4011395995853
Description courte	1764 NLI-84 Rocker with labelling field Switch/push button Single push button studio white - 63x63
Description longue	With pilot lamp for uniform illumination of the labelling field. For flush-mounted switch 1g1w, 1g2w, intermediate, push switch. Size of labelling field: 59.7 x 11.7 mm.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Application	Switch/push button
Design Range	63x63 future linear future Busch-axcent Busch-axcent pur solo carat

Type de montage	Flush Mounted
Type of Fastening	Clamp
Finition de surface	Untreated Glossy
Matériau	Thermoplastic
Label Space Provided	Yes
Model Number	Single push button
RAL Number	RAL 9016 - Blanc signalisation
Couleur	studio white

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E1635
REACH Declaration	2CKA309999E9999

Dimensions

Produit Largeur Net	63 mm
Produit Hauteur Net	63 mm
Produit Longueur Net	20 mm
Poids net	24.5 g

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 10 pièce
Emballage Niveau 1 Poids	0.32 kg
Code douanier	85389099
E-Number (Finland)	2106150
E-Number (Sweden)	1815654
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E1635
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144002

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
-------------	-------------	------	----------	-----------------

2CKA001012A2131	2000/1 US-507 Flush Mounted Inserts Off switch 1-pole	2000/1 US-507	1	piece
2CKA001022A0656	2000/2 UK Switch insert 2-pole switch -solo	2000/2 UK	1	piece
2CKA001012A2193	2000/2 US-101-500 Flush Mounted Inserts 2-pole switch	2000/2 US-101-500	1	piece
2CKA001012A2196	2000/2 US-500 Flush Mounted Inserts 2-pole switch	2000/2 US-500	1	piece
2CKA001011A0816	2000/3 US Switch insert 3-pole switch -solo	2000/3 US	1	piece
2CKA001012A2198	2000/6 US-500 Flush Mounted Inserts Two-way switch	2000/6 US-500	1	piece
2CKA001012A2110	2000/6 US-507 Flush Mounted Inserts Two-way switch	2000/6 US-507	1	piece
2CKA001012A2194	2000/6 USGL-500 Flush Mounted Inserts Two-way switch	2000/6 USGL-500	1	piece
2CKA001022A0659	2000/6 USK-500 Flush Mounted Inserts Two-way switch	2000/6 USK-500	1	piece
2CKA001012A0954	2000/6/2 US Switch insert Two-way switch	2000/6/2 US	1	piece
2CKA001012A2199	2000/7 US-500 Flush Mounted Inserts Intermediate switch	2000/7 US-500	1	piece
2CKA001012A2130	2000/7 US-507 Flush Mounted Inserts Intermediate switch	2000/7 US-507	1	piece
2CKA001413A0483	2020 US-201 Switch insert 1 gang(s) Single push button 0 NC 1 NO	2020 US-201	1	piece
2CKA001413A0491	2020 US-205 Switch insert 2 gang(s) Series push button 0 NC 2 NO	2020 US-205	1	piece
2CKA001413A1105	2020 US-205-500 Flush Mounted Inserts 2 gang(s) Series push button	2020 US-205-500	1	piece
2CKA001413A1104	2020 US-206-500 Flush Mounted Inserts Single push button	2020 US-206-500	1	piece
2CKA001413A0574	2020 US-500 Flush Mounted Inserts Single push button	2020 US-500	1	piece
2CKA001413A1078	2020 US-507 Flush Mounted Inserts Single push button	2020 US-507	1	piece
2CKA001413A1109	2020 USGL-103 Flush Mounted Inserts Single push button	2020 USGL-103	1	piece
2CKA001413A1106	2020 USGL-500 Flush Mounted Inserts Single push button	2020 USGL-500	1	piece
2CKA001012A2238	2400/5 USK-500 Flush Mounted Inserts Series switch	2400/5 USK-500	1	piece
2CKA001012A2232	2400/6 US-500 Flush Mounted Inserts Two-way switch	2400/6 US-500	1	piece
2CKA001754A4240	1721-181K Cover Frame 1gang(s) anthracite - future linear	1721-181K	1	piece
2CKA001754A4168	1721-182 Cover Frame 1gang(s) ivory white - future	1721-182	1	piece
2CKA001754A4506	1721-182K-500 Cover Frame 1gang(s) ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	1721-183K-500 Cover Frame 1gang(s) aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	1721-184 Cover Frame 1gang(s) studio white - future	1721-184	1	piece
2CKA001754A4527	1721-184 NSK-500 Cover Frame 1gang(s) studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	1721-184-500 Cover Frame 1gang(s) studio white - future	1721-184-500	1	piece
2CKA001754A4498	1721-184K-500 Cover Frame 1gang(s) studio white - future linear	1721-184K-500	1	piece
2CKA001754A4775	1721-223 Cover Frame 1gang(s) glass purple - Busch-axcent	1721-223	1	piece
2CKA001754A4760	1721-225 Cover Frame 1gang(s) glass sun - Busch-axcent	1721-225	1	piece
2CKA001754A4770	1721-226 Cover Frame 1gang(s) glass avocado - Busch-axcent	1721-226	1	piece

2CKA001754A4765	1721-227 Cover Frame 1gang(s) glass coral - Busch-axcent	1721-227	1	piece
2CKA001754A4755	1721-228 Cover Frame 1gang(s) glass ocean - Busch-axcent	1721-228	1	piece
2CKA001754A4780	1721-229 Cover Frame 1gang(s) glass oyster - Busch-axcent	1721-229	1	piece
2CKA001754A4790	1721-243 Cover Frame 1gang(s) paper brown - Busch-axcent	1721-243	1	piece
2CKA001754A4800	1721-245 Cover Frame 1gang(s) glass black - Busch-axcent	1721-245	1	piece
2CKA001754A4785	1721-248 Cover Frame 1gang(s) paper blue - Busch-axcent	1721-248	1	piece
2CKA001754A4688	1721-270-500 Cover Frame 1gang(s) platinum - Busch-axcent	1721-270-500	1	piece
2CKA001754A4708	1721-275-500 Cover Frame 1gang(s) black matt - Busch-axcent	1721-275-500	1	piece
2CKA001754A4698	1721-276-500 Cover Frame 1gang(s) titanium - Busch-axcent	1721-276-500	1	piece
2CKA001754A4437	1721-280 Cover Frame 1gang(s) white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	1721-281 Cover Frame 1gang(s) black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	1721-281/11 Cover Frame 1gang(s) black - Busch-axcent flat	1721-281/11	1	piece
2CKA001754A4543	1721-283 Cover Frame 1gang(s) brown glass - Busch-axcent	1721-283	1	piece
2CKA001754A4331	1721-284 Cover Frame 1gang(s) studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	1721-284/11 Cover Frame 1gang(s) studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	1721-285 Cover Frame 1gang(s) yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	1721-286 Cover Frame 1gang(s) green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	1721-287 Cover Frame 1gang(s) red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	1721-288 Cover Frame 1gang(s) blue - Busch-axcent	1721-288	1	piece
2CKA001754A4805	1721-290 Cover Frame 1gang(s) slate grey - Busch-axcent	1721-290	1	piece
2CKA001754A4471	1721-291-500 Cover Frame 1gang(s) entrée-grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	1721-295-500 Cover Frame 1gang(s) château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	1721-298 Cover Frame 1gang(s) concrete grey - Busch-axcent	1721-298	1	piece
2CKA001754A4481	1721-299-500 Cover Frame 1gang(s) maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4535	1721-80-500 Cover Frame 1gang(s) chrome - solo	1721-80-500	1	piece
2CKA001754A4538	1721-80G-500 Cover Frame 1gang(s) chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	1721-811 Cover Frame 1gang(s) white glass - carat	1721-811	1	piece
2CKA001754A4820	1721-815 Cover Frame 1gang(s) porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	1721-821 Cover Frame 1gang(s) bronze - carat	1721-821	1	piece
2CKA001754A4356	1721-823-101 Cover Frame 1gang(s) gold - carat	1721-823-101	1	piece
2CKA001754A4322	1721-825 Cover Frame 1gang(s) glass black - carat	1721-825	1	piece
2CKA001754A4360	1721-826-101 Cover Frame 1gang(s) chrome - carat	1721-826-101	1	piece

2CKA001754A4605	1721-831-500 Cover Frame 1gang(s) anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	1721-832-500 Cover Frame 1gang(s) ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	1721-833-500 Cover Frame 1gang(s) polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	1721-835-500 Cover Frame 1gang(s) polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	1721-836-500 Cover Frame 1gang(s) polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	1721-838-500 Cover Frame 1gang(s) polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	1721-843-500 Cover Frame 1gang(s) antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	1721-84-500 Cover Frame 1gang(s) studio white - solo	1721-84-500	1	piece
2CKA001754A4585	1721-845-500 Cover Frame 1gang(s) antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	1721-846-500 Cover Frame 1gang(s) antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	1721-848-500 Cover Frame 1gang(s) antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	1721-860 Cover Frame 1gang(s) stainless steel - carat	1721-860	1	piece
2CKA001754A4500	1721-866K-500 Cover Frame 1gang(s) stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001754A4531	1721-884K-500 Cover Frame 1gang(s) studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	1721-885K-500 Cover Frame 1gang(s) black matt - future linear	1721-885K-500	1	piece
2CKA001754A4714	1722-12-182K-101 Cover Frame 2gang(s) red - future linear	1722-12-182K- 101	1	piece
2CKA001754A4241	1722-181K Cover Frame 2gang(s) anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	1722-182 Cover Frame 2gang(s) ivory white - future	1722-182	1	piece
2CKA001754A4231	1722-182K Cover Frame 2gang(s) ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	1722-183K-500 Cover Frame 2gang(s) aluminium silver - future linear	1722-183K-500	1	piece
2CKA001754A4174	1722-184 Cover Frame 2gang(s) studio white - future	1722-184	1	piece
2CKA001754A4508	1722-184-500 Cover Frame 2gang(s) studio white - future	1722-184-500	1	piece
2CKA001754A4499	1722-184K-500 Cover Frame 2gang(s) studio white - future linear	1722-184K-500	1	piece
2CKA001754A4776	1722-223 Cover Frame 2gang(s) glass purple - Busch-axcent	1722-223	1	piece
2CKA001754A4761	1722-225 Cover Frame 2gang(s) glass sun - Busch-axcent	1722-225	1	piece
2CKA001754A4771	1722-226 Cover Frame 2gang(s) glass avocado - Busch-axcent	1722-226	1	piece
2CKA001754A4766	1722-227 Cover Frame 2gang(s) glass coral - Busch-axcent	1722-227	1	piece
2CKA001754A4756	1722-228 Cover Frame 2gang(s) glass ocean - Busch-axcent	1722-228	1	piece
2CKA001754A4781	1722-229 Cover Frame 2gang(s) glass oyster - Busch-axcent	1722-229	1	piece
2CKA001754A4791	1722-243 Cover Frame 2gang(s) paper brown - Busch-axcent	1722-243	1	piece
2CKA001754A4801	1722-245 Cover Frame 2gang(s) glass black - Busch-axcent	1722-245	1	piece

2CKA001754A4786	1722-248 Cover Frame 2gang(s) paper blue - Busch-axcent	1722-248	1	piece
2CKA001754A4689	1722-270-500 Cover Frame 2gang(s) platinum - Busch-axcent	1722-270-500	1	piece
2CKA001754A4709	1722-275-500 Cover Frame 2gang(s) black matt - Busch-axcent	1722-275-500	1	piece
2CKA001754A4699	1722-276-500 Cover Frame 2gang(s) titanium - Busch-axcent	1722-276-500	1	piece
2CKA001754A4438	1722-280 Cover Frame 2gang(s) white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4410	1722-281 Cover Frame 2gang(s) black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	1722-281/11 Cover Frame 2gang(s) black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	1722-283 Cover Frame 2gang(s) brown glass - Busch-axcent	1722-283	1	piece
2CKA001754A4332	1722-284 Cover Frame 2gang(s) studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	1722-284/11 Cover Frame 2gang(s) studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	1722-285 Cover Frame 2gang(s) yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	1722-286 Cover Frame 2gang(s) green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	1722-287 Cover Frame 2gang(s) red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	1722-288 Cover Frame 2gang(s) blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	1722-290 Cover Frame 2gang(s) slate grey - Busch-axcent	1722-290	1	piece
2CKA001754A4472	1722-291-500 Cover Frame 2gang(s) entrée-grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	1722-295-500 Cover Frame 2gang(s) château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	1722-298 Cover Frame 2gang(s) concrete grey - Busch-axcent	1722-298	1	piece
2CKA001754A4482	1722-299-500 Cover Frame 2gang(s) maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4537	1722-80-500 Cover Frame 2gang(s) chrome - solo	1722-80-500	1	piece
2CKA001754A4327	1722-80G Cover Frame 2gang(s) chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	1722-811 Cover Frame 2gang(s) white glass - carat	1722-811	1	piece
2CKA001754A4821	1722-815 Cover Frame 2gang(s) porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	1722-821 Cover Frame 2gang(s) bronze - carat	1722-821	1	piece
2CKA001754A4357	1722-823-101 Cover Frame 2gang(s) gold - carat	1722-823-101	1	piece
2CKA001754A4323	1722-825 Cover Frame 2gang(s) glass black - carat	1722-825	1	piece
2CKA001754A4361	1722-826-101 Cover Frame 2gang(s) chrome - carat	1722-826-101	1	piece
2CKA001754A4606	1722-831-500 Cover Frame 2gang(s) anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001754A4601	1722-832-500 Cover Frame 2gang(s) ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A4576	1722-833-500 Cover Frame 2gang(s) polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	1722-835-500 Cover Frame 2gang(s) polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	1722-836-500 Cover Frame 2gang(s) polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece

2CKA001754A4561	1722-838-500 Cover Frame 2gang(s) polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	1722-843-500 Cover Frame 2gang(s) antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	1722-84-500 Cover Frame 2gang(s) studio white - solo	1722-84-500	1	piece
2CKA001754A4586	1722-845-500 Cover Frame 2gang(s) antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	1722-846-500 Cover Frame 2gang(s) antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	1722-848-500 Cover Frame 2gang(s) antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	1722-860 Cover Frame 2gang(s) stainless steel - carat	1722-860	1	piece
2CKA001754A4501	1722-866K-500 Cover Frame 2gang(s) stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	1722-884K Cover Frame 2gang(s) studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	1722-885K-500 Cover Frame 2gang(s) black matt - future linear	1722-885K-500	1	piece
2CKA001754A4242	1723-181K Cover Frame 3gang(s) anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	1723-182 Cover Frame 3gang(s) ivory white - future	1723-182	1	piece
2CKA001754A4232	1723-182K Cover Frame 3gang(s) ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	1723-183K-500 Cover Frame 3gang(s) aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	1723-184 Cover Frame 3gang(s) studio white - future	1723-184	1	piece
2CKA001754A4366	1723-184 NSK Cover Frame 3gang(s) studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4502	1723-184K-500 Cover Frame 3gang(s) studio white - future linear	1723-184K-500	1	piece
2CKA001754A4777	1723-223 Cover Frame 3gang(s) glass purple - Busch-axcent	1723-223	1	piece
2CKA001754A4762	1723-225 Cover Frame 3gang(s) glass sun - Busch-axcent	1723-225	1	piece
2CKA001754A4772	1723-226 Cover Frame 3gang(s) glass avocado - Busch-axcent	1723-226	1	piece
2CKA001754A4767	1723-227 Cover Frame 3gang(s) glass coral - Busch-axcent	1723-227	1	piece
2CKA001754A4757	1723-228 Cover Frame 3gang(s) glass ocean - Busch-axcent	1723-228	1	piece
2CKA001754A4792	1723-243 Cover Frame 3gang(s) paper brown - Busch-axcent	1723-243	1	piece
2CKA001754A4802	1723-245 Cover Frame 3gang(s) glass black - Busch-axcent	1723-245	1	piece
2CKA001754A4787	1723-248 Cover Frame 3gang(s) paper blue - Busch-axcent	1723-248	1	piece
2CKA001754A4690	1723-270-500 Cover Frame 3gang(s) platinum - Busch-axcent	1723-270-500	1	piece
2CKA001754A4710	1723-275-500 Cover Frame 3gang(s) black matt - Busch-axcent	1723-275-500	1	piece
2CKA001754A4700	1723-276-500 Cover Frame 3gang(s) titanium - Busch-axcent	1723-276-500	1	piece
2CKA001754A4439	1723-280 Cover Frame 3gang(s) white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	1723-281 Cover Frame 3gang(s) black - Busch-axcent	1723-281	1	piece
2CKA001753A4128	1723-281/11 Cover Frame 3gang(s) black - Busch-axcent flat	1723-281/11	1	piece

2CKA001754A4545	1723-283 Cover Frame 3gang(s) brown glass - Busch-axcent	1723-283	1	piece
2CKA001754A4333	1723-284 Cover Frame 3gang(s) studio white - Busch-axcent	1723-284	1	piece
2CKA001753A4123	1723-284/11 Cover Frame 3gang(s) studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	1723-285 Cover Frame 3gang(s) yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	1723-286 Cover Frame 3gang(s) green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	1723-287 Cover Frame 3gang(s) red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	1723-288 Cover Frame 3gang(s) blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	1723-290 Cover Frame 3gang(s) slate grey - Busch-axcent	1723-290	1	piece
2CKA001754A4473	1723-291-500 Cover Frame 3gang(s) entrée-grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	1723-295-500 Cover Frame 3gang(s) château-black - Busch-axcent	1723-295-500	1	piece
2CKA001754A4797	1723-298 Cover Frame 3gang(s) concrete grey - Busch-axcent	1723-298	1	piece
2CKA001754A4483	1723-299-500 Cover Frame 3gang(s) maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4540	1723-80-500 Cover Frame 3gang(s) chrome - solo	1723-80-500	1	piece
2CKA001754A4328	1723-80G Cover Frame 3gang(s) chrome gloss - solo	1723-80G	1	piece
2CKA001754A4444	1723-811 Cover Frame 3gang(s) white glass - carat	1723-811	1	piece
2CKA001754A4260	1723-821 Cover Frame 3gang(s) bronze - carat	1723-821	1	piece
2CKA001754A4358	1723-823-101 Cover Frame 3gang(s) gold - carat	1723-823-101	1	piece
2CKA001754A4324	1723-825 Cover Frame 3gang(s) glass black - carat	1723-825	1	piece
2CKA001754A4362	1723-826-101 Cover Frame 3gang(s) chrome - carat	1723-826-101	1	piece
2CKA001754A4607	1723-831-500 Cover Frame 3gang(s) anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	1723-832-500 Cover Frame 3gang(s) ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	1723-833-500 Cover Frame 3gang(s) polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	1723-835-500 Cover Frame 3gang(s) polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	1723-836-500 Cover Frame 3gang(s) polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001754A4562	1723-838-500 Cover Frame 3gang(s) polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	1723-843-500 Cover Frame 3gang(s) antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	1723-84-500 Cover Frame 3gang(s) studio white - solo	1723-84-500	1	piece
2CKA001754A4587	1723-845-500 Cover Frame 3gang(s) antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	1723-846-500 Cover Frame 3gang(s) antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	1723-848-500 Cover Frame 3gang(s) antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	1723-860 Cover Frame 3gang(s) stainless steel - carat	1723-860	1	piece
2CKA001754A4319	1723-866K Cover Frame 3gang(s) stainless steel - Pure Stainless Steel	1723-866K	1	piece

2CKA001754A4416	1723-884K Cover Frame 3gang(s) studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	1723-885K Cover Frame 3gang(s) black matt - future linear	1723-885K	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Cover Plates (partly incl. Insert) → Mechanical Controls

