





22.32








- Open Type Device Pollution degree 2 Installation Environment
- Maximum Surrounding Air Temperature 50°C
- Minimum distance among modular contactors 9 mm
  Field Wiring Terminals:
- Use 60/75°C copper conductor only and wire ranges No. 10-12-18-24 AWG, Solid only
- Terminal tightening torque 7.0 lb.in. (0.8 Nm)
- Suitable for use on a circuit capable of delivering not more than 5000 ARMS Symmetrical, 240 V ac, when protected by Listed Cartridge Fuses, rated K5 Class (No Current Limiting, Non-Time Delay, max 600 Vac, 30 A, 50 kA A.I.C.) or RK5 Class (Current Limiting, Time Delay, max 600 Vac, 15 A, 50 kA A.I.C.) or equivalent
- For use in a circuit protected by Type1 or Type2 Surge Protective Devices with "Max Voltage Protection" rating of 3.7 kVpk and "Minimum Nominal Discharge Current" of 5 kA (at 6 kV)

Utility Model - IB2232001 - 01/21 - Finder S.p.A. con unico socio - 10040 ALMESE (TO) - ITALY



	022.33	022.35	
	13 23	13 21	
	$\langle      $	, I L <sub>+</sub>	
	) )	) (	
	14 24	1 I 14 22	
022.33	2 NO (DPST	- NO)	
022.35	1 NO (SPST-	- NO) + 1 NC (SPST- N	C)
	I <sub>th</sub> 6	5 A	
_/_	AC15 70	00 VA	
	(230 V AC)		

# **ENGLISH**

#### 22.32 MODULAR CONTACTORS 25 A

Contact gap  $\geq$  3 mm for NO contacts only; NC contacts  $\geq$  1.5 mm. Compliant with EN 61095: 2009. AC/DC silent coil (with varistor protection).

- **1** CONNECTION DIAGRAM
- **2** OUTLINE DRAWINGS
- **3** FRONT VIEW
  - A = Selector (22.32.0.xxx.xx40)

The three-position manual selector has the following functions:

### ON position

The contacts are latched in the operated state (NO contacts - closed and NC contacts - open), the mechanical indicator is visible in its window, the LED is not illuminated.

# **AUTO** position

The state of contacts, mechanical indicator and LED follow the coil supply voltage.

## **OFF** position

Even if terminals A1 - A2 are supplied with rated voltage, the coil is not energized, and so the contacts remain in the non-operated state, the mechanical indicator is not visible and the LED is not illuminated.

B = LED

C = Mechanical indicator

# 4 ACCESSORIES

- Auxiliary contact module available, "Quick assembly" with the main contactor 022.33/022.35
- It is not possible to assembly the auxiliary module on 22.32.0.xxx.x4x0 (2 NC versions)

#### OTHER DATA

It is suggested an air gap of 9 mm between adjacent relays for installations and working conditions close to the limit (that is, ambient temperature > 40°C, coil operated for a prolonged period of time, all contacts loaded with current > 20 A).

